



INDOOR UNIT: AD28AL AD38AL

SPLIT SYSTEM AIR CONDITIONER

Model No.	Product Code No.
AD28AL	387006114
AD38AL	387006115



IMPORTANT! Please read before installation

This air conditioning system meets strict safety and operating standards.

For the installer or service person, it is important to install or service the system so that it operates safely and efficiently.

For safe installation and trouble-free operation, you must:

- Carefully read this instruction booklet before beginning.
- · Follow each installation or repair step exactly as shown.
- · Observe all local, state and national electrical codes.
- Pay close attention to all warning and caution notices given in this manual.
- •The unit must be supplied with a dedicated electrical line.



This symbol refers to a hazard or unsafe practice which can result in severe personal injury or death.



This symbol refers to a hazard or unsafe practice which can result in personal injury or product or property damage.

If necessary, get help

These instructions are all you need for most installation sites and maintenance conditions.

If you require help for a special problem, contact our sale/service outlet or your certified dealer for additional instructions.

In case of improper installation

The manufacturer shall in no way be responsible for improper installation or maintenance service, including failure to follow the instructions in this document.

SPECIAL PRECAUTIONS

 During installation, connect before the refrigerant system and then the wiring one; proceed in the reverse orden when removing the units.

WARNING

When wiring



- Do not supply power to the unit until all wiring and tubing are completed or reconnected and checked, to ensure the grounding.
- Highly dangerous electrical voltages are used in this system. Carefully refer to the wiring diagram and these instructions when wiring.

Improper connections and inadequate grounding can cause accidental injury and death.

- · Ground the unit following local electrical codes.
- The Yellow/Green wire cannot be used for any connection different from the ground connection.
- Connect all wiring tightly. Loose wiring may cause overheating at connection points and a possible fire hazard.
- Do not allow wiring to touch the refrigerant tubing, compressor, or any moving parts of the fan.
- Do not use multi-core cable when wiring the power supply and control lines. Use separate cables for each type of line.

When transporting

Be careful when picking up and moving the indoor and outdoor units. Get a partner to help, and bend your knees when lifting to reduce strain on your back. Sharp edges or thin aluminium fins on the air conditioner can cut your fingers.

When installing...

... In a ceiling

Make sure the ceiling is strong enough to hold the unit-weight. It may be necessary to build a strong wooden or metal frame to provide added support.

... In a room

Properly insulate any tubing run inside a room to prevent "sweating", which can cause dripping and water damage to walls and floors.

... In moist or uneven locations

Use a raised concrete base to provide a solid level foundation for the outdoor unit. This prevents damage and abnormal vibrations.

... In area with strong winds

Securely anchor the outdoor unit down with bolts and a metal frame. Provide a suitable air baffle.

... In a snowy area (for heat pump-type systems)

Install the outdoor unit on a raised platform that is higher then drifting snow. Provide snow vents.

When connecting refrigerant tubing

- · Keep all tubing runs as short as possible.
- · Use the flare method for connecting tubing.
- Apply refrigerant lubricant to the matching surfaces of the flare and union tubes before connecting them; screw by hand and then tighten the nut with a torque wrench for a leak-free connection.
- · Check carefully for leaks before starting the test run.

NOTE:

Depending on the system type, liquid and gas lines may be either narrow or wide. Therefore, to avoid confusion, the refrigerant tubing for your particular model is specified as narrow tube for liquid, wide tube for gas.

When servicing

- Turn the power OFF at the main power board before opening the unit to check or repair electrical parts and wiring.
- Keep your fingers and clothing away from any moving parts.
- Clean up the site after the work, remembering to check that no metal scraps or bits of wiring have been left inside the unit being serviced.
- Ventilate the room during the installation or testing the refrigeration system; make sure that, after the installation, no gas leaks are present, because this could produce toxic gas and dangerous if in contact with flames or heat-sources.

Table of Contents

1. SPECIFICATIONS	4
1-1 Unit specifications	4
1-2 Major Component specifications	6
1-3 Other Component specifications	8
1-4 Indoor Fan performance	9
2. DIMENSIONAL DATA	10
3. ELECTRICAL DATA	11
3-1 Electric Wiring Diagrams	11
4. FUNCTION	12
4-1 Cool Mode Operation	12
4-2 Heat Mode Operation	13
4-3 Auto Mode Operation	14
4-4 Dry Mode Operation	15
4-5 Fan Mode Operation	16
4-6 Protections in Cool/Dry Mode	16
4-7 Protections in Heat Mode	18
4-8 Sleep Function	21
4-9 Daily Timer	21
4-10 FEEL Function	21
4-11 Drain Pump Operation	22
5. TROUBLESHOOTING	23
5-1 Check before and after troubleshooting	23
5-2 Air conditioner does not operate	23
5-3 Some part of air conditioner does not operate	27
5-4 Air conditioner operates, but abnormalities are observed	29
5-5 If a sensor is defective	31
6. CHECKING ELECTRICAL COMPONENTS	32
6-1 Measurement of Insulation Resistance	32
6-2 Checking Continuity of Fuse on PCB Ass'y	33
6-3 Checking Motor Capacitor	33

1. SPECIFICATIONS

External static pressure (High)

1-1 Unit Specifications

AD28AL

Power source		220 - 240V ~ 50Hz		
Voltage rating		230V		
Per	formance		Cooling	Heating
	Capacity		See catalogue with the requested matchi	
	Air circulation (High/Med./Low)	m³/h	/h 600/510/440	

Pa (mm W.G.)

atures			
Controls/Temperature controls			Microprocessor/ I.C. thermostat
Control unit			Wireless remote control unit
Timer			ON/OFF 24 hours
Fan speed			3 and Auto /1(Hi)
Air Filter			Washable
Operation sound (*)	High/Med./Low	dB-A	54/52/49
Refrigerant tubing connections			Flare type
Refrigerant	Narrow tube	mm(in.)	6,35 (1/4)
tube diameter	Wide tube	mm(in.)	9,52 (3/8)
Refrigerant			R410A

Dimensions & Weight				
Dimensions	Unit	Height	mm	266
		Width	mm	571
		Depth	mm	852
Package dimensions	Unit	Height	mm	365
		Width	mm	745
		Depth	mm	1086
		Volume	m3	0,3
Weight	Unit	Net	kg	30
		Shipping	kg	34

DATA SUBJECT TO CHANGE WITHOUT NOTICE

49(5) at shipment - 69 (7) with booster cable

(*) Power level measured at operating conditions (HIGH speed / 5mmH20 external static pressure) and inside discharge air duct

AD38AL

Power source			220 - 240	V ~ 50Hz
Voltage rating			23	0V
Porformanco		1	Cooling	Heating
Capacity			See catalogue with th	e requested matching
Air circulation (High/Med /Low)		m ³ /h	600/510/440	
External static pressure (High)	Pa (m	mWG)	49(5) at shipment - 69	(7) with booster cable
	1 a (11	III VV.O.)		
Features				
Controls/Temperature controls			Microprocessor/	I.C. thermostat
Control unit			Wireless remo	te control unit
Timer			ON/OFF	24 hours
Fan speed			3 and Au	uto /1(Hi)
Air Filter			Wash	nable
Operation sound (*)	High/Med./Low	dB-A	54/5	2/49
Refrigerant tubing connections			Flare	e type
Refrigerant	Narrow tube	mm(in.)	6,35	(1/4)
tube diameter	Wide tube	mm(in.)	9,52	(3/8)
Refrigerant			R4 ²	10A
Dimensions & Weight				
Dimensions Unit	Height	mm	20	56
	Width	mm	57	71
	Depth	mm	8	52
Package dimensions Unit	Height	mm	36	65
	Width	mm	74	45
	Depth	mm	10	86
	Volume	m3	0	,3
Weight Unit	Net	kg	3	0

DATA SUBJECT TO CHANGE WITHOUT NOTICE

34

(*) Power level measured at operating conditions (HIGH speed / 5mmH20 external static pressure) and inside discharge air duct

kg

Shipping

1-2 Major Component Specifications

AD28AL

Controller PCB	
Part No.	KSA
Controls	Microprocessor
Control circuit fuse	250 V - 5 A
Remote Control Unit	RC-7(RC)

an 9 Fee Meter				
a ran wotor				
Туре			Centrifugal fan	
Q'ty Dia. and le	enght	mm	2Ø 160 / L 240	
Fan motor modelQ	'ty		3RGB-CO-45-30 5V/11	
No. Of polesrpm (2	230 V) (*)		4 1060/1000/910	
Running Amps (HIGI	H speed)	Α	0,45	
Power input (HIGH s	peed)	W	110	
Coil resistance (Amb	ient temp. 20 °C)	Ω	BLU-BRN: 95	
			BRN-BLK: 37	
			BLK-GRY: 15	
			GRY-VLT: 15	
			WLT-RED: 30	
			RED-YEL: 101	
Safety devices	Туре		Internal thermal protector - 7AM 037 A 5	
-	Operating temp. Open	°C	150 ± 5K	
Run capacitor		μF	1,8	
	-	VAC	450	

Γ	Heat Exch. Coil		
	Coil		Aluminium plate fin / Copper tube
	Rows		2
	Fin pitch	mm	1,6
	face area	m2	0,126

DATA SUBJECT TO CHANGE WITHOUT NOTICE

(*) Fan speeds: H / M / L measured at operating conditions(HIGH speed / 5mmH20 external static pressure)

AD38AL

Controller PCB	
Part No.	KSA
Controls	Microprocessor
Control circuit fuse	250 V - 5 A

Remote Control Unit

RC-7(RC)

Fan & Fan Motor			
Туре			Centrifugal fan
Q'ty Dia. and lengl	nt	mm	2Ø 160 / L 240
Fan motor modelQ'ty			3RGB-CO-45-30 5V/11
No. Of polesrpm (230	V) (*)		4 1060/1000/910
Running Amps (HIGH sp	beed)	A	0,45
Power input (HIGH spee	ed)	W	110
Coil resistance (Ambient	t temp. 20 °C)	Ω	BLU-BRN: 95
			BRN-BLK: 37
			BLK-GRY: 15
			GRY-VLT: 15
			WLT-RED: 30
			RED-YEL: 101
Safety devices	Туре		Internal thermal protector - 7AM 037 A 5
	Operating temp. C)pen °C	150 ± 5K
Run capacitor		μF	1,8
		VAC	450

Hea	at Exch. Coil		
	Coil		Aluminium plate fin / Copper tube
	Rows		2
	Fin pitch	mm	1,6
	face area	m2	0,126
		D 41	

DATA SUBJECT TO CHANGE WITHOUT NOTICE

(*) Fan speeds: H / M / L measured at operating conditions(HIGH speed / 5mmH20 external static pressure)

1-3 Other Component Specifications

AD28AL AD38AL

Thermistor (Coil sense	or TH1)	
Resistance	KΩ	2 10 ± 3%
Thermistor (Room sen	sor TH2)	
Resistance	KΩ	2 10 ± 5%
Drain pump		
Model		PC 309564003
Rating	Voltage	220/240V - 50Hz
	Input	14W
Total head capacity		0,4 l/min
Safety float switch		
Model		BI 1300 2725
Contact rating		230V AC/DC - 0,5A

1-4 Indoor Fan Performance

If external static pressure is too great (due to long extension of ducts, for example), the air flow volume may drop too low at each air outlet. This problem may be solved by increasing the fan speed using the following procedure:

- Remove the screw on the electrical component box and remove the cover plate.
- (2) Disconnect the fan motor sockets in the box.
- (3) Take out the booster cable (sockets at both ends) clamped in the box.
- (4) Securely connect the booster cable sockets between the disconnected fan motor sockets in step 2 as shown in the Fig. 1-1.
- (5) Place the cable neatly in the box and reinstall the cover plate.





NOTE

HH: Using the booster cable

H : At shipment

- How to read the diagram

The vertical axis is the external static pressure (Pa) while the horizontal one is the AIR FLOW RATE (m3/h). The characteristic curves for HH, H, M and L fan speed are shown. The nameplate values shown are based on the H air flow rate. For the type 09/12 flow rate is 600m3/h while the

Fig. 1-2

The nameplate values shown are based on the H air flow rate. For the type 09/12 flow rate is 600m3/h while the external static pressure is 49 Pa at H position. If external static pressure is too great (due, for example, to long duct extension), the air flow rate may drop too much at each air outlet.

This problem can be solved increasing the fan speed with the booster cable.

2. DIMENSIONAL DATA



3. ELECTRICAL DATA 3-1 Electric Wiring Diagrams



4. FUNCTION

4-1 Cool Mode Operation



In Cool Mode, the operation of the Compressor (COMP), Outdoor Fan (OFAN) and Indoor Fan (IFAN) are determined by the difference between the Room Temperature (RT) and the Set Point Temperature (SPT) as in the graph above.

Notes:

- a. In this graph, the IFAN is operating in the "Auto Fan Speed" setting. If the user has selected the low, medium or high fan speed, the IFAN will run constantly at that speed only.
- b. In addition to the value of (RT-SPT), the operations of the relays are also controlled by protection delays. For example, (a) the minimum On/Off time of the COMP is 3 min and 3 min respectively, and (b) the IFAN can change speed only after it has operated at the same speed for 30 sec in autofan setting and 1 sec for H/M/L setting.

4-2 Heat Mode Operation



The Heat Mode operation is similar to the Cool Mode operation. The COMP, OFAN and IFAN are mainly controlled by the value of (RT – SPT). In the graph above, the IFAN is operating in Auto Fan speed mode. Therefore, the IFAN speed changes automatically according to the (RT - SPT).

- Note 1: The 30s IFAN operation is for purging the heat from the in-coil after COMP has stopped.
- Note 2: The IFAN will not be turned on until the in-coil temperature is high enough (as shown in the graph below) to prevent the unit from supplying cool air.



ICT = In-coil Temperature

- Any = Hi, Med or Low fan speed which is selected by the user. In Auto Fan Speed Mode, the fan speed is selected by the unit automatically instead.
- Low = The indoor fan is forced to operate at low speed

4-3 Auto (Cool/Heat) Mode Operation



In Auto Mode, the unit switches between the Auto Cooling Mode and Auto Heating Mode automatically to maintain the room temperature (RT) at the set point temperature (SPT).

4-4 Dry Mode Operation



In Dry Mode, the unit operates in a mild cool mode to lower the humidity of the room. In order to maintain a high efficiency in the drying operation without over lowering the room temperature excessively, the Dry Mode is different from the Cool Mode in two ways.

- The IFAN is forced to operate at low speed only. And, the IFAN is turned off with the COMP.
- b. The unit operates in either the "Dry-on" state or the "Dry-off" state. If RT SPT, the unit will operate in "Dry-off" state. After the COMP has stopped working for 15 min, it is forced to operate for 6 min. If RT > SPT, the unit will operate in "Dry-on" state. After the COMP has been working for 15 min, it is forced off for 3.5 min.

Note 1: COMP is forced off in Dry-on state.

Note 2: COMP is forced to operate in Dry-off state.

4-5 Fan Mode Operation

In Fan Mode, the indoor fan is turned on to improve the air circulation in the room. COMP and OFAN remain OFF all the time.

Note: If the user has selected the Auto Fan Speed setting, the IFAN speed would be selected by the unit automatically according to the difference between RT and SPT, as in Cool Mode.

4-6 Protection operations in Cool and Dry Mode

1. Indoor Coil Defrost Protection

The in-coil defrost protection can prevent the ice formation at the in-coil when the ambient temperature is low.



t1 = 5 min minimum for each COMP starting

t2 = OFAN cycling (alternate between ON and OFF every 30 sec) for 20 min maximum

t3 = COMP and OFAN stop for 10 min

2. Outdoor Coil High Pressure Protection

The out-coil high pressure protection prevent the build up of high pressure at the out-coil during cooling operation.



Note 1: In some applications, the outdoor fan and the compressor are controlled together by the COMP relay output from the controller. In this case, it will take more time for the out-coil to cool down during the high pressure protection, because the outdoor fan will be turned off with the compressor instead of working as in the graph above.

4-7 Protection Operations in Heat Mode

1. Outdoor Coil Deice Protection

The deice process is controlled by an Ice Detection Algorithm (IDA). The IDA is a unique control algorithm incorporated to maintain optimal utilization of the heat pump capacity, especially in below-zero outdoor temperature condition. The out-coil deicing will be activated not only by static temperature detection as normally done, but also while ice forming is detected on the out-coil.



The following routine runs continuously while A/C is working in Heat Mode. The routine outputs Deicing Dynamic Threshold (DDT) and Deicer Threshold Flag (DTF) to the main Deicer routine.



Explanation:

The "Ice Forming Detection" will be done by two algorithms -

- a. In Dynamic Temp Detection, the ice formation will be detected by
 - (i) Compare the OCT with a Deicing Dynamic Temperature Threshold, and
 - (ii) Detect the drop in ICT which accompany the ice formation.
- The Static Temp Detection will be done by comparing the OCT with a Deicing Static Temperature Threshold.

The Deicing Data Record is used to determine the time delay between two deicing cycles. In general, the time delay will be increased if the last deicing cycle can be completed quickly.

2. Indoor Coil High Pressure Protection in Heat Mode

The in-coil high pressure protection prevents the build up of high pressure at the in-coil during heating operation.



4-8 Sleep Function

Room temperature is automatically controlled to compensate for body temperature variations while sleeping. This mode of operation is designed for maximal comfort in both COOL and HEAT modes.



4-9 Daily Timer Function

There are 2 independent timers – ON Timer and OFF Timer. Unit can be programmed to be ON and OFF automatically at preset time everyday, by using a remote controller. The resolutions of the ON/OFF timers are 10 min.

4-10 IFEEL Function

There are 2 independent timers – ON Timer and OFF Timer. Unit can be programmed to be ON and OFF automatically at preset time everyday, by using a remote controller. The resolutions of the ON/OFF timers are 10 min.

4-11 Pump Operation

Drain pump operates only in Cool and Dry Mode.

The float switch used for water level detection is closed under normal condition, and is open when wate overflow.

For the NEC version of MCU, the "Overflow" and "Normal" conditions are indicated by a logic "0" and "1" at the float switch pins connector respectively.

For the Fujitsu version of MCU, the "Overflow" and "Normal" condition are indicated by a logic "1" and "0" at the float switch pins connector respectively. The overflow condition can activate the water pump in Standy and operating modes



5. TROUBLESHOOTING

5-1. Check before and after troubleshooting



Hazardous voltage can cause ELECTRIC SHOCK or DEATH. Disconnect power or turn off circuit breaker before you start checking or servicing.

5-1-1. Check power supply wiring.

• Check that power supply wires are correctly connected to terminals L and N on the terminal plate in the indoor unit.

5-1-2. Check inter-unit wiring.

• Check that inter-unit wiring is correctly connected to the outdoor unit from the indoor unit.

5-1-3. Check power supply.

- Check that voltage is in specified range (±10% of the rating).
- Check that power is being supplied.

5-1-4. Check lead wires and connectors in indoor and outdoor units.

- Check that coating of lead wires is not damaged.
- Check that lead wires and connectors are firmly connected.
- Check that wiring is correct.

5-2. Air conditioner does not operate.

5-2-1. Circuit breaker trips (or fuse blows).

A. When the circuit breaker is set to ON, it trips immediately. (Resetting is not possible.)

- There is a possibility of ground fault.
- Check insulation resistance.

If resistance value is $2M\Omega$ or less, insulation is defective ("NO").



B. Circuit breaker trips in several minutes after turning the air conditioner on.

• There is a possibility of short circuit.



5-2-2. Neither indoor nor outdoor unit runs.

A. Power is not supplied.



B. Check POBERBUTTCONsielen to an it.



C. Check remote control unit.



D. Check fuse on the indoor PCB Ass'y.



E. Check TIMER on the remote control unit.



5-2-3. Only outdoor unit does not run.

A. Check setting temperature.



5-2-4. Only Indoor unit does not run.



5-3. Some part of air conditioner does not operate.

5-3-1. Only indoor fan does not run.



5-3-2 Only outdoor fan does not run.



5-3-3. Only compressor does not run



5-3-4. Compressor and outdoor fan do not run



5-4. Air conditioner operates, but abnormalities are observed

5-4-1. Operation does not switch from HEAT to COOL (or COOL to HEAT)



HEAT to COOL



5-4-2. Poor cooling or heating.



5-4-3. Excessive cooling or heating.



6-5 If a sensor is defective

6-5-1 ICT (indoor coil sensor) OCT(outdoor coil sensor) RAT (room ambient temperature) are defective.



NOTE Allarm signal (*)

Stan by lampoon on the front side of the indoor unit will flash on and off when the thermistor is defective. At the same time the outdoor unit will stop. Indoor operate only for ventilation.



6. CHECKING ELECTRICAL COMPONENTS

6-1 Measurement of Insulation Resistance

The insulation is in good condition if the resistance exceeds $2M\Omega$



NOTE

The shape of the power plug may differ from that of the air conditioner which you are servicing.

6-1-1. Power supply wires

Clamp the grounding terminal of the power plug with a lead clip of the insulation resistance tester and measure the resistance by placing a probe on both the two power terminals. (fig.1)

Then, also measure the resistance between the grounding and other power terminals. (fig.1)

6-1-2. Indoor Unit

Clamp a metallic part of the unit with the lead clip of the insulation resistance tester and measure the resistance by placing a probe on each terminal screw where power supply lines are connected on the terminal plate. (fig.2)

6-1-3. Outdoor Unit

Clamp an aluminium plate fin or copper tube with the lead clip of the insulation resistance tester and measure the resistance by placing a probe on each terminal screw on the terminal plate. (fig.2) Note that the ground line terminal should be skipped for the check.

6-1-4. Measurement of Insulation Resistance for Electrical Parts

Disconnect the lead wires of the desired electric part from terminal plate, capacitor, etc. Similary disconnect the connector. Then measure the insulation resistance. (fig.3 and 4)

NOTE: Refer to electric wiring diagram

If the probe cannot enter the poles because the hole is too narrow then use a probe with a thinner pin.



6-2 Checking Continuity of Fuse on PCB Ass'y

Remove the PCB Ass'y from the electrical component box. Then pull out the fuse from the PCB Ass'y. (fig.5)

Check for continuity using a multimeter as shown in fig.6





Fig. 6

6-3 Checking Motor Capacitor

Remove the lead wires from the capacitor terminals, and then place a probe on the capacitor terminals as shown in fig.7. Observe the deflection of the pointer, setting the resistance measuring range of the multimeter to the maximum value.

The capacitor is "good" if the pointer bounces to a great extent and then gradually returns to its original position.

The range of deflection and deflection time differ according to the capacity of the capacitor.



Fan motor capacitor

Fig. 7

argo*clima* s.p.A.

Via Varese, 90 - 21013 Gallarate - Va - Italy Tel. +39 0331 755111 - Fax +39 0331 776240 www.argoclima.it