



TECHNICAL DATA & SERVICE MANUAL

Euro-Line®

INDOOR UNIT: AWR608CL
AWR609CL
AWR612CL

SPLIT SYSTEM AIR CONDITIONER

Model No.	Product Code No.
AWR608CL	387004015
AWR609CL	387004016
AWR612CL	387004017



IMPORTANT! Please read before installation

This air conditioning system meets strict safety and operating standards.

For the installer or service person, it is important to install or service the system so that it operates safely and efficiently.

For safe installation and trouble-free operation, you must:

- Carefully read this instruction booklet before beginning.
- Follow each installation or repair step exactly as shown.
- Observe all local, state and national electrical codes.
- Pay close attention to all warning and caution notices given in this manual.
- The unit must be supplied with a dedicated electrical line.



WARNING

This symbol refers to a hazard or unsafe practice which can result in severe personal injury or death.



CAUTION

This symbol refers to a hazard or unsafe practice which can result in personal injury or product or property damage.

If necessary, get help

These instructions are all you need for most installation sites and maintenance conditions.

If you require help for a special problem, contact our sale/service outlet or your certified dealer for additional instructions.

In case of improper installation

The manufacturer shall in no way be responsible for improper installation or maintenance service, including failure to follow the instructions in this document.

SPECIAL PRECAUTIONS

- During installation, connect before the refrigerant system and then the wiring one; proceed in the reverse order when removing the units.

WARNING

When wiring



ELECTRICAL SHOCK CAN CAUSE SEVERE PERSONAL INJURY OR DEATH. ONLY A QUALIFIED, EXPERIENCED ELECTRICIANS SHOULD ATTEMPT TO WIRE THIS SYSTEM.

- Do not supply power to the unit until all wiring and tubing are completed or reconnected and checked, to ensure the grounding.
- Highly dangerous electrical voltages are used in this system. Carefully refer to the wiring diagram and these instructions when wiring. Improper connections and inadequate grounding can cause **accidental injury and death.**

- **Ground the unit** following local electrical codes.
- The Yellow/Green wire cannot be used for any connection different from the ground connection.
- Connect all wiring tightly. Loose wiring may cause overheating at connection points and a possible fire hazard.
- Do not allow wiring to touch the refrigerant tubing, compressor, or any moving parts of the fan.
- Do not use multi-core cable when wiring the power supply and control lines. Use separate cables for each type of line.

When transporting

Be careful when picking up and moving the indoor and outdoor units. Get a partner to help, and bend your knees when lifting to reduce strain on your back. Sharp edges or thin aluminium fins on the air conditioner can cut your fingers.

When installing...

... In a ceiling or wall

Make sure the ceiling/wall is strong enough to hold the unit-weight. It may be necessary to build a strong wooden or metal frame to provide added support.

... In a room

Properly insulate any tubing run inside a room to prevent "sweating", which can cause dripping and water damage to walls and floors.

... In moist or uneven locations

Use a raised concrete base to provide a solid level foundation for the outdoor unit.

This prevents damage and abnormal vibrations.

... In area with strong winds

Securely anchor the outdoor unit down with bolts and a metal frame. Provide a suitable air baffle.

... In a snowy area (for heat pump-type systems)

Install the outdoor unit on a raised platform that is higher than drifting snow. Provide snow vents.

When connecting refrigerant tubing

- Keep all tubing runs as short as possible.
- Use the flare method for connecting tubing.
- Apply refrigerant lubricant to the matching surfaces of the flare and union tubes before connecting them; screw by hand and then tighten the nut with a torque wrench for a leak-free connection.
- Check carefully for leaks before starting the test run.

NOTE:

Depending on the system type, liquid and gas lines may be either narrow or wide. Therefore, to avoid confusion, the refrigerant tubing for your particular model is specified as narrow tube for liquid, wide tube for gas.

When servicing

- Turn the power OFF at the main power board before opening the unit to check or repair electrical parts and wiring.
- Keep your fingers and clothing away from any moving parts.
- Clean up the site after the work, remembering to check that no metal scraps or bits of wiring have been left inside the unit being serviced.
- Ventilate the room during the installation or testing the refrigeration system; make sure that, after the installation, no gas leaks are present, because this could produce toxic gas and dangerous if in contact with flames or heat-sources.

Table of Contents

	Page
1. SPECIFICATIONS	4
1-1 Unit specifications	4
1-2 Major Component specifications	7
1-3 Other Component specifications	10
2. DIMENSIONAL DATA	11
3. PERFORMANCE DATA	12
3-1 Air Throw Distance Chart	12
4. ELECTRICAL DATA	15
4-1 Electric Wiring Diagrams	15
5. FUNCTION	16
5-1 Room Temperature Control	16
5-2 Dry Operation (Dehumidification)	17
5-3 Freeze Prevention (Cooling and Dry)	18
6. TROUBLESHOOTING	19
6-1 Check before and after troubleshooting	19
6-2 Air conditioner does not operate	20
6-3 Some part of air conditioner does not operate	24
6-4 Air conditioner operates, but abnormalities are observed	26
6-5 If a sensor is defective	27
7. CHECKING ELECTRICAL COMPONENTS	28
7-1 Measurement of Insulation Resistance	28
7-2 Checking Continuity of Fuse on PCB Ass'y	29
7-3 Checking Motor Capacitor	29
8. MAINTENANCE	30
8-1 Changing Address of Remote Control Unit in Indoor Unit	30

1. SPECIFICATIONS

1-1 Unit Specifications

AWR608CL

Power source	220 - 240V ~ 50Hz
---------------------	-------------------

Voltage rating	230V
-----------------------	------

Performance	
Capacity	See catalogue with the requested matching
Air circulation (High)	m ³ /h 430

Features	
Controls/Temperature controls	Microprocessor/ I.C. thermostat
Control unit	Wireless remote control unit
Timer	ON/OFF 24 hours & Daily program, 1-hour OFF
Fan speed	3 and Auto /1(Hi)
Airflow direction	Horizontal Vertical
Air Filter	Manual Auto
Operation Sound	Hi dB-A 48
Refrigerant tubing connections	Washable, Anti-Mold Flare type
Refrigerant tube diameter	Narrow tube mm(in.) 6,35 (1/4) Wide tube mm(in.) 9,52 (3/8)
Refrigerant	R407C
Refrigerant tube kit / Air clean filter	Optional / Supplied

Dimensions & Weight			
Unit dimensions	Height	mm	270
	Width	mm	805
	Depth	mm	177
Package dimensions	Height	mm	243
	Width	mm	855
	Depth	mm	332
Weight	Net	kg	8.0
	Shipping	kg	10.0
Shipping volume		m ³	0.07

DATA SUBJECT TO CHANGE WITHOUT NOTICE

AWR609CL

Power source	220 - 240V ~ 50Hz
---------------------	-------------------

Voltage rating	230V
-----------------------	------

Performance	
Capacity	See catalogue with the requested matching
Air circulation (High)	m ³ /h 470

Features	
Controls/Temperature controls	Microprocessor/ I.C. thermostat
Control unit	Wireless remote control unit
Timer	ON/OFF 24 hours & Daily program, 1-hour OFF
Fan speed	3 and Auto /1(Hi)
Airflow direction	Horizontal Vertical
Air Filter	Washable, Anti-Mold
Operation Sound	Hi dB-A 51
Refrigerant tubing connections	Flare type
Refrigerant tube diameter	Narrow tube mm(in.) 6,35 (1/4) Wide tube mm(in.) 9,52 (3/8)
Refrigerant	R407C
Refrigerant tube kit / Air clean filter	Optional / Supplied

Dimensions & Weight			
Unit dimensions	Height	mm	270
	Width	mm	805
	Depth	mm	177
Package dimensions	Height	mm	243
	Width	mm	855
	Depth	mm	332
Weight	Net	kg	8.0
	Shipping	kg	10.0
Shipping volume		m ³	0.07

DATA SUBJECT TO CHANGE WITHOUT NOTICE

AWR612CL

Power source	220 - 240V ~ 50Hz
---------------------	-------------------

Voltage rating	230V
-----------------------	------

Performance	
Capacity	See catalogue with the requested matching
Air circulation (High)	m ³ /h 490

Features	
Controls/Temperature controls	Microprocessor/ I.C. thermostat
Control unit	Wireless remote control unit
Timer	ON/OFF 24 hours & Daily program, 1-hour OFF
Fan speed	3 and Auto /1(Hi)
Airflow direction	Horizontal Vertical
Air Filter	Washable, Anti-Mold
Operation Sound	Hi dB-A 51/55
Refrigerant tubing connections	Flare type
Refrigerant tube diameter	Narrow tube mm(in.) 6,35 (1/4) Wide tube mm(in.) 12,7 (1/2)
Refrigerant	R407C
Refrigerant tube kit / Air clean filter	Optional / Supplied

Dimensions & Weight			
Unit dimensions	Height	mm	270
	Width	mm	805
	Depth	mm	177
Package dimensions	Height	mm	243
	Width	mm	855
	Depth	mm	332
Weight	Net	kg	8.0
	Shipping	kg	10.0
Shipping volume		m ³	0.07

DATA SUBJECT TO CHANGE WITHOUT NOTICE

1-2 Major Component Specifications

AWR608CL

Controller PCB	
Part No.	POW-KR79E(A), POW-KR9E(B)
Controls	Microprocessor
Control circuit fuse	250 V - 3,15 A

Remote Control Unit	RCS-9PS4E-G
---------------------	-------------

Fan & Fan Motor	
Type	Coss - flow
Q'ty Dia. and lenght	mm 1.... Ø 95 / L 617
Fan motor model...Q'ty	KFV4-21G5P-S... 1
No. Of poles...rpm (230 V, Cool-Heat)	4...1. 120-1.150
Nominal output	W 20
Running Amps	A 0,11
Power input	W 25
Coil resistance (Ambient temp. 20 °C)	Ω BRN-WHT: 298.8 WHT-PNK: 281.3
Safety devices	Type Thermal fuse
Operating temp. Open	°C 145 ± 2
Close	-
Run capacitor	μF 1.5
	VAC 440

Flap Motor	
Type	Stepping motor
Model	MP24GA1
Rating	DC 12 V
Coil resistance (Ambient temp. 25 °C)	Ω WHT-BLU: (respectively 4 wires) : 380 ± 7%

Heat Exch. Coil	
Coil	Aluminium plate fin / Copper tube
Rows	2
Fin pitch	mm 1,4
face area	0,130

DATA SUBJECT TO CHANGE WITHOUT NOTICE

AWR609CL

Controller PCB	
Part No.	POW-KR99E(A), POW-KR9E(B)
Controls	Microprocessor
Control circuit fuse	250 V - 3,15 A

Remote Control Unit	RCS-9PS4E-G
---------------------	-------------

Fan & Fan Motor	
Type	Coss - flow
Q'ty Dia. and lenght	mm 1... Ø 95 / L 617
Fan motor model...Q'ty	KFV4-21G5P-S... 1
No. Of poles...rpm (230 V, Cool-Heat)	4...1. 200-1.240
Nominal output	W 20
Running Amps	A 0,12
Power input	W 27
Coil resistance (Ambient temp. 20 °C)	Ω BRN-WHT: 298.8 WHT-PNK: 281.3
Safety devices	Type Thermal fuse
	Operating temp. Open °C 145 ± 2
	Close -
Run capacitor	μF 1.5
	VAC 440

Flap Motor	
Type	Stepping motor
Model	MP24GA1
Rating	DC 12 V
Coil resistance (Ambient temp. 25 °C)	Ω WHT-BLU: (respectively 4 wires) : 380 ± 7%

Heat Exch. Coil	
Coil	Aluminium plate fin / Copper tube
Rows	2
Fin pitch	mm 1,4
face area	0,130

DATA SUBJECT TO CHANGE WITHOUT NOTICE

AWR612CL

Controller PCB	
Part No.	POW-KR129E(A), POW-KR9E(B)
Controls	Microprocessor
Control circuit fuse	250 V - 3,15 A

Remote Control Unit	RCS-9PS4E-G
---------------------	-------------

Fan & Fan Motor	
Type	Coss - flow
Q'ty Dia. and length	mm 1... Ø 95 / L 617
Fan motor model...Q'ty	KFV4-21G5P-S...1
No. Of poles...rpm (230 V, Cool-Heat)	4...1, 235-1.270
Nominal output	W 20
Running Amps	A 0,13
Power input	W 31
Coil resistance (Ambient temp. 20 °C)	Ω BRN-WHT: 298.8 WHT-PNK: 281.3
Safety devices	Type Thermal fuse
Operating temp. Open	°C 145 ± 2
Close	-
Run capacitor	μF 1.5
	VAC 440

Flap Motor	
Type	Stepping motor
Model	MP24GA1
Rating	DC 12 V
Coil resistance (Ambient temp. 25 °C)	Ω WHT-BLU: (respectively 4 wires) : 380 ± 7%

Heat Exch. Coil	
Coil	Aluminium plate fin / Copper tube
Rows	2
Fin pitch	mm 1,4
face area	0,130

DATA SUBJECT TO CHANGE WITHOUT NOTICE

1-3 Other Component Specifications





AWR608CL
AWR609CL
AWR612CL

Trasformer (TR)		ATR-I55
Rating	Primary Secondary Capacity	AC 230 V, 50/60 Hz 13.7 V - 0.4 A 5.48 VA
Coil resistance	Ω (at 25°C)	Primary (WHT-WHT): $307 \pm 10\%$ Secondary (BRN-BRN): $1.8 \pm 10\%$
Thermal cut-off temp.		150°C


Thermistor (Coil sensor TH1)		DTN-TKS131B
Resistance	K Ω	0 °C $15,0 \pm 2\%$

Thermistor (Room sensor TH2)		DTN-TKS134B
Resistance	K Ω	25 °C $5,0 \pm 3\%$

2. DIMENSIONAL DATA



Remote control unit



Unit : mm


3. PERFORMANCE DATA

3-1 Air Throw Distance Chart

AWR608CL

Room air temp. : 27°C


Fan speed : High



AWR609CL

Room air temp. : 27°C


Fan speed : High



AWR612CL


Room air temp. : 27°C

Fan speed : High



4. ELECTRICAL DATA

4-1 Electric Wiring Diagrams




5. FUNCTION

5-1. Room Temperature Control

■ Cooling


- Room temperature control is obtained by cycling the compressor ON and OFF under control of the room temperature sensor in the remote control unit.
- The room temperature (and other information) is transmitted every 5 minutes by the remote control unit to the controller in the indoor unit.



- The control circuit will not attempt to turn the compressor ON until the compressor has been OFF for at least 3 minutes. To protect the compressor from stalling out when trying to start against the high side refrigerant pressure, the control circuit has a built-in automatic time delay to allow the internal pressure to equalize.
- As a protective measure, the control circuit switches the compressor OFF after 5 minutes or more of compressor operation.
- Thermo. ON : When the room temperature is above $T + 1^{\circ}\text{C}$ ($T^{\circ}\text{C}$ is set temperature).
Compressor \rightarrow ON
- Thermo. OFF : When the room temperature is equal to or below set temperature $T^{\circ}\text{C}$.
Compressor \rightarrow OFF

5-2. Dry Operation (Dehumidification)

- Dry operation uses the ability of the cooling cycle to remove moisture from the air, but by running at low level to dehumidify without greatly reducing the room temperature. The air conditioner repeats the cycle of turning ON and OFF automatically as shown in the chart below according to the room temperature.




NOTE

- Intermittent ventilation occurs by switching the indoor fan speed between L ↔ LL.
- Dry operation does not occur when the room temperature is under 15°C, which is the monitor zone.
- When the compressor stops, the indoor fan stops as well.


5-3. Freeze Prevention (Cooling and Dry)

- This function prevents freezing of the indoor heat exchange coil.
- When the compressor has been running for 6 minutes or more and the temperature of the indoor heat exchange coil falls below 2.4°C, the control circuit stops the compressor for at least 6 minutes. The compressor does not start again until the temperature rises above 8°C or 6 minutes has elapsed.



6. TROUBLESHOOTING

6-1. Check before and after troubleshooting



WARNING

Hazardous voltage can cause **ELECTRIC SHOCK** or **DEATH**. Disconnect power or turn off circuit breaker before you start checking or servicing.

6-1-1. Check power supply wiring.

- Check that power supply wires are correctly connected to terminals **L** and **N** on the terminal plate in the indoor unit.

6-1-2. Check inter-unit wiring.

- Check that inter-unit wiring is correctly connected to the outdoor unit from the indoor unit.

6-1-3. Check power supply.

- Check that voltage is in specified range ($\pm 10\%$ of the rating).
- Check that power is being supplied.

6-1-4. Check lead wires and connectors in indoor and outdoor units.

- Check that coating of lead wires is not damaged.
- Check that lead wires and connectors are firmly connected.
- Check that wiring is correct.

6-2. Air conditioner does not operate.

6-2-1. Circuit breaker trips (or fuse blows).

A. When the circuit breaker is set to ON, it is tripped soon. (Resetting is not possible.)


- There is a possibility of ground fault.
- Check insulation resistance.

If resistance value is $2M\Omega$ or less, insulation is defective ("NO").




WARNING

*Set circuit breaker to OFF.




B. Circuit breaker trips in several minutes after turning the air conditioner on.

- There is a possibility of short circuit.




6-2-2. Neither indoor nor outdoor unit runs.


A. Power is not supplied.




B. Check "OPERATION selector" switch in the indoor unit.



C. Check remote control unit.



D. Check fuse on the indoor PCB Ass'y.




E. Check TIMER on the remote control unit.



6-2-3. Only outdoor unit does not run.

A. Check setting temperature.

COOL




6-2-4. Only Indoor unit does not run.


• Indoor PCB Ass'y is defective.

6-3. Some part of air conditioner does not operate.


6-3-1. Only indoor fan does not run.




6-3-2. Only flap motor does not run.



6-3-3. Only outdoor fan does not run.




6-3-4. Only compressor does not run.




6-4. Air conditioner operates, but abnormalities are observed.

6-4-1. Poor cooling.




6-4-2. Excessive cooling.



6-5. If a sensor is defective.

6-5-1. Thermistor (TH1 or TH2) is defective.



NOTE Alarm Signal (*)

Operation lamp on the front side of the indoor unit will flash on and off when either indoor coil thermistor or room air thermistor is defective. At the same time the outdoor unit will stop. Indoor unit will operate only for ventilation.

7. CHECKING ELECTRICAL COMPONENTS

7-1. Measurement of Insulation Resistance

- The insulation is in good condition if the resistance exceeds $2M\Omega$.

7-1-1. Power Supply Wires

Clamp the grounding terminal of the power plug with a lead clip of the insulation resistance tester and measure the resistance by placing a probe on either of the two power terminals. (Fig. 1)

Then, also measure the resistance between the grounding and other power terminals. (Fig. 1)

7-1-2. Indoor Unit

Clamp a metallic part of the unit with the lead clip of the insulation resistance tester and measure the resistance by placing a probe on each terminal screw where power supply lines are connected on the terminal plate. (Fig. 2)

7-1-3. Outdoor Unit

Clamp an aluminum plate fin or copper tube with the lead clip of the insulation resistance tester and measure the resistance by placing a probe on each terminal screw on the terminal plate. (Fig. 2)
Note that the ground line terminal should be skipped for the check.


7-1-4. Measurement of Insulation Resistance for Electrical Parts

Disconnect the lead wires of the desired electric part from terminal plate, capacitor, etc. Similarly disconnect the connector. Then measure the insulation resistance. (Figs. 3 and 4)

NOTE

Refer to Electric Wiring Diagram.

If the probe cannot enter the poles because the hole is too narrow then use a probe with a thinner pin.



NOTE

The shape of the power plug may differ from that of the air conditioner which you are servicing.

Fig. 1




Fig. 2




Fig. 3




Fig. 4

7-2. Checking Continuity of Fuse on PCB Ass'y

- Remove the PCB Ass'y from the electrical component box. Then pull out the fuse from the PCB Ass'y. (Fig. 5)
- Check for continuity using a multimeter as shown in Fig. 6.




Fig. 5

7-3. Checking Motor Capacitor

Remove the lead wires from the capacitor terminals, and then place a probe on the capacitor terminals as shown in Fig. 7. Observe the deflection of the pointer, setting the resistance measuring range of the multimeter to the maximum value.

The capacitor is “good” if the pointer bounces to a great extent and then gradually returns to its original position.

The range of deflection and deflection time differ according to the capacity of the capacitor.




Fig. 6




Fig. 7

8. MAINTENANCE

8-1. Changing Address of Remote Control Unit in Indoor Unit


If you are installing more than 1 indoor unit (up to 2) in the same room, it is necessary for you to assign each unit its own address, so each can be operated by its own separate remote control unit. You assign the addresses by matching the remococon address on the PCB of each indoor unit with the switch positions of its remote control unit.

NOTE Once changed, you cannot restore the original address setting of the remote control unit.

To Change Address on PCB

- (1) Cut jumper wire (JP03) on the indoor unit PCB (Controller A).
Use cutting pliers to cut and disconnect the Jumper wire.
- (2) Switch the address switch on the remote control unit to "B" position.
- (3) After inserting the batteries, press ACL button.


Control PCB on Indoor Unit (Controller A)




To Change Address on Remote Control Unit

NOTE Remove the batteries before changing the address.

- (1) Remove tab marked A to change the address of the remote control unit.



- (2) When it is removed, the address is automatically set to B.



argoclima s.p.a.

Via Varese, 90 - 21013 Gallarate - Va - Italy
Tel. +39 0331 755111 - Fax +39 0331 776240
www.argoclima.it