


## SERVICE MANUAL

### TECHNICAL INFORMATION

FOR SERVICE PERSONNEL ONLY



RAK-18NH6AS  
RAK-18NH6A  
RAK-25NH6A  
RAK-35NH6A  
RAK-50NH6A



#### NOTE:

This manual describes only points that differ from RAF-25, 35NH5, RAD-25, 35NH5, RAI-25, 35NH5 and RAM-55QH5 (PM No. 0312E) for items not described in this manual.

RAK-18NH6AS  
RAK-18NH6A  
RAK-25NH6A  
RAK-35NH6A  
RAK-50NH6A

REFER TO THE FOUNDATION MANUAL

#### CONTENTS

SPECIFICATIONS-----	5
HOW TO USE -----	11
CONSTRUCTION AND DIMENSIONAL DIAGRAM-----	33
MAIN PARTS COMPONENT -----	34
WIRING DIAGRAM -----	35
CIRCUIT DIAGRAM -----	37
PRINTED WIRING BOARD LOCATION DIAGRAM -----	39
BLOCK DIAGRAM -----	43
BASIC MODE -----	45
REFRIGERATING CYCLE DIAGRAM-----	59
AUTO SWING FUNCTION -----	61
DESCRIPTION OF MAIN CIRCUIT OPERATION-----	62
SERVICE CALL Q & A-----	67
PARTS LIST AND DIAGRAM-----	77

#### SPECIFICATIONS

TYPE			DC INVERTER (WALL TYPE)				
			INDOOR UNIT				
MODEL			RAK-18NH6AS	RAK-18NH6A	RAK-25NH6A	RAK-35NH6A	RAK-50NH6A
POWER SOURCE			1ø 50/60Hz, 220-240V				
COOLING	TOTAL INPUT (W)		REFER TO THE SPECIFICATION (OUTDOOR)				
	TOTAL AMPERES (A)						
	CAPACITY	(kW)					
		(B.T.U./h)					
HEATING	TOTAL INPUT (W)						
	TOTAL AMPERES (A)						
	CAPACITY	(kW)					
		(B.T.U./h)					
DIMENSIONS (mm)		W	780				
		H	280				
		D	220				
NET WEIGHT (kg)		9.0	9.0	9.5	9.5	9.5	


SPECIFICATIONS AND PARTS ARE SUBJECT TO CHANGE FOR IMPROVEMENT

## ROOM AIR CONDITIONER

### INDOOR UNIT


## SAFETY DURING REPAIR WORK

1. In order to disassemble and repair the unit in question, be sure to disconnect the power cord plug from the power outlet before starting the work.



2. If it is necessary to replace any parts, they should be replaced with respective genuine parts for the unit, and the replacement must be effected in correct manner according to the instructions in the Service Manual of the unit.

If the contacts of electrical parts are defective, replace the electrical parts without trying to repair them.



3. After completion of repairs, the initial state should be restored.
4. Lead wires should be connected and laid as in the initial state.
5. Modification of the unit by user himself should absolutely be prohibited.
6. Tools and measuring instruments for use in repairs or inspection should be accurately calibrated in advance.
7. In installing the unit having been repaired, be careful to prevent the occurrence of any accident such as electrical shock, leak of current, or bodily injury due to the drop of any part.
8. To check the insulation of the unit, measure the insulation resistance between the power cord plug and grounding terminal of the unit. The insulation resistance should be  $1\text{M}\Omega$  or more as measured by a 500V DC megger.
9. The initial location of installation such as window, floor or the other should be checked for being and safe enough to support the repaired unit again. If it is found not so strong and safe, the unit should be installed at the initial location reinforced or at a new location.
10. Any inflammable thing should never be placed about the location of installation.
11. Check the grounding to see whether it is proper or not, and if it is found improper, connect the grounding terminal to the earth.



## WORKING STANDARDS FOR PREVENTING BREAKAGE OF SEMICONDUCTORS

### 1. Scope

The standards provide for items to be generally observed in carrying and handling semiconductors in relative manufacturers during maintenance and handling thereof. (They apply the same to handling of abnormal goods such as rejected goods being returned).

### 2. Object parts

- (1) Micro computer
- (2) Integrated circuits (IC)
- (3) Field-effect transistors (FET)
- (4) P.C. boards or the like on which the parts mentioned in (1) and (2) of this paragraph are equipped.

### 3. Items to be observed in handling

- (1) Use a conductive container for carrying and storing of parts. (Even rejected goods should be handled in the same way).




Fig. 1. Conductive Container

- (2) When any part is handled uncovered (in counting, packing and the like), the handling person must always use himself as a body earth. (Make yourself a body earth by passing  $1M\Omega$  earth resistance through a ring or bracelet).
- (3) Be careful not to touch the parts with your clothing when you hold a part even if a body earth is being taken.
- (4) Be sure to place a part on a metal plate with grounding.
- (5) Be careful not to fail to turn off power when you repair the printed circuit board. At the same time, try to repair the printed circuit board on a grounded metal plate.




Fig. 2. Body Earth

(6) Use a three wire type soldering iron including a grounding wire.




Fig. 3. Grounding of the working table




Fig. 4. Grounding a soldering iron

Use a high insulation mode (100V, 10MΩ or higher) when ordinary iron is to be used.

(7) In checking circuits for maintenance, inspection or some others, be careful not to have the test probes of the measuring instrument shortcircuit a load circuit or the like.

## CAUTION

1. In quiet operation or stopping the running, slight flowing noise of refrigerant in the refrigerating cycle is heard occasionally, but this noise is not abnormal for the operation.
2. When it thunders near by, it is recommend to stop the operation and to disconnect the power cord plug from the power outlet for safety.
3. The room air conditioner does not start automatically after recovery of the electric power failure for preventing fuse blowing. Re-press START/STOP button after 3 minutes from when unit stopped.
4. If the room air conditioner is stopped by adjusting thermostat, or missoperation, and re-start in a moment, there is occasion that the cooling and heating operation does not start for 3 minutes, it is not abnormal and this is the result of the operation of IC delay circuit. This IC delay circuit ensures that there is no danger of blowing fuse or damaging parts even if operation is restarted accidentally.
5. This room air conditioner should not be used at the cooling operation when the outside temperature is below  $-10^{\circ}\text{C}$  ( $14^{\circ}\text{F}$ ).
6. This room air conditioner (the reverse cycle) should not be used when the outside temperature is below  $-15^{\circ}\text{C}$  ( $5^{\circ}\text{F}$ ).  
If the reverse cycle is used under this condition, the outside heat exchanger is frosted and efficiency falls.
7. When the outside heat exchanger is frosted, the frost is melted by operating the hot gas system, it is not trouble that at this time fan stops and the vapour may rise from the outside heat exchanger.

## SPECIFICATIONS

MODEL	RAK-18NH6AS, RAK-18NH6A, RAK-25NH6A, RAK-35NH6A, RAK-50NH6A	
FAN MOTOR	35W	
FAN MOTOR CAPACITOR	NO	
FAN MOTOR PROTECTOR	NO	
COMPRESSOR	–	
COMPRESSOR MOTOR CAPACITOR	NO	
OVERLOAD PROTECTOR	NO	
OVERHEAT PROTECTOR	NO	
FUSE (for MICROPROCESSOR)	NO	
POWER RELAY	NO	
POWER SWITCH	NO	
TEMPORARY SWITCH	YES	
SERVICE SWITCH	NO	
TRANSFORMER	NO	
VARISTOR	NO	
NOISE SUPPRESSOR	NO	
THERMOSTAT	YES(IC)	
REMOTE CONTROL SWITCH (LIQUID CRYSTAL)	YES	
REFRIGERANT CHARGING VOLUME (Refrigerant 410A)	UNIT	-----
	PIPES	WITHOUT REFRIGERANT BECAUSE COUPLING IS FLARE TYPE.

## FEATURES

### 1. NEW REFRIGERANT

#### (1) New refrigerant R410A with no harmful effect on the ozone layer

Refrigerant R410A, which does not damage the ozone layer, was adopted instead of HCFC-22 which is planned to be phased out globally by 2020.

#### (2) New refrigerating oil

The new refrigerant HFC-R410A is not compatible with conventional mineral oils and no lubrication can be expected with those oils. To solve this, the artificial synthetic ester oil is newly adopted.

## NEW TECHNOLOGY

Cautions in relation to HFC (R410A)

### 1. Safety during Servicing

This air conditioner uses the new refrigerant HFC (R410A) for protecting the ozone layer. R410A has several different characteristic features from HCFC-22. Therefore keep the following care items during servicing for safety.

- (1) Since the working pressure of R410A model is about 1.6 times higher than that of HCFC-22 models, it becomes necessary to use part of piping materials and servicing tools exclusive for R410A model.
- (2) It is necessary to exercise more care to prevent the foreign matters (oil, moisture, etc.) from mixing into the piping than in the case of HCFC-22 model. Also, when storing the piping, securely seal its openings with pinching and taping, etc..
- (3) Be sure to charge the refrigerant from the liquid-phase side, as the liquid-phase/gas-phase-composition changes a little in the case of R410A model.
- (4) Never use refrigerant other than R410A in an air conditioner which is designed to operate with R410A.
- (5) If a refrigeration gas leakage occurs during servicing, be sure to ventilate fully.  
If the refrigerant gas comes into contact with fire, a poisonous gas may occur.
- (6) When installing or removing an air conditioner, do not allow air or moisture to remain in the refrigeration cycle. Otherwise, pressure in the refrigeration cycle may become abnormally high so that a rupture or personal injury may be caused.
- (7) After completion of service work, check to make sure that there is no refrigeration gas leakage.  
If the refrigerant gas leaks into the room, coming into contact with fire in the fan-driven heater, space heater, etc., a poisonous gas may occur.

## 2. Refrigerant Piping Materials

### (1) Thickness of Refrigerant Piping

Although the thickness is same as that for HCFC-22 model, as R410A model features higher pressure, be sure to confirm the thickness prior to use.

※Do not use thin pipes (thinner than 0.7 mm).


Nominal diameter	Outside diameter (mm)	Thickness (mm)
1/4	6.35	0.8
1/2	12.70	0.8

### (2) Flare's Expansion Pipe

The projection when the new flare tool is used, is as follows. When using the conventional flare tool, be sure to secure the following projection by using a gauge for projection adjustment.

※When using the conventional flare tool, use a gauge for projection adjustment.

Projection "A"(mm) for Flare Tool for R410A (Clutch Type)



### (3) Flare Nut Dimensions

Along with changes in the expansion pipe dimensions, the opposite side dimensions of flare nuts whose nominal diameter is 1/2 change so that different torque wrenches must be used.

※Figures in ( ) denote those for HCFC-22.

Nominal diameter	Opposite Side Dimensions (mm) of Flare Nuts for R410A
1/4	17 (17)
3/8	22 (22)
1/2	26 (24)



### 3. Servicing Tools

#### (Changes in the Product and Components)


- In order to prevent any other refrigerant from being charged, R410A model is provided with the outdoor unit whose control valve has a different service port diameter (port size: 7/16 UNF 20 threads per inch → 1/2 UNF 20 threads per inch).
- In order to secure larger pressure resisting strength, flare expansion pipe dimensions and flare nut dimensions have been changed.

#### (New Tools for R410A)

New tools for R410A	Applicable to HCFC-22 Model	Changes
Gauge manifold	×	As pressure is high, it is impossible to measure by means of conventional gauge. In order to prevent any other refrigerant from being charged, each port diameter has been changed.
Charge hose	×	In order to increase pressure resistance, hose materials and port size have been changed (to 1/2 UNF 20 threads per inch). When purchasing a charge hose, be sure to confirm the port size.
Electronic balance for refrigerant charging	○	As pressure is high and gasification speed is fast, it is difficult to read the indicated value by means of charging cylinder, as air bubbles occur.
Torque wrench	×	The opposite side dimensions of flare nuts increase. Incidentally, a common wrench is used for nominal diameters 1/2, 5/8.
Flare tool (clutch type)	○	By increasing the clamp bar's receiving hole, strength of spring in the tool has been improved.
Gauge for projection adjustment	—	Used when performing flare processing by means of conventional flare tool.
Vacuum pump adapter	○	Connected to conventional vacuum pump.
Gas leakage detector	×	Exclusive for HFC refrigerant.

- Incidentally, the "refrigerant cylinder" comes with the refrigerant designation (R410A) and protector coating in the U.S.'s ARI specified rose color (ARI color code: PMS 507).
- Also, the "charge port and packing for refrigerant cylinder" require 1/2 UNF 20 threads per inch corresponding to the charge hose's port size.

#### 4. Servicing work (Refrigerant recharging)



#### CAUTION

1. Be sure to use the vacuum pump, vacuum pump adapter and gauge manifold to refer to their instruction manuals beforehand.
2. Ascertain that the vacuum pump is filled with oil to the level designated on the oil gauge.
3. After closed the ball valve of charge hose, it should be disconnected at service port side and refrigerant cylinder side at first.  
Next, after discharging the remained gas in the charge hose by opening the ball valve a little, disconnect it at gauge manifold side. You can prevent from being released the refrigerant suddenly by connecting the ball valve to service port. And you can work with more safety.


#### Working steps



1. Connect the charge hose **A** to outdoor unit.
2. Connect the vacuum pump adapter to the vacuum pump. Connect the 1/2" conversion adapter to the vacuum pump adapter. Connect the charge hose **1** to the conversion adapter.  
Then, service valve **C** & **D** is closed.
3. Connect the charge hose **B** to the refrigerant cylinder.
4. Open the handle Lo **E**.  
Turn ON the power switch of the vacuum pump & adapter.  
Run the vacuum pump in specified time.  
When the compound pressure gauge's pointer has indicated -0.1MPa, place the handle Lo **E** in the fully closed position.  
Turn OFF the power switch of the vacuum pump & adapter.
6. Remove the charge hose **1** of vacuum pump at portion **a**.
7. Air purge of gauge manifold.  
• Open the refrigerant cylinder's valve and push the valve core at portion **a** of gauge manifold. Then the refrigerant is discharge in a moment.
8. Calculation of charged refrigerant amount.
9. Charging of refrigeration.  
• Open the handle Lo **E** in a turn and charge the designated amount.
10. Completion of charging.
11. Be closed the valve of charge hose **A**.
12. Run the compressor at cooling operation.
13. Remove the charge hose **A** & **B**.  
• Remove the charge hose **A** rom portion **G**.  
• Remove the charge hose **B** from portion **e**.
14. Attach the caps.
15. Gas leakage check.

## SWITCH SETTING TO SELECT 1.8 kW OR 1.2 kW CAPACITY

### CAUTION

Before setting the switch, make sure to turn OFF power supply and then set the position of the switch otherwise will cause damage to the Main PCB.




SWITCH POSITION	CAPACITY SELECTION
1. 2kW  1. 8kW	1.2kW
1. 2kW  1. 8kW	1.8kW

NOTE:  
FACTORY default setting is at 1.8kW capacity.

# NAMES AND FUNCTIONS OF EACH PART

## INDOOR UNIT




### NOTE

- Air cleansing filters are washable and can be use in 1 year time. Type number for this air cleansing filter is <SPX-CFH20>. Please use this number for ordering when you want to renew it.
- Air cleansing filter should be cleaned every month or sooner if noticeable loading occurs. When used overtime, it may loose its deodorizing function. For maximum performance, it is recommended to replace it every 1 year depending on application requirements.

## MODEL NAME AND DIMENSIONS

MODEL	WIDTH (mm)	HEIGHT (mm)	DEPTH (mm)
RAK-18NH6AS/RAK-18NH6A/RAK-25NH6A/ RAK-35NH6A/RAK-50NH6A	780	280	220

## INDOOR UNIT INDICATORS



### **FILTER LAMP**

When the device is operated for a total of about 200 hours, the FILTER lamp lights to indicate that it is time to clean the filter.

### **OPERATION LAMP**

This lamp lights during operation.

The OPERATION LAMP flashes in the following cases during heating.

#### **(1) During preheating**

For about 2–3 minutes after starting up.


#### **(2) During defrosting**

Defrosting will be performed about once every one hour when frost forms on the heat exchanger of the outdoor unit, for 5–10 minutes each time.

### **TIMER LAMP**

This lamp lights when the timer is working.

## OPERATION INDICATOR



### **TEMPORARY SWITCH**

Use this switch to start and stop when the remote controller does not work. [Use non-conductor stick (example: toothpick)]

- By pressing the temporary switch, the operation is done in previously set operation mode.
- When the operation is done using the temporary switch after the power source is turned off and turn on again, the operation is done in automatic mode.

### Note

- Avoid to use the room air conditioner for cooling operation when the outside temperature is below 21°C (70°F).

The recommended maximum and minimum operating temperatures of the hot and cold sides should be as below:

		Cooling		Heating	
		Minimum	Maximum	Minimum	Maximum
Indoor	Dry bulb °C	21	32	20	27
	Wet bulb °C	15	23	12	19
Outdoor	Dry bulb °C	21	43	2	21
	Wet bulb °C	15	26	1	15




# MEMO

[illegible]






# SAFETY PRECAUTION

- Please read the “Safety Precaution” carefully before operating the unit to ensure correct usage of the unit.
- Pay special attention to signs of “**▲ Warning**” and “**▲ Caution**”. The “Warning” section contains matters which, if not observed strictly, may cause death or serious injury. The “Caution” section contains matters which may result in serious consequences if not observed properly. Please observe all instructions strictly to ensure safety.
- The sign indicate the following meanings.



 Make sure to connect earth line.	 The sign in the figure indicates prohibition.
 Indicates the instructions that must be followed.	

- Please keep this manual after reading.





## PRECAUTIONS DURING INSTALLATION

<b>WARNING</b>	<ul style="list-style-type: none"> <li>● Do not reconstruct the unit. Water leakage, fault, short circuit or fire may occur if you reconstruct the unit by yourself.</li> </ul>	
	<ul style="list-style-type: none"> <li>● Please ask your sales agent or qualified technician for the installation of your unit. Water leakage, short circuit or fire may occur if you install the unit by yourself.</li> </ul>	
	<ul style="list-style-type: none"> <li>● Please use earth line. Do not place the earth line near water or gas pipes, lightning-conductor, or the earth line of telephone. Improper installation of earth line may cause electric shock.</li> </ul>	
	<ul style="list-style-type: none"> <li>● Be sure to use the specified piping set for R410A. Otherwise, this may result in broken copper pipes or faults.</li> </ul>	
<b>CAUTION</b>	<ul style="list-style-type: none"> <li>● A circuit breaker should be installed depending on the mounting site of the unit. Without a circuit breaker, the danger of electric shock exists.</li> </ul>	
	<ul style="list-style-type: none"> <li>● Do not install near location where there is flammable gas. The outdoor unit may catch fire if flammable gas leaks around it.</li> </ul>	
	<ul style="list-style-type: none"> <li>● Please ensure smooth flow of water when installing the drain hose.</li> </ul>	

## PRECAUTIONS DURING SHIFTING OR MAINTENANCE


<b>WARNING</b>	<ul style="list-style-type: none"> <li>● Should abnormal situation arises (like burning smell), please stop operating the unit and turn off the circuit breaker. Contact your agent. Fault, short circuit or fire may occur if you continue to operate the unit under abnormal situation.</li> </ul>	
	<ul style="list-style-type: none"> <li>● Please contact your agent for maintenance. Improper self maintenance may cause electric shock and fire.</li> </ul>	
	<ul style="list-style-type: none"> <li>● Please contact your agent if you need to remove and reinstall the unit. Electric shock or fire may occur if you remove and reinstall the unit yourself improperly.</li> </ul>	
	<ul style="list-style-type: none"> <li>● If the supply cord is damaged, it must be replaced by the special cord obtainable at authorized service/parts centers.</li> </ul>	

## PRECAUTIONS DURING OPERATION

<b>WARNING</b>	<ul style="list-style-type: none"> <li>● Avoid an extended period of direct air flow for your health.</li> </ul>	
	<ul style="list-style-type: none"> <li>● Do not insert a finger, a rod or other objects into the air outlet or inlet. As the fan is rotating at a high speed, it will cause injury. Before cleaning, be sure to stop the operation and turn the breaker OFF.</li> </ul>	
	<ul style="list-style-type: none"> <li>● Do not use any conductor as fuse wire, this could cause fatal accident.</li> </ul>	
	<ul style="list-style-type: none"> <li>● During thunder storm, disconnect and turn off the circuit breaker.</li> </ul>	


## PRECAUTIONS DURING OPERATION

- The product shall be operated under the manufacturer specification and not for any other intended use.



- Do not attempt to operate the unit with wet hands, this could cause fatal accident.

- When operating the unit with burning equipments, regularly ventilate the room to avoid oxygen insufficiency.



- Do not direct the cool air coming out from the air-conditioner panel to face household heating apparatus as this may affect the working of apparatus such as the electric kettle, oven etc.

- Please ensure that outdoor mounting frame is always stable, firm and without defect. If not, the outdoor unit may collapse and cause danger.




- Do not splash or direct water to the body of the unit when cleaning it as this may cause short circuit.

- Do not use any aerosol or hair sprays near the indoor unit. This chemical can adhere on heat exchanger fin and blocked the evaporation water flow to drain pan. The water will drop on tangential fan and cause water splashing out from indoor unit.




**CAUTION**





- Please switch off the unit and turn off the circuit breaker during cleaning, the high-speed fan inside the unit may cause danger.

- Turn off the circuit breaker if the unit is not to be operated for a long period.



- Do not climb on the outdoor unit or put objects on it.

- Do not put water container (like vase) on the indoor unit to avoid water dripping into the unit. Dripping water will damage the insulator inside the unit and causes short-circuit.



- Do not place plants directly under the air flow as it is bad for the plants.

- When operating the unit with the door and windows opened, (the room humidity is always above 80%) and with the air deflector facing down or moving automatically for a long period of time, water will condense on the air deflector and drips down occasionally. This will wet your furniture. Therefore, do not operate under such condition for a long time.

- If the amount of heat in the room is above the cooling or heating capability of the unit (for example: more people entering the room, using heating equipments and etc.), the preset room temperature cannot be achieved.


- This appliance is not intended for use by young children or infirm persons unless they have been adequately supervised by a responsible person to ensure that they can use the appliance safely.
- Young children should be supervised to ensure that they do not play with the appliance.




# NAMES AND FUNCTIONS OF REMOTE CONTROL UNIT

## REMOTE CONTROLLER

- This controls the operation of the indoor unit. The range of control is about 7 meters. If indoor lighting is controlled electronically, the range of control may be shorter.  
This unit can be fixed on a wall using the fixture provided. Before fixing it, make sure the indoor unit can be controlled from the remote controller.
- Handle the remote controller with care. Dropping it or getting it wet may compromise its signal transmission capability.
- After new batteries are inserted into the remote controller, the unit will initially require approximately 10 seconds to respond to commands and operate.



- **Signal emitting window/transmission sign**  
Point this window toward the indoor unit when controlling it. The transmission sign blinks when a signal is sent.
- **Display**  
This indicates the room temperature selected, current time, timer status, function and intensity of circulation selected.
- **START/STOP button**  
Press this button to start operation. Press it again to stop operation.
- **SLEEP button**  
Use this button to set the sleep timer.
- **TEMPERATURE buttons**  
Use these buttons to raise or lower the temperature setting. (Keep pressed, and the value will change more quickly.)



- **TIME button**  
Use this button to set and check the time and date.
- **RESET buttons**
- **FUNCTION selector**  
Use this button to select the operating mode. Every time you press it, the mode will change from (A) (AUTO) to (HEAT) to (DEHUMIDIFY) to (COOL) and to (FAN) cyclically.
- **FAN SPEED selector**  
This determines the fan speed. Every time you press this button, the intensity of circulation will change from (A) (AUTO) to (HI) to (MED) to (LOW) to (SILENT) (This button allows selecting the optimal or preferred fan speed for each operation mode).
- **AUTO SWING button**  
Controls the angle of the horizontal air deflector.
- **TIMER control**  
Use this button to set the timer.
- **OFF-TIMER button** Select the turn OFF time.
- **ON-TIMER button** Select the turn ON time.
- **RESERVE button** Time setting reservation.
- **CANCEL button** Cancel time reservation.

(A)	AUTO
(HEAT)	HEAT
(DEHUMIDIFY)	DEHUMIDIFY
(COOL)	COOL
(FAN)	FAN
(FAN SPEED)	FAN SPEED
(SILENT)	SILENT
(LOW)	LOW
(MED)	MED
(HI)	HI
(SLEEPING)	SLEEPING
(STOP)	STOP (CANCEL)
(RESERVE)	START (RESERVE)
(START/STOP)	START/STOP
(TIME)	TIME
(TIMER SET)	TIMER SET
(TIMER SELECTOR)	TIMER SELECTOR
(ON TIMER)	ON TIMER
(OFF TIMER)	OFF TIMER
(AUTO SWING)	AUTO SWING

## Precautions for Use

- Do not put the remote controller in the following places.
  - Under direct sunlight.
  - In the vicinity of a heater.
- Handle the remote controller carefully. Do not drop it on the floor, and protect it from water.
- Once the outdoor unit stops, it will not restart for about 3 minutes (unless you turn the power switch off and on or unplug the power cord and plug it in again).  
This is to protect the device and does not indicate a failure.
- If you press the FUNCTION selector button during operation, the device may stop for about 3 minutes for protection.

# VARIOUS FUNCTIONS


## ■ Auto Restart Control

- If there is a power failure, operation will be automatically restarted when the power is resumed with previous operation mode and airflow direction.  
(As the operation is not stopped by remote controller.)
- If you intend not to continue the operation when the power is resumed, switch off the power supply.  
When you switch on the circuit breaker, the operation will be automatically restarted with previous operation mode and airflow direction.

Note: 1. If you do not require Auto Restart Control, please consult your sales agent or OFF by remote control.  
2. Auto Restart Control is not available when Timer or Sleep Timer mode is set.

## AUTOMATIC OPERATION

The device will automatically determine the mode of operation, HEAT, COOL or DEHUMIDIFY depending on the current room temperature. The selected mode of operation will change when the room temperature varies. However the mode of operation will not change when indoor unit connected to multi type outdoor unit.



Press the FUNCTION selector so that the display indicates the **(A)** (AUTO) mode of operation.


- When AUTO has been selected, the device will automatically determine the mode of operation, HEAT, COOL or DEHUMIDIFY depending on the current room temperature. However the mode of operation will not change when indoor unit connected to multi type outdoor unit.
- If the mode automatically selected by the unit is not satisfactory, manually change the mode setting (heat, dehumidify, cool or fan).

**START  
STOP**

Press the **(1)** (START/STOP) button.  
Operation starts with a beep.  
Press the button again to stop operation.

- As the settings are stored in memory in the remote controller, you only have to press the **(1)** (START/STOP) button next time.


You can raise or lower the temperature setting as necessary by maximum of 3°C.



Press the temperature button and the temperature setting will change by 1°C each time.


- The preset temperature and the actual room temperature may vary somewhat depending on conditions.
- The display does not indicate the preset temperature in the AUTO mode. If you change the setting, the indoor unit will produce a beep.

Press the **(FAN SPEED)** button, AUTO, LOW and SILENT is available.



# HEATING OPERATION

- Use the device for heating when the outdoor temperature is under 21°C.  
When it is too warm (over 21°C), the heating function may not work in order to protect the device.
- In order to keep reliability of the device, please use this device above -15°C of the outdoor temperature.



**1**

Press the FUNCTION selector so that the display indicates ☀ (HEAT).

**2**

Set the desired FAN SPEED with the 🌀 (FAN SPEED) button (the display indicates the setting).


Ⓐ (AUTO) : The fan speed changes automatically according to the temperature of the air which blows out.

🌀 (HI) : Economical as the room will become warm quickly.  
But you may feel a chill at the beginning.

🌀 (MED) : Fan speed slow.

🌀 (LOW) : Fan speed slower.

🌀 (SILENT) : Fan speed ultra slower.



**3**

Set the desired room temperature with the TEMPERATURE buttons (the display indicates the setting).

The temperature setting and the actual room temperature may vary somewhat depending on conditions.

**START  
STOP**

Press the ⏻ (START/STOP) button. Heating operation starts with a beep. Press the button again to stop operation.

- As the settings are stored in memory in the remote controller, you only have to press the ⏻ (START/STOP) button next time.

## ■ Defrosting


Defrosting will be performed about once an hour when frost forms on the heat exchange of the outdoor unit, for 5~10 minutes each time.

During defrosting operation, the operation lamp blinks in cycle of 3 seconds on and 0.5 second off. The maximum time for defrosting is 20 minutes.


However, if it is connected to multi type outdoor unit, the maximum time for defrosting is 15 minutes. (If the piping length used is longer than usual, frost will likely to form.)

# DEHUMIDIFYING OPERATION

Use the device for dehumidifying when the room temperature is over 16°C.  
When it is under 15°C, the dehumidifying function will not work.




1

Press the FUNCTION selector so that the display indicates  (DEHUMIDIFY).  
The FAN SPEED is set at LOW or SILENT.

2

Set the desired room temperature with the TEMPERATURE button (the display indicates the setting).




The range of 20-26°C is recommended as the room temperature for dehumidifying.

**START  
STOP**

Press the ① (START/STOP) button. Dehumidifying operation starts with a beep. Press the button again to stop operation.

- As the settings are stored in memory in the remote controller, you only have to press the ① (START/STOP) button next time.




## ■ Dehumidifying Function

- When the room temperature is higher than the temperature setting: The device will dehumidify the room, reducing the room temperature to the preset level.  
When the room temperature is lower than the temperature setting: Dehumidifying will be performed at the temperature setting slightly lower than the current room temperature, regardless of the temperature setting. The function will stop (the indoor unit will stop emitting air) as soon as the room temperature becomes lower than the setting temperature.
- The preset room temperature may not be reached depending on the number of people present in the room or other room conditions.

# COOLING OPERATION

Use the device for cooling when the outdoor temperature is  $-21^{\circ}\text{C}\sim 43^{\circ}\text{C}$ .  
If in doors humidity is very high (80%), some dew may form on the air outlet grille of the indoor unit.



**1**

Press the FUNCTION selector so that the display indicates ❄️ (COOL).

**2**

Set the desired FAN SPEED with the 🌀 (FAN SPEED) button (the display indicates the setting).


Ⓐ (AUTO) : The FAN SPEED is HI at first and varies to MED or LOW automatically when the preset temperature has been reached.

🌀 (HI) : Economical as the room will become cool quickly.

🌀 (MED) : Fan speed slow.

🌀 (LOW) : Fan speed slower.

🌀 (SILENT) : Fan speed ultra slower.



**3**

Set the desired room temperature with the TEMPERATURE button (the display indicates the setting).

The temperature setting and the actual room temperature may vary some how depending on conditions.


**START  
STOP**


Press the ⏻ (START/STOP) button. Cooling operation starts with a beep. Press the button again to stop operation. The cooling function does not start if the temperature setting is higher than the current room temperature (even though the ⏻ (OPERATION) lamp lights). The cooling function will start as soon as you set the temperature below the current room temperature.


■ As the settings are stored in memory in the remote controller, you only have to press the ⏻ (START/STOP) button next time.





# FAN OPERATION


You can use the device simply as an air circulator. Use this function to dry the interior of the indoor unit at the end of summer.



**1** Press the FUNCTION selector so that the display indicates  (FAN).

**2** Press the  (FAN SPEED) button.

 (HI) : The strongest air blow.  
 (MED) : Fan speed slow.  
 (LOW) : Fan speed slower.  
 (SILENT) : Fan speed ultra slower.


**START STOP** Press the  (START/STOP) button. Fan operation starts with a beep. Press the button again to stop operation.

## FAN SPEED (AUTO)

..... When the AUTO fan speed mode is set in the cooling/heating operation:

For the heating operation	<ul style="list-style-type: none"> <li>● When the difference of room temperature and setting temperature is large, fan starts to run at HI speed.</li> <li>● After room temperature reaches the preset temperature, the heating operation, which changes the fan speed and room temperature to obtain optimum conditions for natural healthful heating will be performed.</li> </ul>
For the cooling operation	<ul style="list-style-type: none"> <li>● When the difference of room temperature and setting temperature is large, fan starts to run at HI speed.</li> <li>● After room temperature reaches the preset temperature, the cooling operation, which changes the fan speed and room temperature to obtain optimum conditions for natural healthful cooling will be performed.</li> </ul>

# HOW TO SET THE TIMER




## Time

After you change the batteries;

**1** Set the ⌚ (TIME) button.




## OFF-Timer




You can set the device to turn off at the preset time.

**1** Press the ⌚ (OFF-TIMER) button. The ⌚ (OFF) mark blinks on the display.




## ON-Timer


- The device will turn on at the designated times.



**1** Press the ⌚ (ON-TIMER) button the ⌚ (ON) mark blinks on the display.




## ON/OFF-Timer



- The device will turn on (off) and off (on) at the designated times.
- The switching occurs first at the preset time that comes earlier.
- The arrow mark appearing on the display indicates the sequence of switching operations.


**1** Press the ⌚ (ON-OFF) button so that the ⌚ (OFF) mark blinks.



**2** Set the turn-off time with the TIMER control button. Press the ■ (RESERVE) button.



**3** Press the ⌚ (ON-TIMER) button so that the ⌚ (OFF) mark lights and the ⌚ (ON) mark blinks.




## How to Cancel Reservation


Point the signal window of the remote controller toward the indoor unit, and press the ○ (CANCEL) button.

The ⌚ (RESERVED) sign goes out with a beep and the ⌚ (TIMER) lamp turns off on the indoor unit.


## NOTE

You can set only one of the OFF-timer, ON-timer and ON/OFF-timer.


**2** Press the  (TIME) button.





**3** Set the current time with the TIMER control button.




Example: The current time is 1:30 p.m.


**4** Press the  (TIME) button again.  
The time indication starts lighting instead of flashing.







- The time indication will disappear automatically in 10 second.
  - To check the current time setting, press the  (TIME) button twice.
- The setting of the current time is now complete.

**2** Set the turn-off time with the TIMER control button.



**3** Point the signal window of the remote controller toward the indoor unit, and press the  (RESERVE) button.


The  (OFF) mark starts lighting instead of flashing and the sign  (RESERVED) lights. A beep occurs and the  (TIMER) lamp lights on the indoor unit.







Example: The device will turn off at 11:00p.m.

The setting of turn-off time is now complete.

**2** Set the turn-on time with the TIMER control button.




**3** Point the signal window of the remote controller toward the indoor unit, and press the  (RESERVE) button.


The  (ON) mark starts lighting instead of flashing and the  (RESERVED) sign lights. A beep occurs and the  (TIMER) lamp lights on the indoor unit.







Example:  
The device will turn on at 7:00 a.m.  
The setting of the turn-on time is now complete.

**4** Set the turn-on time with the TIMER control button.




**5** Point the signal window of the remote controller toward the indoor unit, and press the  (RESERVE) button.

The  (ON) mark starts lighting instead of flashing and the  (RESERVED) sign lights. A beep occurs and the  (TIMER) lamp lights on the indoor unit.





Example:  
The device will turn off at 10:30 p.m. and it will be turned on at 7:00 a.m.  
The settings of the turn-on/off times are now complete.


- The timer may be used in three ways: off-timer, on-timer, and ON/OFF (OFF/ON)-timer. Set the current time at first because it serves as a reference.
- As the time settings are stored in memory in the remote controller, you only have to press the  (RESERVE) button in order to use the same settings next time.






# HOW TO SET THE SLEEP TIMER

Set the current time at first if it is not set before (see the pages for setting the current time). Press the  (SLEEP) button, and the display changes as shown below.





Mode	Indication
Sleep timer	 1 hour → 2 hours → 3 hours → 7 hours → Sleep timer off

**Sleep Timer:** The device will continue working for the designated number of hours and then turn off.  
Point the signal window of the remote controller toward the indoor unit, and press the SLEEP button.  
The timer information will be displayed on the remote controller. The TIMER lamp lights with a beep from the indoor unit. When the sleep timer has been set, the display indicates the turn-off time.







Example: If you set 3 hours sleep time at 11:38 p.m., the turn-off time is 2:38 a.m.



The device will be turned off by the sleep timer and turned on by on-timer.




**1** Set the ON-timer.

**2** Press the  (SLEEP) button and set the sleep timer.



For heating:  
In this case, the device will turn off in 2 hours (at 1:38 a.m.) and it will be turned on 6:00 next morning.

**How to Cancel Reservation**

Point the signal window of the remote controller toward the indoor unit, and press the  (CANCEL) button.  
The  (RESERVED) sign goes out with a beep and the  (TIMER) lamp turns off on the indoor unit.

## HOW TO EXCHANGE THE BATTERIES IN THE REMOTE CONTROLLER

---

1


Remove the cover as shown in the figure and take out the old batteries.



2

Install the new batteries.

The direction of the batteries should match the marks in the case.



### **⚠ CAUTION**

1. Do not use new and old batteries, or different kinds of batteries together.
2. Take out the batteries when you do not use the remote controller for 2 or 3 months.

## TEMPORARY SWITCH

---

If the remote controller does not work due to battery failure, press this switch to start and stop operation.

- This temporary operation will be at the setting made most recently. (The unit will immediately go into automatic operation once power is switched on.)

## CIRCUIT BREAKER

---

When you do not use the room air conditioner, set the circuit breaker to "OFF".

## THE IDEAL WAYS OF OPERATION


### Suitable Room Temperature



#### ⚠ Warning

Freezing temperature is bad for health and a waste of electric power.

### Install curtain or blinds



It is possible to reduce heat entering the room through windows.

### Ventilation


#### ⚠ Caution

Do not close the room for a long period of time. Occasionally open the door and windows to allow the entrance of fresh air.




### Effective Usage Of Timer

At night, please use the “OFF or ON timer operation mode”, together with your wake up time in the morning. This will enable you to enjoy a comfortable room temperature. Please use the timer effectively.




### Do Not Forget To Clean The Air Filter

Dusty air filter will reduce the air volume and the cooling efficiency. To prevent from wasting electric energy, please clean the filter every 2 weeks.



### Please Adjust Suitable Temperature For Baby And Children


Please pay attention to the room temperature and air flow direction when operating the unit for baby, children and old folks who have difficulty in movement.



### The Air Conditioner And The Heat Source In The Room


#### ⚠ Caution

If the amount of heat in the room is above the cooling capability of the air conditioner (for example: more people entering the room, using heating equipments and etc.), the preset room temperature cannot be achieved.



### Not Operating For A Long Time


When the indoor unit is not to be used for a long period of time, please switch off the power from the mains. If the power from mains remains "ON", the indoor unit still consumes about 8W in the operation control circuit even if it is in "OFF" mode.



### When Lightning Occurs

#### ⚠ Warning


To protect the whole unit during lightning, please stop operating the unit and remove the plug from the socket.



### Interference From Electrical Products

#### ⚠ Caution

To avoid noise interference, please place the indoor unit and its remote controller at least 1m away from electrical products.



# ATTACHING THE AIR CLEANSING FILTERS

## ⚠ CAUTION

Cleaning and maintenance must be carried out only by qualified service personal. Before cleaning, stop operation and switch off the power supply.


### 1 Open the front panel.

- Pull up the front panel by holding it at both sides with both hands.




### 2 Remove the filter.

- Push upward to release the claws and pull out the filter.




### 3 Attaching the air cleansing filters to the filter.

- Attach the air cleansing filters to the frame by gently compress its both sides and release after insertion into filter frame.




## ⚠ CAUTION

Do not bend the air cleansing filter as it may cause damage to the structure.




### 4 Attach the filters.

- Attach the filters by ensuring that the surface written "FRONT" is facing front.
- After attaching the filters, push the front panel at three arrow portion as shown in figure and close it.



## NOTE

- In case of removing the air cleansing filters, please follow the above procedures.
- The cooling capacity is slightly weakened and the cooling speed becomes slower when the air cleansing filters are used. So, set the fan speed to "HIGH" when using it in this condition.
- Do not operate the air conditioner without filter. Dust may enter the air conditioner and fault may occur.



## MAINTENANCE

### ⚠ CAUTION


Cleaning and maintenance must be carried out only by qualified service personal. Before cleaning, stop operation and switch off the power supply.

### 1. AIR FILTER



Clean the air filter, as it removes dust inside the room. In case the air filter is full of dust, the air flow will decrease and the cooling capacity will be reduced. Further, noise may occur. Be sure to clean the filter following the procedure below.

#### PROCEDURE


- 1 Open the front panel and remove the filter
- Gently lift and remove the air cleansing filter from the air filter frame.



- 2 Vacuum dust from the air filter and air cleansing filter using vacuum cleaner. If there is too much dust, air filter only rinse under running tap water and gently brush it with soft bristle brush. Allow filters to dry in shade.



- 3
- Re-insert the air cleansing filter to the filter frame. Set the filter with "FRONT" mark facing front, and slot them into the original state.
  - After attaching the filters, push the front panel at three arrow portions as shown in figure and close it.




### ⚠ CAUTION

- Do not wash with hot water at more than 40°C. The filter may shrink.
- When washing it, shake off moisture completely and dry it in the shade; do not expose it directly to the sun. The filter may shrink.
- Do not use detergent on the air cleansing filter as some detergent may deteriorate the filter electrostatic performance.


## 2. Washable Front Panel

- Remove the front panel and wash with clean water.  
Wash it with a soft sponge.  
After using neutral detergent, wash thoroughly with clean water.
- When front panel is not removed, wipe it with a soft dry cloth. Wipe the remote controller thoroughly with a soft dry cloth.
- Wipe the water thoroughly.  
If water remains at indicators or signal receiver of indoor unit, it causes trouble.




Method of removing the front panel.  
Be sure to hold the front panel with both hands to detach and attach it.

### Removing the Front Panel



- When the front panel is fully opened with both hands, push the right arm to the inside to release it, and while closing the front panel slightly, put it out forward.

### Attaching the Front Panel



- Move the projections of the left and right arms into the **Flanges** in the unit and securely insert them into the holes.

### CAUTION


- Do not splash or direct water to the body of the unit when cleaning it as this may cause short circuit.
- Never use hot water (above 40°C), benzine, gasoline, acid, thinner or a brush, because they will damage the plastic surface and the coating.




### **⚠ CAUTION**

Cleaning and maintenance must be carried out only by qualified service personal. Before cleaning, stop operation and switch off the power supply.




### **3. MAINTENANCE AT BEGINNING OF LONG OFF PERIOD**

- Running the unit setting the operation mode to  (FAN) and the fan speed to HI for about half a day on a fine day, and dry the whole of the unit.
- Switch off the power plug.



## **REGULAR INSPECTION**




PLEASE CHECK THE FOLLOWING POINTS BY QUALIFIED SERVICE PERSONAL EITHER EVERY HALF YEARLY OR YEARLY. CONTACT YOUR SALES AGENT OR SERVICE SHOP.

<b>1</b>		Is the earth line disconnected or broken?
<b>2</b>		Is the mounting frame seriously affected by rust and is the outdoor unit tilted or unstable?
<b>3</b>		Is the plug of power line firmly plugged into the socket? (Please ensure no loose contact between them).



## AFTER SALE SERVICE AND WARRANTY

### WHEN ASKING FOR SERVICE, CHECK THE FOLLOWING POINTS.

CONDITION	CHECK THE FOLLOWING POINTS
	<ul style="list-style-type: none"> <li>● Do the batteries need replacement?</li> <li>● Is the polarity of the inserted batteries correct?</li> </ul>
	<ul style="list-style-type: none"> <li>● Is the fuse all right?</li> <li>● Is the voltage extremely high or low?</li> <li>● Is the circuit breaker "ON"?</li> <li>● Is the setting of operation mode different from other indoor units?</li> </ul>
	<ul style="list-style-type: none"> <li>● Is the air filter blocked with dust?</li> <li>● Does sunlight fall directly on the outdoor unit?</li> <li>● Is the air flow of the outdoor unit obstructed?</li> <li>● Are the doors or windows opened, or is there any source of heat in the room?</li> <li>● Is the set temperature suitable?</li> <li>● Are the air inlets or air outlets of indoor and outdoor units blocked?</li> <li>● Is the fan speed "LOW" or "SILENT"?</li> </ul>

#### Notes



- In quiet operation or stopping the operation, the following phenomena may occasionally occur, but they are not abnormal for the operation.
  - (1) Slight flowing noise of refrigerant in the refrigerating cycle.
  - (2) Slight rubbing noise from the fan casing which is cooled and then gradually warmed as operation stops.
- The odor will possibly be emitted from the room air conditioner because the various odor, emitted by smoke, foodstuffs, cosmetics and so on, sticks to it. So the air filter and the evaporator regularly must be cleaned to reduce the odor.

- Please contact your sales agent immediately if the air conditioner still fails to operate normally after the above inspections. Inform your agent of the model of your unit, production number, date of installation. Please also inform him regarding the fault.
- Power supply shall be connected at the rated voltage, otherwise the unit will be broken or could not reach the specified capacity.


#### NOTE:

- If the supply cord is damaged, it must be replaced by the special cord obtainable at authorized service parts centers.
- On switching on the equipment, particularly when the room light is dimmed, a slight brightness fluctuation may occur. This is of no consequence.  
The conditions of the local Power Supply Companies are to be observed.

## CONSTRUCTION AND DIMENSIONAL DIAGRAM

MODEL RAK-18NH6AS, RAK-18NH6A, RAK-25NH6A, RAK-35NH6A, RAK-50NH6A

INDOOR UNIT



## MAIN PARTS COMPONENT


### THERMOSTAT

Thermostat Specifications

MODEL			RAK-18NH6AS, RAK-18NH6A, RAK-25NH6A, RAK-35NH6A, RAK-50NH6A	
THERMOSTAT MODEL			IC	
OPERATION MODE			COOL	HEAT
TEMPERATURE °C (°F)	INDICATION 16	ON	16.7 (62.1)	20.0 (68.0)
		OFF	16.0 (60.8)	20.7 (69.3)
	INDICATION 24	ON	24.7 (76.5)	28.0 (82.4)
		OFF	24.0 (75.2)	28.7 (83.7)
	INDICATION 32	ON	32.7 (90.9)	36.0 (96.8)
		OFF	32.0 (89.6)	36.7 (98.1)

### FAN MOTOR

Fan Motor Specifications

MODEL	RAK-18NH6AS, RAK-18NH6A, RAK-25NH6A, RAK-35NH6A, RAK-50NH6A
POWER SOURCE	DC: 5V, 35V
OUTPUT	25W
CONNECTION	 <p>(Control circuit built in)</p>

BLU : BLUE

YEL : YELLOW

BRN : BROWN

WHT : WHITE

GRY : GRAY

ORN : ORANGE

GRN : GREEN

RED : RED

BLK : BLACK


PNK : PINK

VIO : VIOLET

## WIRING DIAGRAM


MODEL RAK-18NH6AS, RAK-18NH6A, RAK-25NH6A, RAK-35NH6A, RAK-50NH6A

INDOOR UNIT




### CIRCUIT DIAGRAM

## Remote Control



PRINTED WIRING BOARD LOCATION DIAGRAM

MODEL RAK-18NH6AS, RAK-18NH6A



Resistor

Circuit's Numerical Value (Ω)	Common Value (Ω)	Power (W)	Shape
R111 27K	±5% 1/10W C		
R112 30K	±5% 1/16W C		
R113 30K	±5% 1/16W C		
R114 750	±5% 1/8 W C		
R115 560	±5% 1/8 W C		
R116 -	-		
R117 68K	±5% 1/16W C		
R118 75K	±2% 1/16W C		
R119 6.8K	±2% 1/16W C		
R121 0.56	±5% 1/4 W C		
R122 100	±5% 1/16W C		
R123 33K	±5% 1/16W C		
R124 100	±5% 1/16W C		
R141 2.7K	±5% 1/10W C		
R211 1K	±5% 1/16W C		
R212 47	±5% 1/10W C		
R301 12.7K	±1% 1/16W C		
R302 12.7K	±1% 1/16W C		
R303 10K	±5% 1/16W C		
R305 1K	±5% 1/16W C		
R306 1K	±5% 1/16W C		
R307 1K	±5% 1/16W C		

Circuit's Numerical Value (Ω)	Common Value (Ω)	Power (W)	Shape
R401 390	±5% 1/10W C		
R402 390	±5% 1/10W C		
R403 5.1K	±5% 1/16W C		
R404 5.1K	±5% 1/10W C		
R405 1K	±5% 1/16W C		
R406 5.1K	±5% 1/16W C		
R501 1M	±5% 1/16W C		
R502 1K	±5% 1/16W C		
R503 1K	±5% 1/16W C		
R504 10K	±5% 1/16W C		
R505 10K	±5% 1/16W C		
R506 10K	±5% 1/16W C		
R507 10K	±5% 1/16W C		
R508 10K	±5% 1/16W C		
R509 10K	±5% 1/16W C		
R510 10K	±5% 1/16W C		
R511 10K	±5% 1/10W C		
R512 10K	±5% 1/10W C		
R513 10K	±5% 1/16W C		
R514 10K	±5% 1/16W C		
R515 10K	±5% 1/16W C		
R516 10K	±5% 1/16W C		
R517 10K	±5% 1/16W C		
R518 10K	±5% 1/6W A		
R519 10K	±5% 1/16W C		
R520 10K	±5% 1/16W C		
R521 10K	±5% 1/16W C		
R522 10K	±5% 1/16W C		
R523 10K	±5% 1/16W C		
R524 10K	±5% 1/16W C		

Circuit's Numerical Value (Ω)	Common Value (Ω)	Power (W)	Shape
R525 10K	±5% 1/16W C		
R526 10K	±5% 1/16W C		
R527 10K	±5% 1/16W C		
R528 10K	±5% 1/16W C		
R529 10K	±5% 1/16W C		
R530 1K	±5% 1/8 W C		
R531 1K	±5% 1/16W C		
R532 1K	±5% 1/16W C		
R533 1K	±5% 1/16W C		
R534 1K	±5% 1/16W C		
R535 1K	±5% 1/16W C		
R536 1K	±5% 1/16W C		
R537 1K	±5% 1/16W C		
R538 1K	±5% 1/16W C		
R539 1K	±5% 1/16W C		
R540 1K	±5% 1/16W C		
R541 1K	±5% 1/16W C		
R542 1K	±5% 1/16W C		
R543 1K	±5% 1/16W C		
R544 1K	±5% 1/16W C		
R545 1K	±5% 1/16W C		
R546 1K	±5% 1/16W C		
R547 1K	±5% 1/16W C		
R548 1K	±5% 1/16W C		
R549 1K	±5% 1/16W C		
R550 1K	±5% 1/16W C		

Circuit's Numerical Value (Ω)	Common Value (Ω)	Power (W)	Shape
R803 120K	±5% 1/16W C		
R804 120K	±5% 1/8 W C		
R805 120K	±5% 1/16W C		
R806 120K	±5% 1/16W C		
R807 4.3K	±5% 1/16W C		
R810 680	±5% 1/16W C		
R811 2K	±5% 1/16W C		
R812 39	±5% 1/8 W C		
R813 39	±5% 1/8 W C		
R821 1K	±5% 1/16W C		
R822 1K	±5% 1/16W C		
R823 1K	±5% 1/16W C		
R824 8.25K	±1% 1/16W C		
R825 10K	±5% 1/16W C		
R826 1K	±5% 1/16W C		
R827 3K	±5% 1/16W C		
R828 10K	±5% 1/16W C		
R829 5.1K	±5% 1/16W C		
R830 1K	±5% 1/6 W A		
R911 560	±5% 1/10W C		
R912 2K	±5% 1/10W C		
R913 2K	±5% 1/10W C		
R914 1.2K	±5% 1/8 W C		
R915 620	±5% 1/10W C		

Capacitor

Circuit's Numerical Value (F)	Common Value (F)	Voltage	Type	Shape
C101 0.22μ	50V F	R		
C102 330μ	50V A	R		
C103 470μ	830V C	C		
C111 2.2μ	10V C			
C112 1000P	50V C			
C113 0.047μ	25V C			
C114 220μ	25V A	R		
C121 0.1μ	25V C			
C122 100μ	10V R			
C123 0.1μ	25V C			
C131 0.22μ	50V C			
C132 0.1μ	25V C			
C211 47μ	16V R			
C212 1μ	16V C			
C302 0.1μ	25V C			
C303 0.1μ	25V C			
C304 0.1μ	25V C			
C401 0.1μ	25V C			
C402 0.1μ	25V C			
C403 0.1μ	25V C			
C404 0.1μ	25V C			
C501 0.1μ	25V C			
C502 0.1μ	25V C			

Circuit's Numerical Value (F)	Common Value (F)	Voltage	Type	Shape
C505 0.1μ	25V C			
C506 0.1μ	25V C			
C507 0.1μ	25V C			
C508 0.1μ	25V C			
C521 0.1μ	25V C			
C522 0.01μ	50V C			
C523 0.1μ	25V C			
C524 0.1μ	25V C			
C531 -	-			
C601 0.1μ	25V C			
C611 1000P	50V C			
C621 1000P	50V C			
C631 1000P	50V C			
C651 0.1μ	25V C			
C712 0.1μ	25V C			
C713 0.1μ	25V C			
C751 1μ	16V C			
C801 150P	50V C			
C802 0.15μ	50V F			
C803 -	-			
C804 -	-			
C821 0.01μ	50V F			
C822 1000P	50V C			
C823 0.047μ	50V C			
C824 0.01μ	50V C			
C825 0.1μ	25V C			

Circuit's Numerical Value (F)	Common Value (F)	Voltage	Type	Shape
C911 47μ	16V D	R		
C912 0.1μ	25V C			
C913 1000P	50V C			
C914 1000P	50V C			
C915 2S41162Y	C			
C916 DTC114EE-TL	C			
C917 2SC5209H	C			
C918 2SC5209H	C			
C919 2SC5209H	C			
C920 2SC5209H	C			
C921 2SC5209H	C			
C922 2SC5209H	C			
C923 2SC5209H	C			
C924 2SC5209H	C			
C925 2SC5209H	C			
C926 2SC5209H	C			
C927 2SC5209H	C			
C928 2SC5209H	C			
C929 2SC5209H	C			
C930 2SC5209H	C			
C931 2SC5209H	C			
C932 2SC5209H	C			
C933 2SC5209H	C			
C934 2SC5209H	C			
C935 2SC5209H	C			

Circuit's Numerical Value (F)	Common Value (F)	Voltage	Type	Shape
C936 2SC5209H	C			
C937 2SC5209H	C			
C938 2SC5209H	C			
C939 2SC5209H	C			
C940 2SC5209H	C			
C941 2SC5209H	C			
C942 2SC5209H	C			
C943 2SC5209H	C			
C944 2SC5209H	C			
C945 2SC5209H	C			
C946 2SC5209H	C			
C947 2SC5209H	C			
C948 2SC5209H	C			
C949 2SC5209H	C			
C950 2SC5209H	C			
C951 2SC5209H	C			
C952 2SC5209H	C			
C953 2SC5209H	C			
C954 2SC5209H	C			
C955 2SC5209H	C			
C956 2SC5209H	C			
C957 2SC5209H	C			
C958 2SC5209H	C			
C959 2SC5209H	C			

Diode

Circuit's Symbol	Model	Shape
D101	DSM3MA2	C
D111	D1FS6	C
D121	1S355	C
D401	HN1D03FU	C
D403	1S355	C
D821	1S355	C
D822	1S355	C
D823	1S355	C
D824	1S355	C
D825	1S355	C
D826	1S355	C
D827	1S355	C
D828	1S355	C
D829	1S355	C
D830	1S355	C
D831	1S355	C
D832	1S355	C
D833	1S355	C
D834	1S355	C
D835	1S355	C
D836	1S355	C
D837	1S355	C
D838	1S355	C
D839	1S355	C
D840	1S355	C

IC

Circuit's Symbol	Model	Shape
IC111	NJM2340M	C
IC121	BA50COT	H
IC401	BR24L04F-W	C
IC402	BR24L04F-W	C
IC501	BR24L04F-W	C
IC521	S80942CMMC	C
IC711	ULN2003ANS	C
IC801	NJM2903M-T	C
IC802	NJM2903M-T	C
IC803	NJM2903M-T	C
IC804	NJM2903M-T	C
IC805	NJM2903M-T	C
IC806	NJM2903M-T	C
IC807	NJM2903M-T	C
IC808	NJM2903M-T	C
IC809	NJM2903M-T	C
IC810	NJM2903M-T	C
IC811	NJM2903M-T	C
IC812	NJM2903M-T	C
IC813	NJM2903M-T	C
IC814	NJM2903M-T	C
IC815	NJM2903M-T	C
IC816	NJM2903M-T	C
IC817	NJM2903M-T	C
IC818	NJM2903M-T	C
IC819	NJM2903M-T	C
IC820	NJM2903M-T	C


Coil

Circuit's Numerical Value (H)	Rating (A)	Shape
L101 82μ	1.3A	H
L111 560μ	0.6A	H
L201 1.5M	0.2A	C
L501 1608CJ	-	C
L751 1608CJ	-	C
L752 1608CJ	-	C
L801 100μ	55mA	C
L911 1.5M	0.2A	C
L912 1.5M	0.2A	C
L913 1.5M	0.2A	C
L914 1.5M	0.2A	C
L915 1.5M	0.2A	C
L916 1.5M	0.2A	C
L917 1.5M	0.2A	C
L918 1.5M	0.2A	C
L919 1.5M	0.2A	C
L920 1.5M	0.2A	C
L921 1.5M	0.2A	C
L922 1.5M	0.2A	C
L923 1.5M	0.2A	C
L924 1.5M	0.2A	C
L925 1.5M	0.2A	C
L926 1.5M	0.2A	C
L927 1.5M	0.2A	C
L928 1.5M	0.2A	C
L929 1.5M	0.2A	C

Connector

Circuit's Symbol	Model	Shape
CN1	PH-2P-Top	H
CN2	CZ-12P-Top	H
CN3	XA-3P-Top	H
CN4	PH-5P-Top	H
CN5	PH-5P-Top	H
CN6	PH-12P-Top	H
CN7	PA-5P-Top	H
CN8	XA-3P-Top	H
CN9	PA-4P-Top	H
CN10	XA-6P-Top	H
CN11	PH-5P-Top	H
CN12	PH-5P-Top	H
CN13	PH-5P-Top	H
CN14	PH-5P-Top	H
CN15	PH-5P-Top	H
CN16	PH-5P-Top	H
CN17	PH-5P-Top	H
CN18	PH-5P-Top	H
CN19	PH-5P-Top	H
CN20	PH-5P-Top	H


MODEL RAK-18NH6A, RAK-25NH6A, RAK-35NH6A, RAK-50NH6A



1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
18
19
20
21
22
23
24
25
26
27
28
29
30
31
32
33
34
35
36
37
38
39
40
41
42
43
44
45
46
47
48
49
50
51
52
53
54
55
56
57
58
59
60
61
62
63
64
65
66
67
68
69
70
71
72
73
74
75
76
77
78
79
80
81
82
83
84
85
86
87
88
89
90
91
92
93
94
95
96
97
98
99
100

## BLOCK DIAGRAM

MODEL RAK-18NH6AS, RAK-18NH6A, RAK-25NH6A, RAK-35NH6A, RAK-50NH6A





BASIC MODE

Operation mode		Fan	Cooling	Dehumidifying (dehumidifying operation by the function select button only, not including that engaged by the dehumidify button)	Heating	Auto										
Basic operation of start/stop switch		<div>Start/stop switch</div> <div>Operation lamp</div> <div>Start</div> <div>Stop</div> <div>Start</div> <div>Stop</div>														
Timer functions	Off-timer	<div>Start/stop switch</div> <div>Operation lamp</div> <div>Cancel switch</div> <div>Operation temp</div> <div>Timer lamp</div> <div>Timer memory</div> <div>(Off-timer during stop)</div> <div>(Change in reserved time)</div>														
	On-timer	<div>Start/stop switch</div> <div>Reserve switch</div> <div>Cancel switch</div> <div>Operation temp</div> <div>Timer lamp</div> <div>Timer memory</div> <div>(Change in reserved time)</div> <div>(On-timer during operation)</div>														
	Off -> On On -> Off timer	<div>Start/stop switch</div> <div>Reserve switch</div> <div>Cancel switch</div> <div>Operation lamp</div> <div>Timer lamp</div> <div>Timer memory</div> <div>(Off-&gt;On timer)</div> <div>(On-&gt;Off timer)</div> <div>(On-&gt;Off timer) during operation</div> <div>(Off-&gt;On timer) during stop</div>														
Fan speed mode (indoor fan)	Auto	<div>Changes from "Hi" to "Med" or "Lo" depending on room temperature.</div> <div><div>Temperature set for cooling</div><div>Thermo judgment</div><div>Compressor</div><div>Hi</div><div>Med</div><div>Lo</div><div>(Compressor stopped forcibly for 3 minutes)</div></div> <div>1. Runs at "Hi" until first thermo off after operation is started.</div> <div>2. Runs at "Lo" when thermo is off.</div>	<div>Changes between "Lo" and "Med" depending on the room temperature.</div> <table><tr><th>Temperature division</th><th>Fan speed</th></tr><tr><td>Division 1</td><td>Lo</td></tr><tr><td>Division 2</td><td>Lo</td></tr><tr><td>Division 3</td><td>Med</td></tr><tr><td>Division 4</td><td>Med</td></tr></table> <div>1. The indoor fan also stops when the compressor is in stop status.</div>	Temperature division	Fan speed	Division 1	Lo	Division 2	Lo	Division 3	Med	Division 4	Med	<div>Set to "ultra-Lo", "Lo", "Med", "Hi", "ultra-Hi" or "stop" depending on the room temperature, time and heat exchange temperature. Set to "stop" if the room temperature is 18°C in the "ultra-Lo" mode other than during preheating (cooling is recovered at 18.33°C).</div> <div><div>When the compressor is running at maximum speed during hot dash or when recovered from defrosting.</div><div>In modes other than left</div><div>42.66 °C</div><div>37.66 °C</div><div>32.66 °C</div><div>29.66 °C</div><div>Hi or ultra-Hi (fan speed set to "auto")</div><div>Med</div><div>Lo</div><div>Heat exchanger temperature</div></div>	<div>Operating mode is judged by room temperature and outdoor temperature.</div> <div>(1) Judging by outdoor temperature</div> <div>• Operating mode is judged by outdoor temperature.</div> <div>Only when the mode is not restricted by this judgment, the judgment by room temperature in the next paragraph will be performed.</div> <div>(a) Outdoor temperature ≥ 30°C : Restricted to cooling</div> <div>(b) Outdoor temperature ≤ 9°C : Restricted to heating</div> <div>(2) Judging by room temperature</div> <div>Operating mode at start up is judged (initial judgment)</div> <div>(a) Conditions for judgment (any of the followings)</div> <div>• When auto operation is started after 1 hour has elapsed since the operation was stopped.</div> <div>• When auto operation is started after the previous manual mode operation.</div> <div>• When the operating mode is switched to auto while operating at manual mode.</div> <div>(b) Judging method</div> <div>• Room temperature ≥ 23°C ±3°C : Cooling</div> <div>• Room temperature &lt; 23°C ±3°C : Heating</div> <div>※ ±3°C is the fine adjustment value from the remote controller.</div> <div><div>Judging operating mode change during operation (Continuous judgment)</div><div>(a) Conditions for judgment (any of the followings)</div><div>• The mode is reviewed at every interval time.</div><div>• When auto operation is started again before 1 hour has elapsed since the operation was stopped.</div><div>(b) Judging method</div><div>• Judge by setting the hysteresis on the final preset temperature.</div><div>The final preset temperature is the actually targeted preset temperature which is the sum of the basic preset temperature and each type of shift value (e.g. ±3°C by remote controller, preset temperature correction value, powerful shift value, etc.).</div><div>[Currently cooling]</div><div>• Room temperature ≤ Final preset temperature −3°C Change to heating</div><div>• Room temperature &gt; Final preset temperature −3°C Continue cooling</div><div>[Currently heating]</div><div>• Room temperature ≥ Final preset temperature +2°C Change to cooling</div><div>• Room temperature &lt; Final preset temperature +2°C Continue heating</div></div>	
	Temperature division	Fan speed														
	Division 1	Lo														
	Division 2	Lo														
Division 3	Med															
Division 4	Med															
Hi	Operates at "Hi" regardless of the room temperature.	Set to "ultra-Hi" when the compressor runs at maximum speed, and to "Hi" in other modes.	Set to "Hi" in modes other than when the compressor stops.	Set to "ultra-Lo", "Lo", "Med", "Hi", "ultra-Hi" or "stop" depending on the room temperature, and time. Set to "stop" if the room temperature is 18°C in the "ultra-Lo" mode other than during preheating (cooling is recovered at 18.33°C). Set to "ultra-Hi" when the compressor is running at maximum speed during hot dash or when recovered from defrosting.	<div>Room temperature</div> <div>22°C</div> <div>Cooling</div> <div>Heating</div> <div>9°C</div> <div>30°C</div> <div>Outdoor temperature</div>											
Med	Operates at "Med" regardless of the room temperature.	Same as at left.	Set to "Med" in modes other than when the compressor stops.	Set to "ultra-Lo", "Lo", "Med" or "stop" depending on the room temperature and time. Set to "stop" if the room temperature is 18°C in the "ultra-Lo" mode other than during preheating (cooling is recovered at 18.33°C).												
Lo	Operates at "Lo" regardless of the room temperature.	Same as at left.	Set to "Lo" in modes other than when the compressor stops.	Set to "ultra-Lo", "Lo", or "stop" depending on the room temperature and time. Set to "stop" if the room temperature is 18°C in the "ultra-Lo" mode other than during preheating (cooling is recovered at 18.33°C). The fan speed is controlled by the heat exchanger temperature; the overload control is executed as in the following diagram: <div><div>Heat exchanger temperature</div><div>KAFON</div><div>KAFOF</div><div>"Med" with overload</div><div>"Lo"</div></div>												
Basic operation of temperature controller	Performs only fan operation at the set speed regardless of the room temperature.	See page 51.	See page 55.	See page 57.	<div>-3°C</div> <div>Heating</div> <div>final preset temperature</div> <div>+2°C</div> <div>Cooling</div>											
Sleep operation (with sleep button ON)	<div>• Enters sleep operation after set as on the left.</div> <div>• Action during sleep operation Lo (sleep) operation</div>	<div>• Same as at left</div> <div>• See page 53.</div>	<div>• Same as at left</div> <div>• See page 55.</div>	<div>• Same as at left</div> <div>• See page 59.</div>	<div>• Same as at left.</div> <div>• Performs the sleep operation of each operation mode.</div>											

Combination of operations:

- When operation mode is selected:
- You cannot operate the indoor units in the following combinations.
  - The indoor unit which is switched on first continues to operate, but other indoor units which is switched on later, does not operate while the lamp lights.

One unit	Other unit
Heating	Cooling
	Dehumidifying
	Circulating (fan)

During automatic operation:

- When heating operation is automatically selected for the first indoor unit, the next indoor unit will then start to heat. Also, if cooling or dehumidifying is automatically selected for the first indoor unit, the next indoor unit will also start to cool or dehumidify.

Notes:

- Refer to the PWRITE-ZU data for the constants expressed by capital alphabet letters in the drawing.
- The speed set of rotation for the fan motor in each operation mode are as shown in Table 1.
- The set room temperatures in the diagram include the shift values in Table 2.

MODEL		RAK-18NH6AS	RAK-18NH6A	RAK-25NH6A	RAK-35NH6A	RAK-50NH6A
PROM NO.	LABEL NAME	REQUIRED VALUE OF UNIT SIDE	REQUIRED VALUE OF UNIT SIDE	REQUIRED VALUE OF UNIT SIDE	REQUIRED VALUE OF UNIT SIDE	REQUIRED VALUE OF UNIT SIDE
0A2	RTOTSA	0°C	0°C	0°C	0°C	
157	WMAX_M	3500 min <sup>-1</sup>	5300 min <sup>-1</sup>	5300 min <sup>-1</sup>	5000 min <sup>-1</sup>	5000 min <sup>-1</sup>
158	WMAX2_M	3500 min <sup>-1</sup>	5300 min <sup>-1</sup>	5300 min <sup>-1</sup>	5000 min <sup>-1</sup>	5000 min <sup>-1</sup>
159	WSTD_M	2950 min <sup>-1</sup>	4000 min <sup>-1</sup>	4000 min <sup>-1</sup>	4000 min <sup>-1</sup>	4000 min <sup>-1</sup>
15A	CMAX_M	3000 min <sup>-1</sup>	3300 min <sup>-1</sup>	3300 min <sup>-1</sup>	4300 min <sup>-1</sup>	4300 min <sup>-1</sup>
15B	CSTD_M	2400 min <sup>-1</sup>	3250 min <sup>-1</sup>	3250 min <sup>-1</sup>	3150 min <sup>-1</sup>	3150 min <sup>-1</sup>
15C	SDMAX_M	2400 min <sup>-1</sup>	2400 min <sup>-1</sup>	2400 min <sup>-1</sup>	1550 min <sup>-1</sup>	1550 min <sup>-1</sup>
15D	SDRPM_M	2100 min <sup>-1</sup>	2100 min <sup>-1</sup>	2100 min <sup>-1</sup>	1400 min <sup>-1</sup>	1400 min <sup>-1</sup>
15F	WMIN_M	800 min <sup>-1</sup>	800 min <sup>-1</sup>	800 min <sup>-1</sup>	800 min <sup>-1</sup>	800 min <sup>-1</sup>
160	CMINHI_M	800 min <sup>-1</sup>	800 min <sup>-1</sup>	800 min <sup>-1</sup>	800 min <sup>-1</sup>	800 min <sup>-1</sup>
161	CMIN_M	1200 min <sup>-1</sup>	1200 min <sup>-1</sup>	1200 min <sup>-1</sup>	1200 min <sup>-1</sup>	1200 min <sup>-1</sup>
162	DMIN_M	1200 min <sup>-1</sup>	1200 min <sup>-1</sup>	1200 min <sup>-1</sup>	1200 min <sup>-1</sup>	1200 min <sup>-1</sup>
163	PKOU_M	550 min <sup>-1</sup>	550 min <sup>-1</sup>	550 min <sup>-1</sup>	550 min <sup>-1</sup>	550 min <sup>-1</sup>
164	FZZY_GN_M	2	2	1.5	1.5	1.5
166	FZZYTM_M	4 min	4 min	4 min	4 min	4 min
172	SHIFTW_M	0 °C	0 °C	2 °C	2 °C	2 °C
173	SFTSZW_M	0 °C	0 °C	2 °C	2 °C	2 °C
175	SHIFTC_M	1.33 °C	1.33 °C	1.33 °C	1.33 °C	1.33 °C
176	SHIFTD_M	3.33 °C	3.33 °C	3.33 °C	3.33 °C	3.33 °C
17C	TEION_M	2 °C	2 °C	2 °C	2 °C	2 °C
17D	TEIOF_M	9 °C	9 °C	9 °C	– °C	– °C
182	FWSS_M	500 min <sup>-1</sup>	500 min <sup>-1</sup>	500 min <sup>-1</sup>	500 min <sup>-1</sup>	500 min <sup>-1</sup>
183	FWSOY_M	600 min <sup>-1</sup>	600 min <sup>-1</sup>	600 min <sup>-1</sup>	700 min <sup>-1</sup>	700 min <sup>-1</sup>
184	FWS_M	720 min <sup>-1</sup>	720 min <sup>-1</sup>	750 min <sup>-1</sup>	820 min <sup>-1</sup>	820 min <sup>-1</sup>
185	FWKAF_M	800 min <sup>-1</sup>	840 min <sup>-1</sup>	850 min <sup>-1</sup>	920 min <sup>-1</sup>	920 min <sup>-1</sup>
186	FWL_M	750 min <sup>-1</sup>	840 min <sup>-1</sup>	850 min <sup>-1</sup>	920 min <sup>-1</sup>	920 min <sup>-1</sup>
187	FWAH_M	800 min <sup>-1</sup>	940 min <sup>-1</sup>	1050 min <sup>-1</sup>	1120 min <sup>-1</sup>	1120 min <sup>-1</sup>
188	FWH_M	800 min <sup>-1</sup>	940 min <sup>-1</sup>	1050 min <sup>-1</sup>	1120 min <sup>-1</sup>	1120 min <sup>-1</sup>
18A	FWHH_M	1030 min <sup>-1</sup>	1030 min <sup>-1</sup>	1170 min <sup>-1</sup>	1250 min <sup>-1</sup>	1250 min <sup>-1</sup>
18B	FCSOY_M	550 min <sup>-1</sup>	550 min <sup>-1</sup>	600 min <sup>-1</sup>	680 min <sup>-1</sup>	680 min <sup>-1</sup>
18C	FCS_M	650 min <sup>-1</sup>	650 min <sup>-1</sup>	750 min <sup>-1</sup>	780 min <sup>-1</sup>	780 min <sup>-1</sup>
18D	FCL_M	680 min <sup>-1</sup>	740 min <sup>-1</sup>	870 min <sup>-1</sup>	950 min <sup>-1</sup>	950 min <sup>-1</sup>
18E	FCAH_M	700 min <sup>-1</sup>	850 min <sup>-1</sup>	980 min <sup>-1</sup>	1030 min <sup>-1</sup>	1030 min <sup>-1</sup>
18F	FCH_M	700 min <sup>-1</sup>	890 min <sup>-1</sup>	1030 min <sup>-1</sup>	1170 min <sup>-1</sup>	1170 min <sup>-1</sup>
190	FCHH_M	990 min <sup>-1</sup>	990 min <sup>-1</sup>	1030 min <sup>-1</sup>	1200 min <sup>-1</sup>	1200 min <sup>-1</sup>
191	FDOY_M	600 min <sup>-1</sup>	600 min <sup>-1</sup>	600 min <sup>-1</sup>	680 min <sup>-1</sup>	680 min <sup>-1</sup>
192	FDS1_M	660 min <sup>-1</sup>	720 min <sup>-1</sup>	750 min <sup>-1</sup>	780 min <sup>-1</sup>	780 min <sup>-1</sup>
193	FDS2_M	660 min <sup>-1</sup>	720 min <sup>-1</sup>	750 min <sup>-1</sup>	780 min <sup>-1</sup>	780 min <sup>-1</sup>


Table 1 Fan speed by mode

Operation mode	Fan speed mode		Label name
Heating operation	Ultra Lo		FWSS_M
	Sleep		FWSOY_M
	Lo		FWS_M
	Overload		FWKAF_M
	Med		FWL_M
	Hi	Set fan speed "AUTO"	FWAH_M
	Hi	Set fan speed "Hi"	FWH_M
	Ultra Hi		FWHH_M
Cooling operation	Sleep		FCSOY_M
	Lo		FCS_M
	Med		FCL_M
	Hi	Set fan speed "AUTO"	FCAH_M
	Hi	Set fan speed "Hi"	FCH_M
	Ultra Hi		FCHH_M
Dehumidifying operation	Sleep		FDOY_M
	Lo 1		FDS1_M
	Lo 2		FDS2_M

Table 2 Room temperature shift value

Operation mode		Shift value
Heating operation	Fan speed "AUTO, Hi, Med"	SHIFTW_M
	Fan speed "Lo, Sleep"	SFTSZW_M
Cooling operation		SHIFTC_M
Dehumidifying operation		SHIFTD_M

Basic Cooling Operation




Notes:

- (1) Condition for entering into Cool Dashed mode. When fan set to “Hi” or “Auto mode” and temperature difference between indoor temperature and set temperature has a corresponding compressor rpm (calculated value in Table 3) larger than WMAX.
- (2) Cool Dashed will release when i) a maximum 25 minutes is lapsed and ii) room temperature is lower than set temperature −3°C (thermo off) and iii) when room temperature has achieved setting temperature −1°C then maximum Cool Dashed time will be revised to 20 minutes. And iv) indoor fan is set to Lo and Med fan mode and v) change operation mode.
- (3) During Cool Dashed operation, thermo off temperature is set temperature (with shift value) −3°C. After thermo off, operation continue in Fuzzy control mode.
- (4) Compressor minimum “ON” time and “OFF” time is 3 minutes.
- (5) During normal cooling mode, compressor maximum rpm CMAX will maintain for 60 minutes if indoor temperature is lower than CLMXTP. No time constrain if indoor temperature is higher than CLMXTP.
- (6) When fan is set to “Hi”, compressor rpm will be limited to CKYMAX.
- (7) When fan is set to “Med”, compressor rpm will be limited to CJKMAX.
- (8) When fan is set to “Lo”, compressor rpm will be limited to CBEMAX.
- (9) During Cool Dashed, when room temperature reaches set temperature −1°C compressor rpm is actual rpm x DWNRATEC.

Table 3 ΔTCMAX

Temperature difference	Calculated compressor rpm
1.66	2265 min <sup>-1</sup>
2	2435 min <sup>-1</sup>
2.33	2600 min <sup>-1</sup>
2.66	2765 min <sup>-1</sup>
3	2935 min <sup>-1</sup>
3.33	3100 min <sup>-1</sup>
3.66	3265 min <sup>-1</sup>
4	3435 min <sup>-1</sup>
4.33	3600 min <sup>-1</sup>
4.66	3765 min <sup>-1</sup>
5	3935 min <sup>-1</sup>
5.33	4100 min <sup>-1</sup>
5.66	4265 min <sup>-1</sup>
6	4435 min <sup>-1</sup>
6.33	4600 min <sup>-1</sup>
6.66	4765 min <sup>-1</sup>
7	4935 min <sup>-1</sup>
7.33	5100 min <sup>-1</sup>
7.66	5265 min <sup>-1</sup>
8	5435 min <sup>-1</sup>
8.33	5600 min <sup>-1</sup>
8.66	5765 min <sup>-1</sup>
9	5935 min <sup>-1</sup>
9.33	6100 min <sup>-1</sup>
9.66	6265 min <sup>-1</sup>
10	6435 min <sup>-1</sup>
10.33	6600 min <sup>-1</sup>
10.66	6765 min <sup>-1</sup>
11	6935 min <sup>-1</sup>


## New Cool Rhythm



### Notes:

- (1) New cool rhythm is engaged when the fan speed is “auto” and the room temperature is less than set one plus 0.66°C in the “auto” operation mode or cooling mode.
- (2) The minimum new cool rhythm time is 10 minutes when the temperature falls and rises.
- (3) Cool rhythm is not engaged during Nice temperature, Sleep operation.
- (4) PI control is engaged during new cool rhythm: the speed limit is the same as during normal operation.
- (5) The new cool rhythm set temperature is also shifted during thermo OFF.


## Cooling Sleep Operation




### Notes:

- (1) The sleep operation starts when the sleep key is pressed.
- (2) When the sleep key is set, the maximum compressor speed is limited, and the indoor fan is set to “sleep Lo”.
- (3) 30 minutes after the sleep key is set, the sleep shift of temperature starts, and upper shift is made at least 6 times. If 25°C is not reached after 6 shifts, shifts repeat unit 25°C is reached.
- (4) The sleep shift upper value of set temperature is 28°C.
- (5) After 6 hours, a shift down to the initial set temperature is made at a rate of 0.33°C/5 min.
- (6) If the operation mode is changed during sleep operation, the set temperature is cleared, and shift starts from the point when switching is made.
- (7) The indoor fan speed does not change even when the fan speed mode is changed.
- (8) When operation is stopped during sleep operation, the set temperature when stopped, as well as the time, continue to be counted.
- (9) If the set lime is changed during sleep operation, all data including set temperature, time, etc. is cleared and restarted.
- (10) If sleep operation is canceled by the cancel key or sleep key, all data is cleared.

## Cooling Defrost




Dehumidifying



- Notes:**
- (1) If the room temperature is (cooling preset temperature) - (1.33°C) or less after 30 seconds from starting the operation, the operation is done assuming as the preset temperature = (room temperature at the time) - (2°C).
  - (2) The indoor fan is operated in the "Lo" mode. During thermo OFF indoor fan will be OFF for 5 minutes and ON for 1 minute.
  - (3) When the operation is started by the thermostat turning ON, the start of the indoor fan is delayed 32 seconds after the start of compressor operation.
  - (4) The compressor is operated forcedly for 3 minutes after operation is started.
  - (5) The minimum ON time and OFF time of the compressor are 3 minutes.

Dehumidifying Sleep Operation



- Notes:**
- (1) The sleep operation starts when the sleep key is pressed.
  - (2) When the sleep key is set, the indoor fan is set to "sleep silent" (FDOY\_M or AFDOY).
  - (3) The indoor fan speed does not change even when the fan speed mode is changed.
  - (4) If the set time is changed during sleep operation, all data including set temperature, time, etc. is cleared and restarted.
  - (5) If sleep operation is canceled by the cancel key or sleep key, all data is cleared.
  - (6) If the position of air deflector is being operated using remote control, the operation will be performed at any desired position of air deflector.

Basic Cooling Operation





Table 3 ΔTCMAX

Temperature difference	Calculated compressor rpm
1.66	2265 min <sup>-1</sup>
2	2435 min <sup>-1</sup>
2.33	2600 min <sup>-1</sup>
2.66	2765 min <sup>-1</sup>
3	2935 min <sup>-1</sup>
3.33	3100 min <sup>-1</sup>
3.66	3265 min <sup>-1</sup>
4	3435 min <sup>-1</sup>
4.33	3600 min <sup>-1</sup>
4.66	3765 min <sup>-1</sup>
5	3935 min <sup>-1</sup>
5.33	4100 min <sup>-1</sup>
5.66	4265 min <sup>-1</sup>
6	4435 min <sup>-1</sup>
6.33	4600 min <sup>-1</sup>
6.66	4765 min <sup>-1</sup>
7	4935 min <sup>-1</sup>
7.33	5100 min <sup>-1</sup>
7.66	5265 min <sup>-1</sup>
8	5435 min <sup>-1</sup>
8.33	5600 min <sup>-1</sup>
8.66	5765 min <sup>-1</sup>
9	5935 min <sup>-1</sup>
9.33	6100 min <sup>-1</sup>
9.66	6265 min <sup>-1</sup>
10	6435 min <sup>-1</sup>
10.33	6600 min <sup>-1</sup>
10.66	6765 min <sup>-1</sup>
11	6935 min <sup>-1</sup>

Notes:


- (1) Condition for entering into Cool Dashed mode. When fan set to “Hi” or “Auto mode” and temperature difference between indoor temperature and set temperature has a corresponding compressor rpm (calculated value in Table 3) larger than WMAX.
- (2) Cool Dashed will release when i) a maximum 25 minutes is lapsed and ii) room temperature is lower than set temperature −3°C (thermo off) and iii) when room temperature has achieved setting temperature −1°C then maximum Cool Dashed time will be revised to 20 minutes. And iv) indoor fan is set to Lo and Med fan mode and v) change operation mode.
- (3) During Cool Dashed operation, thermo off temperature is set temperature (with shift value) −3°C. After thermo off, operation continue in Fuzzy control mode.
- (4) Compressor minimum “ON” time and “OFF” time is 3 minutes.
- (5) During normal cooling mode, compressor maximum rpm CMAX will maintain for 60 minutes if indoor temperature is lower than CLMXTP. No time constrain if indoor temperature is higher than CLMXTP.
- (6) When fan is set to “Hi”, compressor rpm will be limited to CKYMAX.
- (7) When fan is set to “Med”, compressor rpm will be limited to CJKMAX.
- (8) When fan is set to “Lo”, compressor rpm will be limited to CBEMAX.
- (9) During Cool Dashed, when room temperature reaches set temperature −1°C compressor rpm is actual rpm x DWNRATEC.

### Reversing Valve Defrosting




- Notes:
- (1) The defrosting inhibit period is set as shown in the diagram below. When defrosting has finished once, the inhibit period is newly set, based on the outdoor temperature when the compressor was started. During this period, the defrost signal is not accepted.
  - (2) If the difference between the room and outdoor temperatures is large when defrosting is finished, the maximum compressor speed (WMAX) or (WMAX2) can be continued for 120 minutes maximum.
  - (3) The defrosting period is 20 minutes maximum.
  - (4) When operation is stopped during defrosting, it is switched to auto refresh defrosting.
  - (5) Auto refresh defrosting cannot be engaged within 15 minutes after operation is started or defrosting is finished.

### Setting Defrosting Inhibit Period



- Notes:
- (1) The first inhibit time after operation start is set to DFTIM1.
  - (2) From the second time onwards, the inhibit time is set according to the time required for defrosting.  
Reverse cycle operation time  $\geq$  [DEFCOL] : DEFTIM1 is set.  
Reverse cycle operation time  $<$  [DEFCOL] : The time corresponding to outdoor temperature is set.

### Heating Sleep Operation




- Notes:
- (1) The sleep operation starts when the sleep key is pressed.
  - (2) When the sleep key is set, the maximum compressor speed is limited to WBEMAX, and the indoor fan is set to "Sleep Silent" (FWSOY).
  - (3) If the operation mode is changed during sleep operation, the changed operation mode is set and sleep control starts.
  - (4) The indoor fan speed does not change even when the fan speed mode is changed. (Lo)
  - (5) When defrosting is to be set during sleep operation, defrosting is engaged and sleep operation is restored after defrosting.
  - (6) When operation is stopped during sleep operation, the set temperature when stopped, as well as the time, continue to be counted.
  - (7) If the set time is changed during sleep operation, all data including set temperature, time, etc. is cleared and restarted.
  - (8) If sleep operation is cancelled by the cancel key or sleep key all data is cleared.
  - (9) There is no preset temperature shift due to time elapse.

#### NOTE

1. Refer to the PWRITE-ZU data for the constants expressed by capital alphabet letters in the drawing.


# REFRIGERATING CYCLE DIAGRAM RAK-18NH6AS, RAK-18NH6A, RAK-25NH6A, RAK-35NH6A, RAK-50NH6A

Cooling, dehumidifying, defrosting





REFRIGERATING CYCLE DIAGRAM  
 RAK-18NH6AS, RAK-18NH6A, RAK-25NH6A, RAK-35NH6A, RAK-50NH6A



## AUTO SWING FUNCTION

MODEL: RAK-18NH6AS, RAK-18NH6A, RAK-25NH6A, RAK-35NH6A, RAK-50NH6A

INPUT SIGNAL	PRESENT CONDITION			OPERATING SPECIFICATION	REFERENCE
	OPERATION	OPERATION MODE	AIR DEFLECTOR		
KEY INPUT	STOP	EACH MODE	STOP	ONE SWING (CLOSING AIR DEFLECTOR) ① DOWNWARD ② UPWARD	INITIALIZE AT NEXT OPERATION.
			DURING ONE SWING	STOP AT THE MOMENT.	
	DURING OPERATION	AUTO COOL COOL FAN AUTO DRY DRY	STOP	START SWINGING ① DOWNWARD ② UPWARD ③ DOWNWARD	
			DURING SWINGING	STOP AT THE MOMENT.	
THERMO. ON (INTERNAL FAN ON)  THERMO. ON (INTERNAL FAN OFF)	DURING OPERATION	AUTO HEAT HEAT CIRCULATOR	STOP	START SWINGING ① DOWNWARD ② UPWARD ③ DOWNWARD	
			DURING SWINGING	STOP AT THE MOMENT.	
		AUTO DRY DRY AUTO HEAT HEAT CIRCULATOR	TEMPORARY STOP	START SWING AGAIN.	
			DURING SWINGING	STOP SWINGING TEMPORARILY. (SWING MODE IS CLEARED IF SWING COMMAND IS TRANSMITTED DURING TEMPORARY STOP.)	
MAIN SWITCH ON	STOP	COOL FAN DRY	STOP DURING ONE SWING	INITIALIZE ① DOWNWARD ② UPWARD	
		HEAT CIRCULATOR	STOP DURING ONE SWING	INITIALIZE ① DOWNWARD	
MAIN SWITCH OFF	DURING OPERATION	EACH MODE	STOP DURING SWINGING	ONE SWING (CLOSING AIR DEFLECTOR) ① DOWNWARD ② UPWARD	INITIALIZE AT NEXT OPERATION.
			DURING INITIALIZING		
CHANGE OF OPERATION	DURING OPERATION	EACH MODE	STOP	INITIALIZING CONDITION OF EACH MODE.	
			DURING SWINGING	STOP SWINGING AND MODE BECOMES INITIALIZING CONDITION.	

# DESCRIPTION OF MAIN CIRCUIT OPERATION

RAK-18NH6AS, RAK-18NH6A, RAK-25NH6A, RAK-35NH6A, RAK-50NH6A

## 1. Reset Circuit




Fig. 1-1




Fig. 1-2

- The reset circuit initializes the microcomputer program when power is ON or OFF.
- Low voltage at pin ⑦ resets the microcomputer and Hi activates the microcomputer.
- When power "ON" 5V voltage rises and reaches 4.4V, pin ① of IC521 is set to "Hi". At this time the microcomputer starts operation.
- When power "OFF" voltage drops and reaches 4.2V, pin ① of IC521 is set to "Low". This will RESET the microcomputer.

## 2. Receiver Circuit




Fig. 2-1

- The light receiver unit receives the infrared signal from the wireless remote control. The receiver amplifies and shapes the signal and outputs it.

## 3. Buzzer Circuit




Fig. 3-1 Buzzer Circuit

- When the buzzer sounds, an approx. 3.9kHz square signal is output from buzzer output pin (30) of the microcomputer. After the amplitude of this signal has been set to 12Vp-p by a transistor, it is applied to the buzzer. The piezoelectric element in the buzzer oscillates to generate the buzzer's sound.




Fig. 3-2 Buzzer Operation

4. Auto Sweep Motor Circuit




Fig.4-1

- Fig. 4-1 shows the Auto sweep motor drive circuit; the signals shown in Fig.4-2 are output from pins 15 – 18 of microcomputer.




Fig.4-2 Microcomputer Output Signals

- As the microcomputer’s outputs change as shown in Fig.4-2, the core of the auto sweep motor is excited to turn the rotor. Table 4-1 shows the rotation angle of horizontal air deflectors.

Table 4-1 Auto sweep Motor Rotation

	Rotation angle per step ( ° )	Time per step (ms.)
Horizontal air deflectors	0.0882	10

## 5. Room Temperature Thermistor Circuit

- Fig. 5-1 shows the room temperature thermistor circuit.




Fig. 5-1

- The voltage at (A) depends on the room temperature as shown in Fig. 5-2.




Fig. 5-2

## 6. Heat exchanger temperature thermistor circuit




Fig. 6-1

- The circuit detects the indoor heat exchanger temperature and controls the following.

- (1) Preheating.
- (2) Low-temperature defrosting during cooling and dehumidifying operation.
- (3) Detection of the reversing valve non-operation or heat exchanger temperature thermistor open.

The voltage at (A) depends on the heat exchanger temperature as shown in Fig. 6-2.




Fig. 6-2

## 7. Initial Setting Circuit (IC401)

- When power is supplied, the microcomputer reads the data in IC401 (E<sup>2</sup>PROM) and sets the preheating activation value and the rating and maximum speed of the compressor, etc. to their initial values.
- Data of self-diagnosis mode is stored in IC401; data will not be erased even when power is turned off.




Fig. 7-1

## 8. Initial Setting Circuit (IC401) – For RAK-18NH6AS only

- When power is supplied, the microcomputer reads the data in IC401 and IC402 (E<sup>2</sup>PROM) and sets the preheating activation value and the rating and maximum speed of the compressor, etc. to their initial values.





Fig. 8-1

SW2 will act as a program selector for IDR .2kW and 1.8kW. When switch is turn to position 1.8kW, IC401 will be selected as 1.8kW mode. When switch is turn to position 1.2kW, IC402 will be selected as 1.2kW mode.


# SERVICE CALL Q & A

MODEL RAK-18NH6AS, RAK-18NH6A, RAK-25NH6A, RAK-35NH6A, RAK-50NH6A


## COOLING MODE



## DEHUMIDIFYING MODE



## HEATING MODE





## AUTO FRESH DEFROSTING

**Q7)** After the ON/OFF button is pressed to stop heating, the outdoor unit is still working with the OPERATION lamp lighting.



**A7)** Auto Fresh Defrosting is carried out : the system checks the outdoor heat exchanger and defrosts it as necessary before stopping operation.

## AUTO OPERATION

**Q8)** Fan speed does not change when fan speed selector is changed during auto operation.



**A8)** At this point fan speed is automatic.

## NICE TEMPERATURE RESERVATION

**Q9)** When on-timer has been programmed, operation starts before the preset time has been reached.



**A9)** This is because “Nice temperature reservation” function is operating. This function starts operation earlier so the preset temperature is reached at the preset time. Operation may start maximum 60 minutes before the preset time.

**Q10)** Does “Nice temperature reservation” function operate during dehumidifying?



**A10)** It does not work. It works only during cooling and heating.

**Q11)** Even if the same time is preset, the operation start time varies.



**A11)** This is because “Nice temperature reservation” function is operating. The start time varies according to the load of room. Since load varies greatly during heating, the operation start time is corrected, so it will vary each day.

## INFRARED REMOTE CONTROL

**Q12)** Timer cannot be set.



**A12)** Has the clock been set? Timer cannot be set unless the clock has been set.

**Q13)** The current time display disappears soon.



**A13)** The current time disappears in approx. 10 seconds. The time set display has priority.


When the current time is set the display flashes for approx 3 minutes.

**Q14)** The timer has been programmed, but the preset time disappears.



**A14)** Is the current time past the preset time? When the preset time reaches the current time, it disappears.

## OTHERS










## TROUBLESHOOTING WHEN TIMER LAMP BLINKS.

Model RAK-18NH6AS, RAK-18NH6A, RAK-25NH6A, RAK-35NH6A, RAK-50NH6A

Perform troubleshooting according to the number of times the indoor timer lamp and outdoor LD301 blink.

## SELF-DIAGNOSIS LIGHTING MODE

Model: RAK-18NH6AS, RAK-18NH6A, RAK-25NH6A, RAK-35NH6A, RAK-50NH6A

No.	Blinking of Timer lamp	Reason for indication	Possible cause
1	 1 time	<u>Reversing valve defect</u> When the indoor heat exchanger temperature is too low in the heating mode or it is too high in the cooling mode.	(1) Reversing valve defect (2) Heat exchanger thermistor disconnected (only in the heating mode) (Note) The malfunction mode is entered the 3rd time this abnormal indication appears (read every 3 minutes).
2	 2 times	<u>Outdoor unit forced operation</u> When the outdoor unit is in forced operation or balancing operation after forced operation	Electrical parts in the outdoor unit
3	 3 times	<u>Indoor/outdoor interface defect</u> When the interface signal from the outdoor unit is interrupted.	(1) Indoor interface circuit (2) Outdoor interface circuit
4	 4 times	<u>Outdoor electrical assembly defective.</u>	Please check at the outdoor electrical led lamp blinking (LD301) and refer to self diagnosis lighting mode for outdoor unit.
5	 9 times	<u>Room thermistor or heat exchanger thermistor is faulty</u> When room thermistor or heat exchanger thermistor is opened circuit or short circuit.	(1) Room thermistor (2) Heat exchanger thermistor
6	 10 times	<u>Over-current detection at the DC fan motor</u> When over-current is detected at the DC fan motor of the indoor unit.	(1) Indoor fan locked (2) Indoor fan motor (3) Indoor control P.W.B.
※1 7	 13 times	<u>IC401 or IC402 data reading error</u> When data read from IC401 or IC402 is incorrect.	IC401 or IC402 abnormal


(  -- Lights for 0.35 sec. at interval of 0.35 sec.)

## <Cautions>


- (1) If the interface circuit is faulty when power is supplied, the self-diagnosis display will not be displayed.
- (2) If the indoor unit does not operate at all, check to see if the connecting cable is connected or disconnected.
- (3) To check operation again when the timer lamp is blinking, you can use the remote control for operation (except for mode mark ※1).

# CHECKING INDOOR UNIT ELECTRICAL PARTS


## 1. Power does not come on (no operation)




## 2. Only indoor fan does not operate (other is normal)




## 3. Air deflector does not move (others are normal)





## 4. All systems stop from several seconds to several minutes after operation is started (all indicators are also off)



5. Check the control P.W.B (power circuit)




# CHECKING THE REMOTE CONTROLLER



You can check the remote control switch by other methods as explained below.

## Using the test card



The sensible area should flash in orange when you operate the remote control unit if it is good.

Check functions again.  
If it does not work, replace the remote controller.

# Procedure for Disassembly and Reassembly

INDOOR UNIT RAK-18NH6AS, RAK-18NH6A, RAK-25NH6A, RAK-35NH6A, RAK-50NH6A

## 1. Front Panel

- (1) Pull up the washable panel by holding it at both lower sides with both hands.




Fig. 1

- (2) When the panel opens full, push the inner part of the right arm into the inside and pull the panel forward while closing it gradually.




Fig. 2

## 2. Front cover

- (1) After removing two screws, pull the center of the front cover forward and release the claws.
- (2) Hold the front cover at both lower sides and pull them forward to remove.




Fig. 3

## 3. Main P.W.B. and Reception/Indication P.W.B

- (1) Remove each connector from the lead wire.
- (2) Remove the four P.W.B supports from the main P.W.B..
- (3) Pull the support hook at the upper side of the indication lamp of the reception/indication P.W.B and pull out the P.W.B forward.




Fig. 4



#### 4. Tangential air flow fan and fan motor

- (1) Remove two screws locking the drain pan.
- (2) Press to lower the hook at the center of the unit a little and pull the claw forward to remove the drain pan.




Fig. 5

- (3) Remove the screws from the upper and lower bearing covers.
- (4) Remove the locking hook of the lower bearing cover from the Cabinet.




Fig. 6

- (5) Remove two lock screws from the fan motor holder.
- (6) Pull up the evaporator by holding it at the lower side. Insert a screwdriver through the space between the evaporator and drain chute and loosen the fan lock screw to remove the fan and fan motor.





Fig. 7

## PARTS LIST AND DIAGRAM

## INDOOR UNIT

MODEL: RAK-18NH6AS, RAK-18NH6A, RAK-25NH6A, RAK-35NH6A, RAK-50NH6A



**MODEL RAK-18NH6AS**

NO.	PART NO. RAK-18NH6AS	Q'TY / UNIT	PARTS NAME
1	PMRAS-07GH4 901	1	CABINET
4	PMRAS-25YH4 S04	1	FAN MOTOR
6	PMRAS-260GA R01	1	TANGENTIAL AIR FLOW FAN
7	PMRAS-25YH4 908	1	FAN SUPPORT ASSEMBLY
8	PMRAS-25YH4 909	1	FAN COVER
9	PMRAS-25YH4 910	1	FAN MOTOR SUPPORT
10	PMRAS-07GH4 R02	1	CYCLE ASSY
13	PMRAK-25NH6 002	1	PIPE SUPPORT
14	PMRAS-25YH4 S15	1	SPRING
16	PMRAS-25YH4 S17	1	TERMINAL BOARD (2P)
18	PMRAS-260GHA R01	1	THERMISTOR ASSEMBLY
20	PMRAK-18NH6AS R01	1	P.W.B (MAIN) & RECEIVER
25	PMRAS-25YH4 S26	1	DRAIN PAN ASSY
28	PMRAS-25YH4 S29	1	AUTO SWEEP MOTOR
32	PMRAK-18NH6 002	1	FRONT COVER ASSEMBLY
35	PMRAK-18NH6 003	1	FRONT PANEL
36	PMRAK-18NH6 004	1	AIR FILTER (R)
37	PMRAK-18NH6 005	1	AIR FILTER (L)
38	PMRAS-25YH4 950	1	LOWER COVER
39	PMRAS-25YH4 S40	1	MOUNTING PLATE
40	PMRAS-10C3M 003	1	REMOTE CONTROL SUPPORT
42	PMRAK-18NH6A R02	1	REMOTE CONTROL ASSEMBLY

**MODEL RAK-18NH6A**

<b>NO.</b>	<b>PART NO. RAK-18NH6A</b>	<b>Q'TY / UNIT</b>	<b>PARTS NAME</b>
1	PMRAS-07GH4 901	1	CABINET
4	PMRAS-25YH4 S04	1	FAN MOTOR
6	PMRAS-260GA R01	1	TANGENTIAL AIR FLOW FAN
7	PMRAS-25YH4 908	1	FAN SUPPORT ASSEMBLY
8	PMRAS-25YH4 909	1	FAN COVER
9	PMRAS-25YH4 910	1	FAN MOTOR SUPPORT
10	PMRAS-07GH4 R02	1	CYCLE ASSY
13	PMRAK-25NH6 002	1	PIPE SUPPORT
14	PMRAS-25YH4 S15	1	SPRING
16	PMRAS-25YH4 S17	1	TERMINAL BOARD (2P)
18	PMRAS-260GHA R01	1	THERMISTOR ASSEMBLY
20	PMRAK-18NH6A R01	1	P.W.B (MAIN) & RECEIVER
25	PMRAS-25YH4 S26	1	DRAIN PAN ASSY
28	PMRAS-25YH4 S29	1	AUTO SWEEP MOTOR
32	PMRAK-18NH6 002	1	FRONT COVER ASSEMBLY
35	PMRAK-18NH6 003	1	FRONT PANEL
36	PMRAK-18NH6 004	1	AIR FILTER (R)
37	PMRAK-18NH6 005	1	AIR FILTER (L)
38	PMRAS-25YH4 950	1	LOWER COVER
39	PMRAS-25YH4 S40	1	MOUNTING PLATE
40	PMRAS-10C3M 003	1	REMOTE CONTROL SUPPORT
42	PMRAK-18NH6A R02	1	REMOTE CONTROL ASSEMBLY

**MODEL RAK-25NH6A**

NO.	PART NO. RAK-25NH6A	Q'TY / UNIT	PARTS NAME
1	PMRAS-07GH4 901	1	CABINET
4	PMRAS-25YH4 S04	1	FAN MOTOR
6	PMRAS-260GA R01	1	TANGENTIAL AIR FLOW FAN
7	PMRAS-25YH4 908	1	FAN SUPPORT ASSEMBLY
8	PMRAS-25YH4 909	1	FAN COVER
9	PMRAS-25YH4 910	1	FAN MOTOR SUPPORT
10	PMRAK-25NH5 R02	1	CYCLE ASSY
13	PMRAK-25NH6 002	1	PIPE SUPPORT
14	PMRAS-25YH4 915	1	SPRING
16	PMRAS-25YH4 917	1	TERMINAL BOARD (2P)
18	PMRAS-260GHA R01	1	THERMISTOR ASSEMBLY
20	PMRAK-25NH6A R01	1	P.W.B (MAIN) & RECEIVER
25	PMRAS-25YH4 S26	1	DRAIN PAN ASSY
28	PMRAS-25YH4 S29	1	AUTO SWEEP MOTOR
32	PMRAK-18NH6 002	1	FRONT COVER ASSEMBLY
35	PMRAK-18NH6 003	1	FRONT PANEL
36	PMRAK-18NH6 004	1	AIR FILTER (R)
37	PMRAK-18NH6 005	1	AIR FILTER (L)
38	PMRAS-25YH4 950	1	LOWER COVER
39	PMRAS-25YH4 S40	1	MOUNTING PLATE
40	PMRAS-10C3M 003	1	REMOTE CONTROL SUPPORT
42	PMRAK-18NH6A R02	1	REMOTE CONTROL ASSEMBLY

**MODEL RAK-35NH6A**

<b>NO.</b>	<b>PART NO. RAK-35NH6A</b>	<b>Q'TY / UNIT</b>	<b>PARTS NAME</b>
1	PMRAS-07GH4 901	1	CABINET
4	PMRAS-25YH4 S04	1	FAN MOTOR
6	PMRAS-260GA R01	1	TANGENTIAL AIR FLOW FAN
7	PMRAS-25YH4 908	1	FAN SUPPORT ASSEMBLY
8	PMRAS-25YH4 909	1	FAN COVER
9	PMRAS-25YH4 910	1	FAN MOTOR SUPPORT
10	PMRAK-25NH5 R02	1	CYCLE ASSY
13	PMRAK-25NH6 002	1	PIPE SUPPORT
14	PMRAS-25YH4 S15	1	SPRING
16	PMRAS-25YH4 S17	1	TERMINAL BOARD (2P)
18	PMRAS-260GHA R01	1	THERMISTOR ASSEMBLY
20	PMRAK-35NH6A R01	1	P.W.B (MAIN) & RECEIVER
25	PMRAS-25YH4 S26	1	DRAIN PAN ASSY
28	PMRAS-25YH4 S29	1	AUTO SWEEP MOTOR
32	PMRAK-18NH6 002	1	FRONT COVER ASSEMBLY
35	PMRAK-18NH6 003	1	FRONT PANEL
36	PMRAK-18NH6 004	1	AIR FILTER (R)
37	PMRAK-18NH6 005	1	AIR FILTER (L)
38	PMRAS-25YH4 950	1	LOWER COVER
39	PMRAS-25YH4 S40	1	MOUNTING PLATE
40	PMRAS-10C3M 003	1	REMOTE CONTROL SUPPORT
42	PMRAK-18NH6A R02	1	REMOTE CONTROL ASSEMBLY

**MODEL RAK-50NH6A**

NO.	PART NO. RAK-50NH6A	Q'TY / UNIT	PARTS NAME
1	PMRAS-07GH4 901	1	CABINET
4	PMRAS-25YH4 S04	1	FAN MOTOR
6	PMRAS-260GA R01	1	TANGENTIAL AIR FLOW FAN
7	PMRAS-25YH4 908	1	FAN SUPPORT ASSEMBLY
8	PMRAS-25YH4 909	1	FAN COVER
9	PMRAS-25YH4 910	1	FAN MOTOR SUPPORT
10	PMRAS-19SH4 R01	1	CYCLE ASSY
13	PMRAK-25NH6 002	1	PIPE SUPPORT
14	PMRAS-25YH4 S15	1	SPRING
16	PMRAS-25YH4 S17	1	TERMINAL BOARD (2P)
18	PMRAS-260GHA R01	1	THERMISTOR ASSEMBLY
20	PMRAK-50NH6A R01	1	P.W.B (MAIN) & RECEIVER
25	PMRAS-25YH4 S26	1	DRAIN PAN ASSY
28	PMRAS-25YH4 S29	1	AUTO SWEEP MOTOR
32	PMRAK-18NH6 002	1	FRONT COVER ASSEMBLY
35	PMRAK-18NH6 003	1	FRONT PANEL
36	PMRAK-18NH6 004	1	AIR FILTER (R)
37	PMRAK-18NH6 005	1	AIR FILTER (L)
38	PMRAS-25YH4 950	1	LOWER COVER
39	PMRAS-25YH4 S40	1	MOUNTING PLATE
40	PMRAS-10C3M 003	1	REMOTE CONTROL SUPPORT
42	PMRAK-18NH6A R02	1	REMOTE CONTROL ASSEMBLY

# HITACHI

---

**RAK-18NH6AS**  
**RAK-18NH6A**  
**RAK-25NH6A**  
**RAK-35NH6A**  
**RAK-50NH6A**

**PM NO. 0489E**

Printed in Malaysia