
HITACHI Inspire the Next

SERVICE MANUAL TECHNICAL INFORMATION

FOR SERVICE PERSONNEL ONLY





NO. 0465E

PM

RAS-70YH7/RAC-70YH7

REFER TO THE FOUNDATION MANUAL

CONTENTS

CAUTION	4
SPECIFICATIONS	5
INSTALLATION	6
HOW TO USE	7
CONSTRUCTION AND DIMENSIONAL DIAGRAM	29
MAIN PARTS COMPONENT	31
WIRING DIAGRAM	33
CIRCUIT DIAGRAM	35
PRINTED WIRING BOARD LOCATION DIAGRAM	41
BLOCK DIAGRAM	44
BASIC MODE	45
REFRIGERATING CYCLE DIAGRAM	59
DESCRIPTION OF MAIN CIRCUIT OPERATION	61
SERVICE CALL Q & A	74
TROUBLE SHOOTING	78
PARTS LIST AND DIAGRAM	98

SPECIFICATIONS

ТҮРЕ		(WALL TYPE)			
			INDOOR UNIT	OUTDOOR UNIT	
MODEL			RAS-70YH7	RAC-70YH7	
POWER S	OURCE		1 Ø, 50/60 Hz, 220-240V		
	TOTAL INPUT	(W)	2,170 (200	0 – 2,820)	
COOLING	TOTAL AMPERES	(A)	9.9	95	
COOLING	CAPACITY	(kW)	7.00 (1.5	0 - 8.00)	
		(B.T.U./h)	23,900 (5,120 – 27,315)		
	TOTAL INPUT	(W)	2,200 (200 – 2,970)		
HEATING	TOTAL AMPERES	(A)	10.10		
HEATING	CAPACITY	(kW)	8.00 (1.50 - 9.20)		
		(B.T.U./h)	27,300 (5.11	9 – 31,396)	
DIMENSIONS		W	1150	850	
		Н	333	800	
(mm)	(mm) D		245	298	
NET WEIGHT (kg)		15	55		

※ After installation

SPECIFICATIONS AND PARTS ARE SUBJECT TO CHANGE FOR IMPROVEMENT


ROOM AIR CONDITIONER

INDOOR UNIT + OUTDOOR UNIT

JANUARY 2010 Refrigeration & Air-Conditioning Division

SAFETY DURING REPAIR WORK

1. In order to disassemble and repair the unit in question, be sure to disconnect the power cord plug from the power outlet before starting the work.



2. If it is necessary to replace any parts, they should be replaced with respective genuine parts for the unit, and the replacement must be effected in correct manner according to the instructions in the Service Manual of the unit.

If the contacts of electrical parts are defective, replace the electrical parts without trying to repair them.

- 3. After completion of repairs, the initial state should be restored.
- 4. Lead wires should be connected and laid as in the initial state.
- 5. Modification of the unit by user himself should absolutely be prohibited.



- 6. Tools and measuring instruments for use in repairs or inspection should be accurately calibrated in advance.
- 7. In installing the unit having been repaired, be careful to prevent the occurence of any accident such as electrical shock, leak of current, or bodily injury due to the drop of any part.
- 8. To check the insulation of the unit, measure the insulation resistance between the power cord plug and grounding terminal of the unit. The insulation resistance should be $1M\Omega$ or more as measured by a 500V DC megger.
- The initial location of installation such as window, floor or the other should be checked for being and safe enough to support the repaired unit again.
 If it is found not so strong and safe, the unit should be installed at the initial location reinforced or at a new location.
- 10. Any inflammable thing should never be placed about the location of installation.
- 11. Check the grounding to see whether it is proper or not, and if it is found improper, connect the grounding terminal to the earth.



WORKING STANDARDS FOR PREVENTING BREAKAGE OF SEMICONDUCTORS

1. Scope

The standards provide for items to be generally observed in carrying and handling semiconductors in relative manufacturers during maintenance and handling thereof. (They apply the same to handling of abnormal goods such as rejected goods being returned).

- 2. Object parts
 - (1) Micro computer
 - (2) Integrated circuits (IC)
 - (3) Field-effect transistors (FET)
 - (4) P.C. boards or the like on which the parts mentioned in (1) and (2) of this paragraph are equipped.
- 3. Items to be observed in handling
 - (1) Use a conductive container for carrying and storing of parts. (Even rejected goods should be handled in the same way).




Fig. 1. Conductive Container

- (2) When any part is handled uncovered (in counting, packing and the like), the handling person must always use himself as a body earth. (Make yourself a body earth by passing one M ohm earth resistance through a ring or bracelet).
- (3) Be careful not to touch the parts with your clothing when you hold a part even if a body earth is being taken.
- (4) Be sure to place a part on a metal plate with grounding.
- (5) Be careful not to fail to turn off power when you repair the printed circuit board. At the same time, try to repair the printed circuit board on a grounded metal plate.




Fig. 2. Body Earth

(6) Use a three wire type soldering iron including a grounding wire.




Fig. 3. Grounding of the working table




Fig. 4. Grounding a soldering iron


Use a high insulation mode (100V, $10M\Omega$ or higher) when ordinary iron is to be used.

(7) In checking circuits for maintenance, inspection or some others, be careful not to have the test probes of the measuring instrument shortcircuit a load circuit or the like.

- 1. In quiet or stop operation, slight flowing noise of refrigerant in the refrigerating cycle is heard occasionally, but this noise is not abnormal for the operation.
- 2. When it thunders near by, it is recommended to stop the operation and to disconnect the power cord plug from the power outlet for safety.
- 3. In the event of power failure, the airconditioner will restart automatically in the previously selected mode once the power is restored. In the event of power failure during TIMER operation, the timer will be reset and the unit will begin or stop operating under a new timer setting.
- 4. If the room air conditioner is stopped by adjusting thermostat, or missoperation, and re-start in a moment, there is occasion that the cooling and heating operation does not start for 3 minutes, it is not abnormal and this is the result of the operation of IC delay circuit. This IC delay circuit ensures that there is no danger of blowing fuse or damaging parts even if operation is restarted accidentally.
- This room air conditioner should not be used at the cooling operation when the outside temperature is below −10°C (14°F).
- This room air conditioner (the reverse cycle) should not be used when the outside temperature is below -15°C (5°F).
 If the reverse cycle is used under this condition, the outside heat exchanger is frosted and efficiency falls.
- 7. When the outside heat exchanger is frosted, the frost is melted by operating the hot gas system, it is not trouble that at this time fan stops and the vapour may rise from the outside heat exchanger.

SPECIFICATIONS

MODEL		RAS-70YH7	RAC-70YH7	
FAN MOTOR		30 W	47 W	
FAN MOTOR CAPACITOR		NO	NO	
FAN MOTOR PROTECTOR		NO	NO	
COMPRESSOR		_	JU1015D9	
COMPRESSOR MOTOR CAP	ACITOR	NO	NO	
OVERLOAD PROTECTOR		NO	NO	
OVERHEAT PROTECTOR		NO	YES	
FUSE (MICRO COMPUTER C	CIRCUIT)	3.15A	NO	
POWER RELAY		G4A	G4A	
POWER SWITCH		NO	NO	
TEMPORARY SWITCH		YES	NO	
TEST/SERVICE SWITCH		NO	YES	
TRANSFORMER		NO	NO	
VARISTOR		416NR	450NR	
NOISE SUPPRESSOR		NO	NO	
THERMOSTAT		YES(IC)	YES(IC)	
REMOTE CONTROL SWITCH (LIQUID CRYSTAL)		YES	NO	
FUSE CAPACITY		30 A TIME DELAY FUSE		
REFRIGERANT CHARGING	UNIT		₩ 1850g	
VOLUME (Refrigerant R410A)	PIPES (MAX. 30m) (MIN. 3m)	CHAR	GELESS	




INDOOR UNIT AIR FILTER To prevent dust from coming into the indoor unit. (Refer Instruction manual) FRONT PANEL (AIR INLET). **INDOOR UNIT INDICATORS** Light indicator showing the operating condition. (Refer page 8) HORIZONTAL DEFLECTOR • VERTICAL **DEFLECTOR (AIR OUTLET)** (Refer Instruction manual) **REMOTE CONTROLLER** Send out operation signal to the indoor unit. So Ø as to operate the whole unit. 008 (Refer Instruction manual) ĉ

NOTE

- Air cleansing filters are not washable and can be use in 1 year time. Type number for this air cleansing filter is <SPX-CFH12>. Please use this number for ordering when you want to renew it.
- Air cleansing filter should be cleaned every month or sooner if noticeable loading occurs. When used overtime, it may loose its deodorizing function. For maximum performance, it is recommended to replace it every 1 year depending on application requirements.

OUTDOOR UNIT



DRAIN PIPE Condensed water drain to outside.


AIR INLET (BACK, LEFT SIDE)

AIR OUTLET

MODEL NAME AND DIMENSIONS

MODEL	WIDTH (mm)	HEIGHT (mm)	DEPTH (mm)
RAS-70YH7	1150	333	245
RAC-70YH7	850	800	298

INDOOR UNIT INDICATORS



TIMER LAMP

This lamp lights when the timer is working.

OPERATION LAMP

This lamp lights during operation.

The OPERATION LAMP flashes in the following cases during heating.

(1) During preheating


For about 2–3 minutes after starting up.

(2) During defrosting

Defrosting will be performed about once an hour when frost forms on the heat exchanger of the outdoor unit, for 5–10 minutes each time.

FILTER LAMP

When the device is operated for a total of about 200 hours, the FILTER lamp lights to indicate that it is time to clean the filter. The lamp goes out when the " $\underbrace{\times}$ (AUTO SWING)" button is pressed while the device is on "STANDBY MODE".



TEMPORARY SWITCH

Use this switch to start and stop when the remote controller does not work. [Use non-conductor stick (example: toothpick)]

- By pressing the temporary switch, the operation is done in previously set operation mode.
- When the operation is done using the temporary switch after the power source is turned off and turn on again, the operation is done in automatic mode.

Note

 Avoid to use the room air conditioner for cooling operation when the outside temperature is below -10°C (14°F).

The recommended maximum and minimum operating temperatures of the hot and cold sides should be as below:


		Cooling		Heating	
-		Minimum	Maximum	Minimum	Maximum
Indoor	Dry bulb °C	21	32	20	27
	Wet bulb °C	15	23	12	19
Outdoor	Dry bulb °C	21	43	2	21
	Wet bulb °C	15	26	1	15

MEMO



SAFETY PRECAUTION

- Please read the "Safety Precaution" carefully before operating the unit to ensure correct usage of the unit.
- Pay special attention to signs of "A Warning" and "A Caution". The "Warning" section contains matters which, if not observed strictly, may cause death or serious injury. The "Caution" section contains matters which may result in serious consequences if not observed properly. Please observe all instructions strictly to ensure safety.
- The sign indicate the following meanings.



• Please keep this manual after reading.

PRECAUTIONS DURING INSTALLATION • Do not reconstruct the unit. Water leakage, fault, short circuit or fire may occur if you reconstruct the unit by vourself. • Please ask your sales agent or qualified technician for the installation of your unit. Water leakage, short circuit or fire may occur if you install the unit by yourself. • Please use earth line. WARNING Do not place the earth line near water or gas pipes, lightning-conductor, or the earth line of telephone. Improper installation of earth line may cause electric shock. • Be sure to use the specified piping set for R410A. Otherwise, this may result in broken copper pipes or faults. • A circuit breaker should be installed depending on the mounting site of the unit. Without a circuit breaker, the danger of electric shock exists. • Do not install near location where there is flammable gas. The outdoor unit may CAUTION catch fire if flammable gas leaks around it. • Please ensure smooth flow of water when installing the drain hose. PRECAUTIONS DURING SHIFTING OR MAINTENANCE Should abnormal situation arises (like burning smell), please stop operating the unit and turn off the circuit breaker. Contact your agent. Fault, short circuit or fire may Â occur if you continue to operate the unit under abnormal situation. W Please contact your agent for maintenance. Improper self maintenance may cause Α electric shock and fire. R Ν • Please contact your agent if you need to remove and reinstall the unit. Electric

- shock or fire may occur if you remove and reinstall the unit yourself improperly.
- If the supply cord is damaged, it must be replaced by the special cord obtainable at authorized service/parts centers.

PRECAUTIONS DURING OPERATION

• Avoid an extended period of direct air flow for your health.

W A R N I S

Т

Ν

G

- Do not insert a finger, a rod or other objects into the air outlet or inlet. As the fan is rotating at a high speed, it will cause injury. Before cleaning, be sure to stop the operation and turn the breaker OFF.
- Do not use any conductor as fuse wire, this could cause fatal accident.



• During thunder storm, disconnect and turn off the circuit breaker.

PRECAUTIONS DURING OPERATION

• The product shall be operated under the manufacturer specification and not for any other intended use.





- Do not attempt to operate the unit with wet hands, this could cause fatal accident.
- When operating the unit with burning equipments, regularly ventilate the room to avoid oxygen insufficiency.





• Do not direct the cool air coming out from the air-conditioner panel to face household heating apparatus as this may affect the working of apparatus such as the electric kettle, oven etc.

• Please ensure that outdoor mounting frame is always stable, firm and without defect. If not, the outdoor unit may collapse and cause danger.





• Do not splash or direct water to the body of the unit when cleaning it as this may cause short circuit.

• Do not use any aerosol or hair sprays near the indoor unit. This chemical can adhere on heat exchanger fin and blocked the evaporation water flow to drain pan. The water will drop on tangential fan and cause water splashing out from indoor unit.





44

C A

U

T I O

Ν

• Please switch off the unit and turn off the circuit breaker during cleaning, the high-speed fan inside the unit may cause danger.

• Turn off the circuit breaker if the unit is not to be operated for a long period.





• Do not climb on the outdoor unit or put objects on it.

• Do not put water container (like vase) on the indoor unit to avoid water dripping into the unit. Dripping water will damage the insulator inside the unit and causes short-circuit.





- Do not place plants directly under the air flow as it is bad for the plants.
- When operating the unit with the door and windows opened, (the room humidity is always above 80%) and with the air deflector facing down or moving automatically for a long period of time, water will condense on the air deflector and drips down occasionally. This will wet your furniture. Therefore, do not operate under such condition for a long time.
- If the amount of heat in the room is above the cooling or heating capability of the unit (for example: more people entering the room, using heating equipments and etc.), the preset room temperature cannot be achieved.
- This appliance is not intended for use by young children or infirm persons unless they have been adequately supervised by a responsible person to ensure that they can use the appliance safely.
 Young children should be supervised to ensure that they do not play with the appliance.

REMOTE CONTROLLER

TIMER SELECTOR

PARALLEL SWING

SYMMETRY SWING

ON TIMER

OFF TIMER


Ð

(Ŧ)

11

 \land

- This controls the operation of the indoor unit. The range of control is about 7 meters. If indoor lighting is controlled electronically, the range of control may be shorter. This unit can be fixed on a wall using the fixture provided. Before fixing it, make sure the indoor unit can be controlled from the remote controller.
- Handle the remote controller with care. Dropping it or getting it wet may compromise its signal transmission capability.
- After new batteries are inserted into the remote controller, the unit will initially require approximately 10 seconds to respond to commands and operate.



If you press the FUNCTION selector button during operation, the device may stop for about 3 minutes for protection.


VARIOUS FUNCTIONS

Auto Restart Control


- If there is a power failure, operation will be automatically restarted when the power is resumed with previous operation mode and airflow direction.
- (As the operation is not stopped by remote controller.)
- If you intend not to continue the operation when the power is resumed, switch off the power supply.
 When you switch on the circuit breaker, the operation will be automatically restarted with previous operation mode and airflow direction.
 - Note: 1. If you do not require Auto Restart Control, please consult your sales agent or OFF by remote control.
 - 2. Auto Restart Control is not available when Timer or Sleep Timer mode is set.

AUTOMATIC OPERATION

The device will automatically determine the mode of operation, HEAT, COOL or DEHUMIDIFY depending on the current room temperature. The selected mode of operation will change when the room temperature varies. However the mode of operation will not change when indoor unit connected to multi type outdoor unit.



- Use the device for heating when the outdoor temperature is under 21°C.
- When it is too warm (over 21°C), the heating function may not work in order to protect the device.
- In order to keep reliability of the device, please use this device above -15°C of the outdoor temperature.



Defrosting


Defrosting will be performed about once an hour when frost forms on the heat exchange of the outdoor unit, for $5 \sim 10$ minutes each time.

During defrosting operation, the operation lamp blinks in cycle of 3 seconds on and 0.5 second off. The maximum time for defrosting is 20 minutes.

However, if it is connected to multi type outdoor unit, the maximum time for defrosting is 15 minutes. (If the piping length used is longer than usual, frost will likely to form.)

DEHUMIDIFYING OPERATION

Use the device for dehumidifying when the room temperature is over 16° C. When it is under 15° C, the dehumidifying function will not work.




- When the room temperature is higher than the temperature setting: The device will dehumidify the room, reducing the room temperature to the preset level. When the room temperature is lower than the temperature setting: Dehumidifying will be performed at the temperature setting slightly lower than the current room temperature, regardless of the temperature setting. The function will stop (the indoor unit will stop emitting air) as soon as the room temperature becomes lower than the setting temperature.
- The preset room temperature may not be reached depending on the number of people present in the room or other room conditions.

COOLING OPERATION

Use the device for cooling when the outdoor temperature is -10° C~ 43° C. If in doors humidity is very high (80%), some dew may form on the air outlet grille of the indoor unit.

	Press the FUNCTION selector so that the display indicates
	Set the desired FAN SPEED with the # (FAN SPEED) button (the display indicates the setting).
	(AUTO) : The FAN SPEED is HI at first and varies to MED or LOW automatically when the preset temperature has been reached.
	(HI) : Economical as the room will become cool quickly.
	(MED) : Fan speed slow.
	🖹 (LOW) : Fan speed slower.
	(SILENT) : Fan speed ultra slower.
	Set the desired room temperature with the TEMPERATURE button (the display indicates the setting). The temperature setting and the actual room temperature may vary some how depending on conditions.
START STOP	Press the ① (START/STOP) button. Cooling operation starts with a beep. Press the button again to stop operation. The cooling function does not start if the temperature setting is higher than the current room temperature (even though the ① (OPERATION) lamp lights). The cooling function will start as soon as you set the temperature below the current room temperature.
	s the settings are stored in memory in the remote controller, you only ave to press the $①$ (START/STOP) button next time.


You can use the device simply as an air circulator. Use this function to dry the interior of the indoor unit at the end of summer.



FAN SPEED (AUTO) When the AUTO fan speed mode is set in the cooling/heating operation:

For the heating operation	 When the difference of room temperature and setting temperature is large, fan starts to run at HI speed. After room temperature reaches the preset temperature, the heating operation, which changes the fan speed and room temperature to obtain optimum conditions for natural healthful heating will be performed.
For the cooling operation	 When the difference of room temperature and setting temperature is large, fan starts to run at HI speed. After room temperature reaches the preset temperature, the cooling operation, which changes the fan speed and room temperature to obtain optimum conditions for natural healthful cooling will be performed.

HOW TO SET THE TIMER



How to Cancel Reservation

Point the signal window of the remote controller toward the indoor unit, and press the \bigcirc (CANCEL) button.

The ⊕ (RESERVED) sign goes out with a beep and the ⊕ (TIMER) lamp turns off on the indoor unit.

NOTE


You can set only one of the OFF-timer, ON-timer and ON/OFF-timer.

rol button. The time indication star instead of flashing.	button again. ts lighting
	 The time indication will disappear automatically in 10 second. To check the current time setting, press the ① (TIME) button twice.
ple: The current time is 1:30 p.m.	The setting of the current time is now complete.
3 Point the signal window of the remote contr press the I (RESERVE) button. The ($\stackrel{1}{\bigcirc}$ (OFF) mark starts lighting instead of flash lights. A beep occurs and the ($\stackrel{1}{\bigcirc}$ (TIMER) lamp $\stackrel{1}{\bigcirc}$ $\stackrel{1}{\bigcirc}$ $\stackrel{1}{\bigcirc}$ $\stackrel{1}{\bigcirc}$ $\stackrel{1}{\bigcirc}$ $\stackrel{1}{\bigcirc}$ $\stackrel{1}{\bigcirc}$ Exar The setting of turn-off time is now	ning and the sign (i) (RESERVED) o lights on the indoor unit. nple: The device will turn off at 11:00p.m.
3 Point the signal window of the remote contropress the (RESERVE) button.	roller toward the indoor unit, and
The \textcircled{O} (ON) mark starts lighting instead of flasing lights. A beep occurs and the \textcircled{O} (TIMER)	
Example: The device will tu The setting of the	rn on at 7:00 a.m. e turn-on time is now complete.
5 Point the signal window of the remote cont	roller toward the indoor unit, and
press the (RESERVE) button.	
The (1) (ON) mark starts lighting instead of flasign lights. A beep occurs and the (2) (TIMER	•
ن 🕂 🔶 🚽 🕐 at 7:00 a.m.	rn off at 10:30 p.m. and it will be turned on e turn-on/off times are now complete.
	 J → ↔ → → → → → → → → → → → → → → → → →

- The timer may be used in three ways: off-timer, on-timer, and ON/OFF (OFF/ON)-timer. Set the current time at first because it serves as a reference.
- As the time settings are stored in memory in the remote controller, you only have to press the I (RESERVE) button in order to use the same settings next time.

HOW TO SET THE SLEEP TIMER

Set the current time at first if it is not set before (see the pages for setting the current time). Press the \star (SLEEP) button, and the display changes as shown below.



How to Cancel Reservation

Point the signal window of the remote controller toward the indoor unit, and press the \bigcirc (CANCEL) button.

The O (RESERVED) sign goes out with a beep and the O (TIMER) lamp turns off on the indoor unit.

HOW TO EXCHANGE THE BATTERIES IN THE REMOTE CONTROLLER




Remove the cover as shown in the figure and take out the old batteries.

Install the new batteries.
 The direction of the batteries should match the marks in the case.

A CAUTION

- 1. Do not use new and old batteries, or different kinds of batteries together.
- 2. Take out the batteries when you do not use the remote controller for 2 or 3 months.




TEMPORARY SWITCH

- If the remote controller does not work due to battery failure, press this switch to start and stop operation.
- This temporary operation will be at the setting made most recently. (The unit will immediately go into automatic operation once power is switched on.)

CIRCUIT BREAKER

When you do not use the room air conditioner, set the circuit breaker to "OFF".



Install curtain or blinds It is possible to reduce heat entering the room through windows.

Ventilation

A Caution

Do not close the room for a long period of time. Occasionally open the door and windows to allow the

entrance of fresh air.



Effective Usage Of Timer

At night, please use the "OFF or ON timer operation mode", together with your wake up time in the morning. This will enable you to enjoy a comfortable room temperature. Please use the timer effectively.



Do Not Forget To Clean The Air Filter

Dusty air filter will reduce the air volume and the cooling efficiency. To prevent from wasting electric energy, please clean the filter every 2 weeks.



Please Adjust Suitable Temperature For Baby And Children

Please pay attention to the room temperature and air flow direction when operating the unit for baby, children and old folks who have difficulty in movement.




FOR USER'S INFORMATION

The Air Conditioner And The Heat Source In The Room


A Caution

If the amount of heat in the room is above the cooling capability of the air conditioner (for example: more people entering the room, using heating equipments and etc.), the preset room temperature cannot be achieved.



Not Operating For A Long Time


When the indoor unit is not to be used for a long period of time, please switch off the power from the mains. If the power from mains remains "ON", the indoor unit still consumes about 8W in the operation control circuit even if it is in "OFF" mode.



When Lightning Occurs

A Warning


To protect the whole unit during lightning, please stop operating the unit and remove the plug from the socket.



Interference From Electrical Products

A Caution

To avoid noise interference, please place the indoor unit and its remote controller at least 1m away from electrical products.





Cleaning and maintenance must be carried out only by qualified service personal. Before cleaning, stop operation and switch off the power supply.




Open the front panel.

Remove the filter.

filter.

• Pull up the front panel by holding it at both sides with both hands.






Attaching the air cleansing filters to the filter.

• Attach the air cleansing filters to the frame by gently compress its both sides and release after insertion into filter frame.

Push upward to release the claws and pull out the





Do not bend the air cleansing filter as it may cause damage to the structure.








Attach the filters.

- Attach the filters by ensuring that the surface written "FRONT" is facing front.
- After attaching the filters, push the front panel at three arrow portion as shown in figure and close it.



NOTE

- In case of removing the air cleansing filters, please follow the above procedures.
- The cooling capacity is slightly weakened and the cooling speed becomes slower when the air cleansing filters are used. So, set the fan speed to "HIGH" when using it in this condition.
- Do not operate the air conditioner without filter. Dust may enter the air conditioner and fault may occur.



MAINTENANCE

Cleaning and maintenance must be carried out only by qualified service personal. Before cleaning, stop operation and switch off the power supply.

1. AIR FILTER I

Clean the air filter, as it removes dust inside the room. In case the air filter is full of dust, the air flow will decrease and the cooling capacity will be reduced. Further, noise may occur. Be sure to clean the filter following the procedure below.

PROCEDURE


Open the front panel and remove the filter
 Gently lift and remove the air cleansing filter from the air filter frame.

Vacuum dust from the air filter and air cleansing filter using vacuum cleaner. If there is too much dust, air filter only rinse under running tap water and gently brush it with soft bristle brush. Allow filters to dry in shade.



• Re-insert the air cleansing filter to the filter frame. Set the filter with "FRONT" mark facing front, and slot them into the original state.

• After attaching the filters, push the front panel at three arrow portions as shown in figure and close it.



- Do not wash with hot water at more than 40°C. The filter may shrink.
- When washing it, shake off moisture completely and dry it in the shade; do not expose it directly to the sun. The filter may shrink.
- Do not use detergent on the air cleansing filter as some detergent may deteriorate the filter electrostatic performance.

2. Washable Front Panel


• Remove the front panel and wash with clean water.

Wash it with a soft sponge. After using neutral detergent, wash thoroughly with clean water.

- When front panel is not removed, wipe it with a soft dry cloth. Wipe the remote controller thoroughly with a soft dry cloth.
- Wipe the water thoroughly. If water remains at indicators or signal receiver of indoor unit, it causes trouble.

Method of removing the front panel. Be sure to hold the front panel with both hands to detach and attach it.

Removing the Front Panel



- When the front panel is fully opened with both hands, push the right arm to the inside to release it, and while closing the front panel slightly, put it out forward.
- Attaching the Front Panel
 - Move the projections of the left and right arms into the **Flanges** in the unit and securely insert them into the holes.

- Do not splash or direct water to the body of the unit when cleaning it as this may cause short circuit.
- Never use hot water (above 40°C), benzine, gasoline, acid, thinner or a brush, because they will damage the plastic surface and the coating.



A CAUTION

Cleaning and maintenance must be carried out only by qualified service personal. Before cleaning, stop operation and switch off the power supply.

3. MAINTENANCE AT BEGINNING OF LONG OFF PERIOD Running the unit setting the operation mode to (FAN) and the fan speed to HI for about half a day on a fine day, and dry the whole of the unit. Switch off the power plug.

REGULAR INSPECTION

PLEASE CHECK THE FOLLOWING POINTS BY QUALIFIED SERVICE PERSONAL EITHER EVERY HALF YEARLY OR YEARLY. CONTACT YOUR SALES AGENT OR SERVICE SHOP.

1		Is the earth line disconnected or broken?
2		Is the mounting frame seriously affected by rust and is the outdoor unit tilted or unstable?
3	Confirm	Is the plug of power line firmly plugged into the socket? (Please ensure no loose contact between them).

AFTER SALE SERVICE AND WARRANTY

WHEN ASKING FOR SERVICE, CHECK THE FOLLOWING POINTS.

CONDITION	CHECK THE FOLLOWING POINTS
If the remote controller is not transmitting a signal. Remote controller display is dim or blank.)	 Do the batteries need replacement? Is the polarity of the inserted batteries correct?
When it does not operate	 Is the fuse all right? Is the voltage extremely high or low? Is the circuit breaker "ON"? Is the setting of operation mode different from other indoor units?
When it does not cool well When it does not hot well	 Is the air filter blocked with dust? Does sunlight fall directly on the outdoor unit? Is the air flow of the outdoor unit obstructed? Are the doors or windows opened, or is there any source of heat in the room? Is the set temperature suitable? Are the air inlets or air outlets of indoor and outdoor units blocked? Is the fan speed "LOW" or "SILENT"?

Notes


- In quiet operation or stopping the operation, the following phenomena may occassionally occur, but they are not abnormal for the operation.
 - (1) Slight flowing noise of refrigerant in the refrigerating cycle.
 - (2) Slight rubbing noise from the fan casing which is cooled and then gradually warmed as operation stops.
- The odor will possibly be emitted from the room air conditioner because the various odor, emitted by smoke, foodstuffs, cosmetics and so on, sticks to it. So the air filter and the evaporator regularly must be cleaned to reduce the odor.
- Please contact your sales agent immediately if the air conditioner still fails to operate normally after the above inspections. Inform your agent of the model of your unit, production number, date of installation. Please also inform him regarding the fault.
- Power supply shall be connected at the rated voltage, otherwise the unit will be broken or could not reach the specified capacity.

NOTE:

- If the supply cord is damaged, it must be replaced by the special cord obtainable at authorized service parts centers.
- On switching on the equipment, particularly when the room light is dimmed, a slight brightness fluctuation may occur. This is of no consequence.


The conditions of the local Power Supply Companies are to be observed.


CONSTRUCTION AND DIMENSIONAL DIAGRAM



Note:

- 1. Service space (free space needed for servicing) is 200mm on the right, 100mm on the left and 50mm on top.
- 2. The wide and narrow pipes must be thermally insulated.
- 3. Piping length is within 30m
- 4. Height different of the piping between the indoor unit and the outdoor unit should be within 20m.
- 5. Power supply cord length is about 2m
- 6. Connecting cable 2.5mm dia. x 3 (AB Line), 1.6mm dia. x 2 (CD Line) is used for the connection.





MAIN PARTS COMPONENT

THERMOSTAT (Room Temperature Thermistor)

Thermostat Specifications

MODEL			RAS-70YH7		
THERMOSTAT MODEL			IC		
OPERATION MODE			COOL	HEAT	
	INDICATION	ON	15.6 (60.1)	20.0 (68.0)	
TEMPERATURE °C (°F)	16	OFF	15.3 (59.5)	20.7 (69.3)	
	INDICATION 24	ON	23.6 (74.5)	28.0 (82.4)	
		OFF	23.3 (73.9)	28.7 83.7)	
	INDICATION	ON	31.6 (88.9)	36.0 (96.8)	
	32	OFF	31.3 (88.3)	36.7 (98.1)	

INDOOR FAN MOTOR

Fan Motor Specifications

MODEL	RAS-70YH7			
POWER SOURCE	DC: 100 ~ 322V			
OUTPUT	30W			
CONNECTION	$100 \sim 322V \circ \begin{array}{c} RED \\ 0V \circ \\ BLK \\ 0V \circ \\ WHT \\ 15V \circ \\ YEL \\ 0 \sim 6.5V \circ \\ BLU \\ FG \circ \\ BLU \\ FG \circ \\ (Control circuit built in) \\ \end{array}$			


OUTDOOR FAN MOTOR


Fan Motor Specifications

ITEM	MODEL	RAC-70YH7				
POWER SOURCE		DC: 120 ~ 380V				
OUTPUT	(W) MAX	47				
COIL		BLACK (W)				
RESISTANCE VALUE (Ω)	20°C 2M	U-V 35 \pm 2.5 V-W 35 \pm 2.5 W-U 35 \pm 2.5				
BLU : BLUE GRY : GRAY BLK : BLACK	YEL : YELLO ORN : ORANO PNK : PINK					


COMPRESSOR MOTOR

Compressor Motor Specifications







When the Air Conditioner has been operated for a long time with the capillary tubes clogged or crushed or with too little refrigerant, check the color of the refrigerant oil inside the compressor. If the color has been changed conspicuously, replace the compressor.



Remote Control





ounting f : compone : solder	ent side	Ξ	A : : R : : P : : C :	AXI/ RAD RAD HAN CHIF	NAL (7 Al (7 D INSI P SUI	.5mm Ert RFAC	MOUNTIN	١G
RES	IST	OF					<u>CAP</u>	
SYMBOL	(2)	TOL	POLER (W)	TYPE	FACE	REHWARK	SYMBOL	()
R003 R004	2.2 1M	5% 5%	5 1/4	H	A	ACR	C001 C002	0. 0
R101 R102 R103	620 1K 15K	3	1/10 1/10 1/10	C	88		C003 C004	<u>o</u>
R104 R105	2.2K	5%	1/10 1/10	C	8		C006 C101 C102	22
R106 R107	150K 330	1% 5%	1/10 1/4		AB		C103 C104	10
R108 R131 R132	1.2M 0.62	6 8	1 2	ΗP	A	ACR	C105 C106 C107	
R133 R134	1M 22	ăй	1/2 1/2	Ċ	B		C108 C110	ľ.
R135	750	١, يو	1/2		•		C111 C112	0.
R141	1K 5.1K	5% 5%	1/6 1/16	A C	A		C113 C114 C115	0.
R202 R203	5 X	멋엇	1/16 1/16		A		C116 C118	10 10
R204 R205	10K 2.7K	5X 5X	<u>1/16</u> 1/16		A		C131 C132 C133	4
R207	10K		1/16		A		C134	
R210 R211	1M 1K	5% 5%	<u>1/16</u> 1/6	C A	8		C201 C202	
R212 R221	47 390	5	1/6 1/4	AC	A		C203	6
R222 R232 R233	390 1K 390	5X 5X	1/4 1/10 1/8	C	A B A		C204 C205	
R234	1K	5%	1/16	C			C206 C207	
R301 R302	3.3K	5%	1/10 1/16	С	B		C208 C209	
R303 R307 R308	10K 1K 12•7K	5× 5× 1×	1/16 1/16 1/16	C C C	A A A		C211 C212	4
R309 R310	1K 12.7K	5X 1%	<u>1/16</u> 1/16	C C	A			
R311 R312 R313	10K 10K 10K	Ň	1/16 1/16 1/16	C	A		C231 C301 C302	10
R314 R315	10K 10K	ы М	1/16 1/16	С	Â		C303 C401	
R317	1K	5%	1/16	С	A		C501	10
R401 R402	390 390		1/16 1/16		A		C502 C503 C504	
R403 R404	5.1K 5.1K	ň	1/16 1/16	C C	A		C505	10
R409 R410 R411	5.1K 5.1K 10K	56	1/16 1/16 1/16	C C C	A		C601 C660	
R412 R413	10K 10K 5.1K	566	1/16 1/16	СC	Â		C701 C702	0. 6
R414	5.1K 4.3K	옛 성	1/16 1/4		A		C703 C704	0. 0.
R502 R503	4.3K 4.7K		1/10 1/8	C	8 8		C801 C802	15 0.
R504 R507	3.3K	5%	1/10 1/2 1/10	C	8		C808 C821	0. 0.
R508 R509 R510	10K 100 15K		1/10 1/10 1/10	C	B A B		C822 C823 C825	10 0.0 0.
R603	1K	5%	1/16	С	A		C826 C901	<u>م</u> \
R604 R609 R611	20K 1K 10K	555	1/16 1/16 1/16	C	A		C902 C903 C905	0. 0
							C906 C907	22
R619 R620	100 10K	5% 5%	1/10 1/16	C C	A		C910 C991 C992	0
R622 R623	10K 10K	ស័ត	1/16 1/16	C C	A		C993	0
R624	10K	57	1/16	C	A		C1101 C1102 C1103	10
R650 R654	10K 10K	ò	1/16 1/16	C	A		C1103 C1104 C1105	10
R655 R656	10K 10K	តត	1/16 1/16 1/16	C	A		C1106 C1107	, 0.
A660	1K	5	1/ 10	C	A		C1108 C1109	
R668	10K	ň			A		<u>COIL</u>	
R669 R701	10K 20K	16 16	1/16 1/6	C A	A A			EXI
R721 R723	240 180	5%	1/10 1/10	C C	A		L110 L111	EXI
R725 R726	240 240	5X 5X	1/10 1/10		A			EX
R803 R804	120K 120K	5% 5%	1/16 1/16	C	A			EXI
R805 R806 R807	120K 120K 4-3K	5% 5%	1/16 1/16 1/16	C	A A A			LB
R610 R611	680 2K	ыŅ	1/10 1/10 1/15 1/4	C C	A			
R812 R813 R821	39 39 470	줮줮줮	1/4	C C	A A A		T001	200
R622 R623	10K 10K	1% 1%	1/16 1/16	C	A		L1101 L1102	
R824 R825 R826	8-25K 10K 1K	1X 1X 5X	1/16 1/16 1/16	č	A A A		TRAN	
R827 R828	3K 10K	5%	1/16 1/16 1/16	C	A		Symbol	
R829 R830	5. 1K 1K		1/16 1/16		A		Q141 Q201	
R904 R905	1M 1M	5% 5%	1/2 1/2	C C	B		<u> </u>	
R906 R907	13K 2K	1% 1%	1/10 1/10	C C	8 8		6203 6204 6301	\vdash
R908 R909 R910	12K 220K 270K	1% 5% 5%	1/10 2 1/2	C P C	B A A		G502	E
R920 R996	10	8	1/2	Ź	A B	CFS	G503 G801	\vdash
R1101	10K	5%	1/10	С	A		G802 G803	E
R1102 R1103	1K 10K	5% 5%	1/10 1/10	C C	B		G821	E
R1104 R1105 R1106		555	1/10 1/16 1/6		B A B		Q1101	
R1107 R1108	150 2K	5% 5%	1/4 1/10	C C	AB		ZENN	١E
R1109 R1110 R1111	1K	5% 5%	1/10 1/4 1/10	C C	B A B		SYMBOL	
R1111 R1112	560	5%	1/10		8		ZD141 ZD202 ZD201	\vdash
						\square	ZD901	E
							ZD902	<u>ل</u>


Mounting face A: component side B: solder side

		~ ~ ~				
	1				mc	_
SYMBOL	(#F)			μuπ.		HEWR
C001 C002	0.68		F	P	Â	
C003	100	450	Ď	Ĥ	Â	КМН
C004	0.01	1000V	C	H	A	
C006 C101	220p 2200p	2000 AC250	C	PR	A	L
C102	470	ß	D	R	A	LXZ
C103 C104	1800 0-1	88	рu	H C	AB	LXZ
C105	0.1	25	Ċ	č	8	
C106	220	10	D	R	A	YXA
C107 C108	0.1	25	Ś	L C	B	
	0.01	1230	4	Р	Â	10 11
C111		ļ	1			
C112 C113	0.01 0.01	AC280 AC280	C C	PP	A	SON SON
C114						
	0.01 1000p	AC250 AC250	C	P	A	
C116 C118	10000		C	P	Â	58 M
C131	10	50	D	R		PF
	470p 22p	50 50	сu	C C	B	
	68	50	Ď	Ř	Â	LXZ
C201	10	16	D	R	A	
		10		<u> </u>	~	
C202 C203	0.1	25	C C	C C	B	
6203	0.1	25	U U		~	
C204	0.1	25	C	С	A	
C205	0.1	25	C	c	8	
	0.1	3 18	90	č	8	
C207	0.1	8	C	C	A	
C208 C209	0.1	25	C C	C C	B	1
C211 C212	47	16	≏∖	R	<u> </u>	<u> </u>
	4000	-		Ē	-	Ē
C231 C301	1000p 0.1	50 25	C C	C C	8 8	1
C302	0.1	25	C	C	B	
C303	0.1	25	CC	C	8	<u> </u>
		R	C	C	•	E
	10000	50	C	ç	8	
C502 C503	10 0.1	16 25	D C	RC	AB	КL
C504	0.1	8	C	C	8	
C505	10000	50	C	C	8	
C601	0.1	25	С	c	в	
C660	0.1	25	C	С	В	
C701	0. 15u	50	F	R	A	
C702	68/	50	Þ	R	Â	ω
	0.01	10250	00	P P	A	50 M. 50 M.
<u>C704</u>	0.01	<i>I</i> C250	с	۳	A	100 120
C801	150P	50	С	С	A	СН
C802 C808	0.22u 0.1u	50 25	F	R	A	F
C821	0.010	50	۶F	R	Â	F
C822 C823	10000		C	C C	A	B
	0-047u 0-1u	28	C C	C C	A	B
C826	0.01	50	C	C	8	
C901 C902	0.470	10	CC	C C	8	
C903	0.01		č			
				I C	A	
C905	0.01	1000	C	Ρ	A	
C905 C906 C907	0.01 2200p	1000				
C906 C907 C910	2200p 470p		0000	P P C P	A A B A	
C906 C907 C910 C991	2200p 470p 0.1	<u> 88</u> \ 88	00000	P P C P C	A A B A A	
C906 C907 C910	2200p 470p		0000	P P C P	A A B A	
C906 C907 C910 C991 C992 C993	2200p 470p 0.1 0.1	88 88 88 88 88 88 88 88 88 88 88 88 88	000000		A B A A B	
C906 C907 C910 C991 C992 C993 C993 C1101	2200p 470p 0.1 0.1	<u> 3</u> 3 3 3 3 3 3 3 3 3 3 3 3 3 3 3 3 3 3	000000	P P C P C C C	A A A A A	8
C906 C907 C910 C991 C992 C993 C993 C1101 C1102 C1102 C1103	2200p 470p 0.1 0.1 1000p 1000p 0.1u		0000000 000	P P C P C C C C C C C C	A B A A B B B B A	B F
C906 C907 C910 C991 C992 C993 C1101 C1102 C1103 C1104	2200p 470p 0.1 0.1 1000p 1000p 0.1u 1000p	<u> </u>			A B A A B B B B A B	B F B
C906 C907 C910 C991 C992 C993 C1101 C1102 C1102 C1104 C1105 C1106	2200p 470p 0.1 0.1 1000p 1000p 0.1u 1000p 1000p 47		0000000 000	P P C P C C C C C C C C	A B A A B B B B A	8 F 8 8
C906 C907 C910 C991 C992 C993 C1101 C1102 C1103 C1104 C1105 C1106 C1107	2200p 470p 0.1 0.1 1000p 0.1u 1000p 0.1u 1000p 47 0.1u	<u>ଟ୍ଟି</u> ୍ଦି\ଞ୍ଜିନନନ ନନ୍ଦନ୍ଦନ ଅନ୍ତର ଅଭିନ			A A A A B B B A B B A A A A A	8 F 8 8 F
C906 C907 C910 C991 C992 C993 C1101 C1102 C1103 C1104 C1105 C1106 C1106 C1107 C1108	2200p 470p 0.1 0.1 0.1 1000p 1000p 0.1u 1000p 47 0.1u 0.01	<u>ଟ୍ଟି୍୍ର୍୍ର୍୍ର୍୍୍ର୍୍୍୍ର୍୍୍୍ର୍୍୍୍ର୍୍୍୍ର୍୍</u>			A A B B B B A A A A A A A A A A	8 F 8 8 F VDM
C906 C907 C991 C992 C993 C1101 C1102 C1103 C1104 C1105 C1106 C1107 C1108 C1109	2200p 470p 0.1 0.1 0.1 1000p 1000p 0.1u 1000p 47 0.1u 0.01	<u>ଟ୍ଟି</u> ୍ଦି\ଞ୍ଜିନନନ ନନ୍ଦନ୍ଦନ ଅନ୍ତର ଅଭିନ			A A A A B B B A B B A A A A A	8 F 8 8 F
C906 C907 C990 C991 C992 C993 C1101 C1102 C1103 C1104 C1105 C1105 C1106 C1107 C1106 C1107 C1108 C1109	22000 4700 0.1 0.1 10000 10000 0.1u 10000 0.1u 10000 47 0.1u 0.01 0.01				A B A A A B B B B A A A A A A A	8 8 8 9 7 7 7 7 7 7 7 7 7 7 7 7 7 7 7 7
C906 C907 C991 C992 C992 C993 C1101 C1102 C1103 C1104 C1105 C1106 C1106 C1109 C1109 C0IL SVMB0L	22000 4700 0.1 0.1 10000 10000 0.1u 10000 47 0.1u 0.01 0.01 0.01 0.01				A A A A A B B B B B B B B B B B A A A A	8 8 8 9 7 7 7 7 7 7 7 7 7 7 7 7 7 7 7 7
C906 C907 C991 C992 C992 C993 C1101 C1102 C1103 C1104 C1105 C1106 C1106 C1109 C1109 C0IL SVMB0L	22000 4700 0.1 0.1 10000 10000 0.1u 10000 0.1u 10000 47 0.1u 0.01 0.01				A A A A A B B B B B B B B B B B A A A A	8 8 8 9 7 7 7 7 7 7 7 7 7 7 7 7 7 7 7 7
C906 C907 C991 C991 C992 C992 C1101 C1102 C1104 C1105 C1106 C1107 C1008 C1109 C1109 C1108 C1109 C1101	22000 4700 0.1 0.1 10000 10000 0.1 10000 0.1 10000 47 0.01 0.01 0.01 0.01 0.01 0.01			P C C C C C C C C C C C C C C C C C C C	A B A A B B B B B B A A A A A A A A A A	8 8 8 9 7 7 7 7 7 7 7 7 7 7 7 7 7 7 7 7
C906 C907 C910 C991 C992 C993 C1101 C1102 C1103 C1104 C1105 C1106 C1107 C1108 C1109 C011 SVMB0L L101 L110	22000 4700 0.1 0.1 10000 10000 0.1u 10000 47 0.1u 0.01 0.01 0.01 0.01			P P C C C C C C C C C C C C C C C C C C	A A A A A B B B A A A A A A A A A A A A	8 8 8 9 7 7 7 7 7 7 7 7 7 7 7 7 7 7 7 7
C906 C907 C910 C991 C992 C993 C1101 C1102 C1103 C1104 C1105 C1106 C1107 C1108 C1109 COIL SYMBOL L101 L110	22000 4700 0.1 0.1 10000 0.1 10000 0.1 10000 0.1 10000 47 0.1 0.01 10000 47 0.01 0.01 Excel s Excel s			P C C C C C C C C C C C C C C C C C C C	A A A A A A A A A A A A A A A A A	8 8 8 9 7 7 7 7 7 7 7 7 7 7 7 7 7 7 7 7
C906 C907 C910 C991 C991 C992 C992 C1101 C1102 C1104 C1105 C1106 C1107 C1108 C1107 C1108 C1107 C1108 C1107 L110 L101 L101 L111 L1112 L113	22000 4700 0.1 0.1 10000 0.19 10000 0.19 10000 47 0.19 10000 47 0.01 0.01 0.01 0.01 0.01 0.01 0.01 0.0			P P C C C C C C C C C C C C C C C C C C	A A A A A A A A A A A A A A A A A	8 8 8 9 7 7 7 7 7 7 7 7 7 7 7 7 7 7 7 7
C906 C907 C910 C991 C991 C992 C992 C1101 C1102 C1104 C1105 C1106 C1107 C1108 C1107 C1108 C1107 C1108 C1107 L110 L101 L101 L111 L1112 L113	22000 4700 0.1 0.1 100000 100000 1000000			P C C C C C C C C C C C C C C C C C C C	A A B B B A A A A B B B A A A A A A A A	8 8 8 9 7 7 7 7 7 7 7 7 7 7 7 7 7 7 7 7
C906 C907 C910 C991 C991 C992 C993 C1101 C1102 C1102 C1103 C1103 C1104 C1105 C1106 C1107 C1108 C1108 C1109 C1101 L101 L101 L111 L111 L112 L113 L114	22000 4700 0.1 0.1 10000 0.10 10000 0.10 10000 47 0.10 0.01 0.01 0.01 EXCELS EXCELS EXCELS EXCELS			P C C C C C C C C C C C C C C C C C C C		8 8 8 9 7 7 7 7 7 7 7 7 7 7 7 7 7 7 7 7
C906 C907 C910 C991 C992 C993 C1101 C1102 C1102 C1103 C1104 C1105 C1107 C1106 C1107 C1107 C1108 C1109 C1101 L101 L111 L111 L112 L112 L114 L801 L801	22000 27000 47000 0.1 0.1 1000000 100000 100000 100000000	10000 1000		P P C C C C C C C C C C C C C C C C C C	A A B B A B B A A A A A A A A A A A A A	8 8 8 9 7 7 7 7 7 7 7 7 7 7 7 7 7 7 7 7
C906 C907 C910 C991 C992 C993 C1101 C1102 C1102 C1103 C1104 C1105 C1107 C1106 C1107 C1107 C1108 C1109 C1101 L101 L111 L111 L112 L112 L114 L801 L801	22000 27000 47000 0.1 0.1 1000000 100000 100000 100000000	10000 1000		P P C C C C C C C C C C C C C C C C C C	A A B B A A A A A A A A A A A A A A A A	8 8 8 9 7 7 7 7 7 7 7 7 7 7 7 7 7 7 7 7
C906 C907 C910 C991 C992 C993 C1101 C1102 C1103 C1104 C1105 C1106 C1107 C1106 C1107 C1106 C1107 C1108 C1107 C1108 C1107 C1108 C1101 L101 L111 L111 L112 L112 L113 L114 L901 L901 L902 L902 L902	22000 22000 4700 0.1 0.1 100000 100000 100000 10000 10000 1000			P P C C C C C C C C C C C C C C C C C C	A A B B A B B A A A A A A A A A A A A A	8 8 8 9 7 7 7 7 7 7 7 7 7 7 7 7 7 7 7 7
C906 C907 C991 C991 C991 C993 C993 C993 C1101 C1102 C1102 C1103 C1104 C1107 C1108 C1107 C1108 C1107 C1108 C1109 C1107 C1108 C1109 C1107 C1108 C1108 C1107 C110 C1107 C1108 C1107 C1107 C1108 C1107 C1108 C1107 C1108 C1107 C1108 C1107 C1108 C1107 C1108 C1107 C1107 C1108 C1107 C107 C	22000 4700 0.1 0.1 10000 0.10 10000 0.10 10000 47 10000 47 10000 47 10000 47 10000 47 10000 47 10000 47 10000 47 10000 47 10000 47 10000 47 10000 47 10000 47 10000 47 10000 47 10000 47 10000 47 10000 47 10000 47 100000 10000 100000 100000 100000 100000 100000 100000 1000000 100000 1000000 100000 100000 1000000 100			P P C C C C C C C C C C C C C C C C C C		8 8 8 9 7 7 7 7 7 7 7 7 7 7 7 7 7 7 7 7
C906 C907 C910 C991 C992 C993 C1101 C1102 C1103 C1104 C1105 C1107 C1106 C1109 C1107 C1108 C1107 C1109 C1101 L101 L101 L111 L112 L111 L114 L901 L1901 T901 T901	22000 22000 4700 0.1 0.1 100000 100000 100000 10000 10000 1000	10000 100000 100000 100000 10000 10000 10000 10000 10000 10000		P P C C C C C C C C C C C C C C C C C C	A A B B B A A A A A A A A A A A A A A A	8 8 8 9 7 7 7 7 7 7 7 7 7 7 7 7 7 7 7 7
C906 C907 C910 C991 C992 C993 C1101 C1102 C1103 C1104 C1105 C1107 C1108 C1109 C1109 C1108 C1109 C1101 L1101 L111 L112 L113 L114 L901 L901 L1021 L901 L1021 L901 L1021 L901 L1104	22000 22000 4700 0.1 0.1 10000 10000 0.10 10000 10000 10000 47 0.10 0.01 0.01 0.01 0.01 EXCELS EXCEL	10000 1000		P P C C C C C C C C C C C C C C C C C C		8 8 8 9 7 7 7 7 7 7 7 7 7 7 7 7 7 7 7 7
C906 C907 C910 C991 C991 C992 C993 C1101 C1102 C1102 C1102 C1103 C1104 C1107 C1106 C1107 C1106 C1107 C1106 C1107 C1106 C1107 C1106 C1107 C1106 C1107 C1106 C1107 C1106 C1107 C1107 C1107 C1108 C1107 C1108 C1107 C1107 C1108 C1107 C1108 C1107 C1107 C1108 C1107 C1107 C1108 C1107 C1108 C1107 C1107 C1107 C1108 C1107 C1107 C1108 C1107 C107 C	22000 22000 4700 0.1 10000 10000 0.10 10000 47 0.001 100000 10000 10000 10000 10000 1000000 100000 10000 10000 1000000 100000			P P C C C C C C C C C C C C C C C C C C	A A B B B A A A A A A A A A A A A A A A	8 8 8 9 7 7 7 7 7 7 7 7 7 7 7 7 7 7 7 7
C906 C907 C910 C991 C992 C993 C1101 C1102 C1103 C1104 C1105 C1107 C1108 C1109 C1109 C1108 C1109 C1101 L1101 L111 L112 L113 L114 L901 L901 L1021 L901 L1021 L901 L1021 L901 L1104	22000 22000 4700 0.1 10000 10000 0.10 10000 47 0.001 100000 10000 10000 10000 10000 1000000 100000 10000 10000 1000000 100000			P P C C C C C C C C C C C C C C C C C C		8 8 8 9 7 7 7 7 7 7 7 7 7 7 7 7 7 7 7 7
C906 C907 C910 C991 C991 C992 C993 C1101 C1102 C1102 C1102 C1103 C1104 C1107 C1106 C1107 C1106 C1107 C1106 C1107 C1106 C1107 C1106 C1107 C1106 C1107 C1106 C1107 C1106 C1107 C1107 C1107 C1108 C1107 C1108 C1107 C1107 C1108 C1107 C1108 C1107 C1107 C1108 C1107 C1107 C1108 C1107 C1108 C1107 C1107 C1107 C1108 C1107 C1107 C1108 C1107 C107 C	22000 22000 4700 0.1 0.1 100000 100000 100000 10000 10000 1000			P P C C C C C C C C C C C C C C C C C C		
C906 C907 C907 C908 C9991 C9993 C9993 C1101 C1102 C1103 C1104 C1104 C1105 C1105 C1107 C1106 C1107 C1108 C1107 C1109 C1101 L101 L111 L112 L113 L114 L901 L901 L902 NF1 T001 T301 L1102 TRAM	22000 22000 4700 0.1 0.1 100000 100000 100000 1000000 100000 100000 1000000 100000 100000 100000 1000000			P P C C C C C C C C C C C C C C C C C C		
C906 C907 C910 C991 C992 C993 C1101 C1102 C1103 C1104 C1105 C1107 C1108 C1109 C011 L1101 L111 L112 L113 L114 L901 L1102 NF1 T001 L1102 L1103 L1104 L901 L1102 TRA1 SYMB0L 0141	22000 22000 4700 0.1 0.1 10000 10000 0.10 10000 10000 10000 10000 10000 0.10 10000 10000 10000 0.10 10000 10000 10000 0.10 10000 10000 0.10 10000 0.10 10000 0.10 10000 0.10 10000 0.10 10000 0.10 10000 0.10 10000 10000 0.10 10000 0.10 10000 10000 0.10 10000 10000 0.10 10000 10000 0.10 100000 100000 10000 100000 100000 100000 10000 10000 10000 1000	10000 1000		P P C C C C C C C C C C C C C C C C C C		
C906 C907 C907 C991 C991 C992 C993 C1101 C1102 C1103 C1104 C1104 C1105 C1107 C1108 C1107 C1108 C1107 C1108 C1107 C1108 C1107 C1108 C1107 C1108 C0IL L101 L111 L112 L113 L114 L101 L112 L113 L114 L901 NF1 T001 T301 T1021 TRAN SYMB0L G141 G201 G201	22000 22000 4700 0.1 0.1 100000 100000 100000 10000 10000 1000	10000 100		P P C C C C C C C C C C C C C C C C C C		
C906 C907 C907 C991 C992 C993 C1001 C1102 C1103 C1104 C1105 C1106 C1107 C1108 C1109 C011 L101 L111 L1101 L1111 L1101 L1101 L1101 L1101 L1101 L1101 L1101 L1101 L1102 TRA1 G201 G201 G201	22000 22000 4700 0.1 0.1 100000 100000 100000 10000 10000 1000	10000 1000				
C306 C907 C910 C931 C932 C933 C1101 C1102 C1103 C1104 C1105 C1106 C1107 C1108 C1109 C1101 L101 L111 L111 L112 L113 L114 L901 L901 L1021 L1031 L112 L113 L114 L901 L901 T301 TRAN SYB0L 0141 0202 0203	22000 22000 4700 0.1 0.1 100000 10000 10000 10000 10000 10000	10000 100000 100000 100000 100000 100000 1000000 1000000 100000		P P C C C C C C C C C C C C C C C C C C		
C906 C907 C910 C991 C992 C993 C1101 C1102 C1103 C1104 C1105 C1107 C1108 C1109 C1101 L101 L111 L111 L111 L112 L113 L114 L901 L102 YF01 T301 TRAN SYMBOL Q201 Q202 Q203 Q204	22000 22000 4700 0.1 0.1 0.1 10000 10000 0.10 10000 0.10 10000 47 10.01 10.00 47 10.01 10.01 10.00 47 10.01 10.00 47 10.01 10.00 47 10.01 10.01 10.01 10.00 47 10.01 10.00 47 10.01 10.00 47 10.01 10.00 47 10.01 10.00 47 10.01 10.00 47 10.01 10.00 47 10.01 10.01 10.00 10.00 47 10.01 10.00 1	10000 1000		P P C C C C C C C C C C C C C C C C C C		
C306 C907 C910 C991 C992 C993 C1101 C1102 C1102 C1103 C1104 C1105 C1107 C1106 C1107 C1107 C1108 C1101 L111 L112 L113 L114 L901 L901 T301 L102 NF1 T801 C1102 Q201 Q201 Q201 Q201 Q201 Q201 Q201 Q201	22000 22000 4700 0.1 0.1 100000 100000 100000 10000 10000 1000	10000 1000		P P C C C C C C C C C C C C C C C C C C		
C906 C907 C910 C991 C992 C993 C1101 C1102 C1103 C1104 C1105 C1107 C1108 C1109 C011 C1108 C1109 C011 L1101 L1101 L111 L112 L113 L114 L901 L911 L901 L1102 T301 T301 T301 T301 T301 T301 T301 T301 T301 C1102 Q203 Q204 Q203 Q204 Q203 Q204 Q301	22000 22000 4700 0.1 0.1 10000 10000 0.10 100000 100000 100000 10000 10000 10000	10000 1000		P P C C C C C C C C C C C C C C C C C C		
C306 C907 C910 C991 C992 C993 C1101 C1102 C1102 C1103 C1104 C1105 C1107 C1106 C1107 C1107 C1108 C1101 L111 L112 L113 L114 L901 L901 T301 L102 NF1 T801 C1102 Q201 Q201 Q201 Q201 Q201 Q201 Q201 Q201	22000 22000 4700 0.1 0.1 10000 10000 0.10 100000 100000 100000 10000 10000 10000	10000 1000		P P C C C C C C C C C C C C C C C C C C		
C906 C907 C910 C991 C992 C993 C1101 C1102 C1103 C1104 C1105 C1106 C1107 C1108 C1109 C011 L101 L111 L901 T301 T301 T301 T301 T301 T301 T301 T301 G201 G202 G203 G204 G205 G203<	22000 22000 4700 0.1 0.1 10000 10000 0.10 100000 100000 100000 10000 10000 10000	10000 1000		P P C C C C C C C C C C C C C C C C C C		
C906 C907 C910 C931 C932 C933 C1101 C1102 C1103 C1104 C1105 C1106 C1107 C1108 C1109 C1101 L111 L1111 L1102 TRA1 G201 G203 G204 G203 G204 G205 G305	22000 22000 4700 0.1 0.1 100000 100000 100000 10000 10000 1000	10000 100000 100000 100000 10000 10000 10000 10000 10000 100000		P P C C C C C C C C C C C C C C C C C C		
C906 C907 C907 C907 C991 C992 C993 C1001 C1002 C1003 C1004 C1005 C1006 C1007 C1008 C1001 L101 L101 L101 L101 L101 L111 L902 NF1 T001 T301 L1101 L1102 COLL SWB0L G201 T301 T301 T301 T301 T301 G202 G203 G204 G203 G204 G205 G203 G204 G203 G203 G203 G203 G203 G20	22000 22000 22000 4700 0.1 0.1 100000 100000 100000 10000 1000	10000 1000		P P C C C C C C C C C C C C C C C C C C		
C906 C907 C910 C991 C992 C993 C1101 C1102 C1103 C1104 C1105 C1106 C1107 C1108 C1109 C1101 L111 L111 L111 L111 L111 L111 L111 L112 L113 L114 L901 L901 L902 MF1 T001 T301 L1101 L1102 G203 G204 G301 G302 G303 G301 G302 G303 G303 G303	22000 22000 4700 0.1 0.1 100000 10000 100000 10000 10000 10000	10000 100000 100000 100000 100000 100000 1000000 1000000 100000 10000		P P C C C C C C C C C C C C C C C C C C		
C906 C907 C910 C991 C993 C993 C1101 C1102 C1103 C1104 C1105 C1106 C1107 C1108 C1109 C011 L1101 L111 L112 L113 L114 L901 L1102 NF1 T001 T301 T301 T102 Q203 Q204 Q301 Q302 Q303 Q203 Q204 Q301 Q302 Q303 Q304 Q305 Q306 Q301 Q302 Q303 Q304 Q305 Q306 Q301 Q302 Q30	22000 22000 4700 0.1 0.1 100000 10000 100000 10000 10000 10000	10000 1000		P P C C C C C C C C C C C C C C C C C C		8 F 8 8 F VDM
C906 C907 C910 C991 C993 C993 C1101 C1102 C1103 C1104 C1105 C1106 C1107 C1108 C1109 C011 L1101 L111 L112 L113 L114 L901 L1102 NF1 T001 T301 T301 T102 Q203 Q204 Q301 Q302 Q303 Q203 Q204 Q301 Q302 Q303 Q304 Q305 Q306 Q301 Q302 Q303 Q304 Q305 Q306 Q301 Q302 Q30	22000 22000 4700 0.1 0.1 0.1 10000 10000 0.10 100000 100000 10000 100000 100000 10000 10000 10000 10000	10000 100000 100000 100000 100000 100000 1000000 1000000 100000 10000		P P C C C C C C C C C C C C C C C C C C		
C906 C907 C910 C991 C992 C993 C1101 C1102 C1103 C1104 C1105 C1106 C1107 C1108 C1109 C011 L1101 L1111 L1111 L1111 L1111 L1111 L1111 L1112 L1113 L1114 L901 L1102 TRA1 C0141 G2021 G2031 G2031 G2031 G2031 G2031 G2031 G2031 G2032 G2031 G2032 G2031 G2032 G2031 G2032 G2033 G2034 G2035 G2036 <	22000 22000 4700 0.1 0.1 100000 100000 100000 100000 10000 100	10000 1000		P P C C C C C C C C C C C C C C C C C C		
C906 C907 C910 C1101 C1102 C1103 C1104 C1105 C1107 C1108 C1109 C011 L111 L111 L111 L111 L111 L111 L112 L113 L114 L901 L902 NF01 0111 L1102 L1101 L1102 Q201 Q202 Q203 Q204 Q301 Q202 Q303 I Q222 Q203	22000 22000 22000 4700 0.1 0.1 10000 10000 0.1 10000 10000 470 0.1 0.00			P P C C C C C C C C C C C C C C C C C C		
C906 C907 C910 C911 C1102 C1103 C1104 C1105 C1107 C1108 C1101 L111 L111 L111 L111 L111 L112 L113 L114 L901 L902 NF80L G1111 L102 NF80L G1411 G202 G301 G202 G303 G204 G301 G202 G303 G201 G202 G303 I G203 G204	22000 22000 22000 4700 0.1 0.1 10000 10000 0.1 10000 10000 470 0.1 10000 470 0.1 0.01			P P C C C C C C C C C C C C C C C C C C		
C906 C907 C910 C991 C992 C993 C1101 C1102 C1103 C1104 C1105 C1106 C1107 C1108 C1101 L111 L1101 L1102 PR01 SYMB01 Q201 Q202 Q203 Q204 Q301 Q302 Q303 Q301 Q302 Q	22000 22000 22000 47000 0.1 0.1 100000 100000 100000 10000 10000 100000 100000 100000 100000 100	10000 1000		P P C C C C C C C C C C C C C C C C C C		
C906 C907 C907 C907 C907 C991 C992 C993 C1101 C1102 C1103 C1104 C1105 C1107 C1108 C1109 C011 L111 L112 L113 L111 L901 L902 NF1 T001 T301 L1101 L1102 RA SWE01 0301 0302 0301 0302 0301 0302 0303	22000 22000 22000 4700 0.1 0.1 0.1 100000 100000 100000 100000 100000 100000 100000 100000 1			P P C C C C C C C C C C C C C C C C C C		
C906 C907 C910 C910 C991 C992 C993 C1101 C1102 C1103 C1104 C1105 C1106 C1107 C1108 C1107 C1107 C1108 C1107 C1107 C1108 C1107 C1107 C1108 C1107 C1107 C1108 C1107 C107 C	22000 22000 22000 4700 0.1 0.1 100000 100000 100000 10000 1000	10000 1000				

ZD901 JUMPER C A ZD902 UDZS3-69 C A

DIODI	Ξ			
symbol	MODEL TYPE		FACE	REWARK
D101		A	A	
D102 D103		H C	A	
D131	U1GU44	C	8	
D132 D133		C C	B	
D134	U1GU44	Ċ	B	\square
D401		C	A	
D701	DSM3	C	A	
D821	155355	C	A	
D902 D81		A	A	
DB1 IC	D3SBA60	<u> H</u>		
SYMBOL	MODEL TYPE	IYPE	FACE	REHWARK
IC1		C	A	
IC001	STR-V852	н	A	
IC101 IC102	KIA7805API KIA431A	HR	A	
IC201	KIA7815API	н	A	
IC401	BR24L04F-W	С	A	
IC501 IC502	KID65003AF KID65003AF	C C	A	
IC801	NJM2903M	C	A	
PHO ⁻			B	
SYMBOL	MODEL TYPE		116	REMARK
PC101	PS2701-1	IMPE C	FACE	
PC201	PS2701-1	C	8	
PC202	PS2701-1	C	8	
PC1101 PC1102	TLP421BL TLP421BL	C C	8	
. USIUE		Ĭ		
=USE	_			
SYMBOL	MODEL TYPE		<u>.</u>	REWARK
WFUSE		н	FACE	
f f	TP00351-51 TP00351-51	R R	A	
T I				
JUMP	<u>ER</u>	.		
symbol	MODEL TYPE	IMPE	- 	EWR
JW1			A	
SWIT	сн			
	r		06	
SYMBOL	MODEL TYPE	ME	FÅŒ	E WR
SW1	L EVERALUOK	1 11		
SURC	<u>GE ARRES</u>		R	
symbol.			06	
	MODEL TYPE		EACE.	REWAR
	100EL 11/E 416NR-12D	TYPE P	FACE A	
		IMPE	FACE	
VA001	416NR-12D	IMPE	FACE	
	415NR-120 ATOR	P	A	
VA001 DCCII SYMBOL	416NR-12D <u>ATOR</u> MODEL TYPE		FACE	
VA001 DCCII SYMBOL	415NR-120 ATOR			
VA001 OCCII SYMBOL DSC1	416NR-12D <u>ATOR</u> MODEL TYPE		FACE	
	41649-120 _ATOR _MODEL TYPE EFONC1005	IMPE P I I I I I I I I I I I I I I I I I I		
	AIGNE-12D ATOR MODEL TYPE EFONC1005 JECTOR MODEL TYPE B2D-PH-K-S	IMPE P I I I I I I I I I I I I I I I I I I	FACE A FACE A	
VA001 DCCII SYMBOL DSC1 CONN SYMBOL CN3 CN4	41649-120 ATOR WOUL TYPE EFONC1005 JECTOR WOUL TYPE B28-PTK-S CT-4P-V			
VA001 DCCII SYMBOL DSC1 CONN SYMBOL CN3 CN4 CN5A	AIGNE-12D ATOR MODEL TYPE EFONC1005 JECTOR MODEL TYPE B2D-PH-K-S	TYPE P TYPE R TYPE	FACE A FACE A FACE	
VA001 OCCII SYMBOL OSC1 CONN CN3 CN3 CN3 CN5A CN5A	416NR-12D .ATOR MODEL TYPE EFONC1005 JECTOR MODEL TYPE B2B-PH-K-S CT-4P-V CT-5P-V B11B-PH-K-S		FACE A FACE A A A A A A	
VA001 VA001 OCCII SYMBOL DSC1 CONN SYMBOL CNSA CNSA CNSA CNSA CNSA CNSA	41699-120 ATOR MODEL TYPE EFONC1005 JECTOR MODEL TYPE B28-P1+K-3 CT-4P-V			
VA001 VA001 OCCII SYMBOL DSC1 DSC1 CNSA CNSA CNSA CNSA CNSA CNSA CNSA CNSA CNSA CNSA	41699-120 ATOR MODEL TYPE EFONC1005 JECTOR MODEL TYPE B2B-PH-K-S CT-4P-V CT-4P-V CT-4P-V B1B-PH-K-S B14P-NH-K-S B44P-XH-K-S		FACE A FACE A A A A A A	
VA001 VA001 OCCII SYMBOL DSC1 DSC1 CNSA CNSA CNSA CNSA CNSA CNSA CNSA CNSA CNSA CNSA	415NF-12D ATOR MODEL TYPE EFONC1005 VECTOR MODEL TYPE B28-PH-K-S CT-SP-V B118-PH-K-S B48-PH-K-S B48-PH-K-S		FACE A FACE A A A A A A A	
VA001 OCCII SYMBOL OSC1 CONN SYMBOL CNS3 CNS3 CNS5	41699-120 ATOR MODEL TYPE EFONC1005 JECTOR MODEL TYPE B2B-PH-K-S CT-4P-V CT-5P-V B14B-PH-K-S B44B-PH-K-S B44B-PH-K-S CT-6P-V B58B-PH-K-K		FACE A FACE A A A A A A A	
VA001 VA001 OCCII SYMBOL 0561 CONN CNSA CNSA CNSA CNSA CNSA CNSA CNSA CNSA CNSA CNSA CNSA CNSA CNSA CNSA CNSA CNSA CNSA CNSA	416NR-12D ATOR MODEL TYPE EFONC1005 JECTOR MODEL TYPE B2B-PH-K-S CT-4P-V CT-5P-V B11B-PH-K-S CT-6P-V B5B-PH-K-S CT-6P-V B5B-PH-K-S		FACE	
VA001 VA001 OCCII SYMBOL 0501 CONN SYMBOL 0501 CN5A	41699-120 ATOR MODEL TYPE EFONC1005 JECTOR NODEL TYPE B20-PH-K-S B10-PH-K-S B10-PH-K-S B10-PH-K-S B50-PH-K-S B50-PA-K-S			
VA001 VA001 OCCII SYMBOL 0501 CONN SYMBOL 0501 CN5A	41699-120 ATOR NODEL TYPE EFONC1005 IECTOR NODEL TYPE B2B-PH-K-S CT-SP-V B11B-PH-K-S B4B-PH-K-S B4B-PH-K-S CT-SP-V B11B-PH-K-S B4B-PH-K-S B5B-PH-K-S		FALE	
VA001 VA001 OCCII SYMBOL 0861 CONS CNS CNS CNS CNS CNS CNS CNS C	41699-120 ATOR MODEL TYPE EFONC1005 JECTOR MODEL TYPE B28-PH-K-S CT-SP-V B118-PH-K-S B48-PH-K-S B48-PH-K-S B58-PH-K			
VA001 VA001 OCCII SYMBOL 0851 CONN CNS CNS CNS CNS CNS CNS CNS C	41699-120 ATOR MODEL TYPE EFONC1005 JECTOR MODEL TYPE B28-PH-K-S CT-SP-V B18-PH-K-S B48-PH-K-S B48-PH-K-S B58-PH-K-			
VA001 VA001 OCCII SYMBOL 0501 CONN CN50	416WF-12D ATOR MODEL TYPE EFONC1005 JECTOR MODEL TYPE B2B-PH-K-S CT-4P-V CT-5P-V B1B-PH-K-S B4B-PH-K-S B4B-PH-K-S B4B-PH-K-S B5B-PA-K-S			
VA001 VA001 OCCII SYMBOL 0851 CONN CNS CNS CNS CNS CNS CNS CNS C	416WF-12D ATOR MODEL TYPE EFONC1005 JECTOR MODEL TYPE B2B-PH-K-S CT-4P-V CT-5P-V B1B-PH-K-S B4B-PH-K-S B4B-PH-K-S B4B-PH-K-S B5B-PA-K-S			
VA001 VA001 OCCII SYMB0L DSC1 CONS CNS0 CNS0 CNS0 CNS0 CNS0 CNS0 CNS0 CNS1 C	41699-120 ATOR MODEL TYPE EFOMC1005 EFOMC1005 NODEL TYPE B2B-PH-K-S CT-SP-V B11B-PH-K-S B4B-PH-K-S B4B-PH-K-S B4B-PH-K-S B5B-PA-K-S B5B-F			
VA001 VA001 OCCII SYMBOL 05C1 CONN CNS1 CNS2 CNS3 CNS4 CNS5	416NR-12D ATOR MODEL TYPE EFONC1005 JECTOR MODEL TYPE B2B-PH-K-S CT-8P-V CT-5P-V B1B-PH-K-S B4B-PH-K-S B4B-PH-K-S B4B-PH-K-S B4B-PH-K-S B4B-PH-K-S B4B-PH-K-S B5B-PA-K-S B5B-PA-K-S B4B-PH-K-S B5B-PA-K-S B4B-PH-K-S B5B-PA-K-S B4B-PH-K-S B5B-PA-K-S B4B-PH-K-S B5B-PA-K-S B4B-PH-K-S B5B-PA-K-S B4B-PH-K-S B5B-PA-K-S B4B-PH-K-S B5B-PA-K-S B4B-PH-K-S B5B-PA-K-S B4B-PH-K-S B5B-PA-K-S B4B-PH-K-S B5B-PA-K-S B4B-PH-K-S B5B-PA-K-S B4B-PH-K-S B5B-PA-K-S B4B-PH-K-S B5B-PA-K-S B4B-PH-K-S B5B-PA-K-S B4B-PH-K-S B5B-PA-K-S B4B-PH-K-S B5B-PA-K-S B4B-PH-K-S B5B-PA-K-S B4B-PH-K-S B5B-PA-K-S B5B-PA-K-S B4B-PH-K-S B5B-PA-K-S B4B-PH-K-S B5B-PA-K-S B5B-PA-K-S B5B-PA-K-S B4B-PH-K-S B5B-PA-K-S B5B-PA-K-S B4B-PH-K-S B5B-PA-K-S B5B-PA-K-S B4B-PH-K-S B5B-PA-K-S B4B-PH-K-S B5B-PA-K-S B4B-PH-K-S B5B-PA-K-S B4B-PH-K-S B5B-PA-K-S B4B-PH-K-S B5B-PA-K-S B4B-PH-K-S B5B-PA-K-S B4B-PH-K-S B5B-PA-K-S B4B-PH-K-S B5B-PA-K-S B4B-PH-K-S B5B-PA-K-S B4B-PH-K-S B4B-PH-K-S B5B-PA-K-S B4B-PH-K-S B4B-PH-K-S B4B-PH-K-S B5B-PA-K-S B4B-PH-K-S			
VA001 VA001 OCCII SYMBOL DSC1 CONS SYMBOL CNS3 CNS3 CNS3 CNS5	416NR-12D ATOR MODEL TYPE EFONC1005 EFONC1005 JECTOR MODEL TYPE B2B-PH-K-S CT-SP-V B11B-PH-K-S B4B-PH-K-S B4B-PH-K-S B5B-PA-K-S B4B-PA-K-S B5B-PA-K-S B5B-PA-K-S B5B-PA-K-S B4B-PA-K-S B4B-PA-K-S B5B-PA-K-S B5B-PA-K-S B4B-FA-K-S B4B-FA-K-S B4B-FA-K-S B4B-FA-K-S B4B-FA-K-S B4B-FA-K-S B4B-K-S B4B-K-S B4B-K-S B4B-K-			
VA001 VA001 VA001 OCCII SYMBOL 0501 CNS0	41699-120 ATOR MODEL TYPE FFOMC1005 FFOM			
	416NR-12D ATOR MODEL TYPE EFONC1005 FFONC1005 JECTOR MODEL TYPE B2B-PH-K-S CT-SP-V B1B-PH-K-S B4B-PH-K-S B4B-PH-K-S B4B-PH-K-S B5B-PA-K-S B5B-PA-K-S B5B-PA-K-S B5B-PA-K-S B5B-PA-K-S B5B-PA-K-S B5B-PA-K-S B5B-PA-K-S B5B-PA-K-S B5B-PA-K-S B5B-PA-K-S B5B-PA-K-S B5B-PA-K-S B5B-PA-K-S B0ARD-N TYPE B0ARD-N TYPE B0ARD-N TYPE B0ARD-N TYPE B0ARD-N TYPE		FACE	
VA001 VA001 VA001 OCCII SYMBOL 0501 SYMBOL 0501 CNI CNI CNI CNI CNI CNI CNI CNI	416NP-12D 416NP-12D A T OR NODEL TYPE EFONC1005 <u>IECTOR</u> NODEL TYPE <u>B2B-PH-K-S</u> CT-GP-V B11B-PH-K-S B4B			
VA001 VA001 VA001 OCCII SYMBOL 08501 CONS CONS CONS CNS CNS CNS CNS CNS CNS CNS C	416NR-12D ATOR MODEL TYPE EFONC1005 FFONC1005 JECTOR MODEL TYPE B2B-PH-K-S CT-SP-V B1B-PH-K-S B4B-PH-K-S B4B-PH-K-S B4B-PH-K-S B4B-PH-K-S B4B-PH-K-S B4B-PH-K-S B5B-PA-K-S B4B-PA-K-S B5B-PA-K-S B5B-PA-K-S B4B-PA-K-S B5B-PA-K-S B4B-PA-K-S B5B-PA-K-S B4B-PA-K-S B5B-PA-K-S B4B-PA-K-S B4B-PA-K-S B4B-PA-K-S B5B-PA-K-S B4B-PA-K-S B5B-PA-K-S B4B-PA-K-S B5B-PA-K-S B4B-PA-K-S B5B-PA-K-S B4B-PA-K-S B5B-PA-K-S B4B-PA-K-S		FACE	
VA001 VA001 VA001 OCCII SYMBOL OSC1 CON1 CNS1 CNS2 CNS3 CNS5 CN	41698-120 41698-120 A T OR MODEL TYPE EFOMC1005 EFOMC1005 EFOMC1005 IEC T OR MODEL TYPE B2B-PH-K-S CT-6P-V B11B-PH-K-S B4B-HK-S B4B-HK-S			
VA001 VA001 VA001 OCCII SYMBOL OSC1 CON1 CNS1 CNS2 CNS3 CNS5 CN	416NP-12D 416NP-12D A TOR NODEL TYPE EFONC1005 <u>FC TOR</u> NODEL TYPE <u>B2B-PH-K-S</u> <u>CT-SP-V</u> <u>B1B-PH-K-S</u> <u>B4B-PH-K-S</u> <u>B4B-PH-K-S</u> <u>B4B-PH-K-S</u> <u>B4B-PH-K-S</u> <u>B4B-PH-K-S</u> <u>B4B-PH-K-S</u> <u>B4B-PH-K-S</u> <u>B4B-PH-K-S</u> <u>B4B-PH-K-S</u> <u>B4B-PH-K-S</u> <u>B4B-PH-K-S</u> <u>B4B-PH-K-S</u> <u>B4B-PH-K-S</u> <u>B4B-PH-K-S</u> <u>B4B-PH-K-S</u> <u>B4B-PH-K-S</u> <u>B4B-PH-K-S</u> <u>B4B-PH-K-S</u> <u>B4B-PH-K-S</u> <u>B4B-PH-K-S</u> <u>B4B-PH-K-S</u> <u>B5B-PA-K-S</u> <u>B4B-PH-K-S</u> <u>B5B-PA-K-S</u> <u>B4B-PH-K-S</u> <u>B5B-PA-K-S</u> <u>B4B-PH-K-S</u> <u>B5B-PA-K-S</u> <u>B4B-PA-K-S</u> <u>B4B-PA-K-S</u> <u>B4B-PA-K-S</u> <u>B4B-PA-K-S</u> <u>B4B-PA-K-S</u> <u>B4B-PA-K-S</u> <u>B4B-PA-K-S</u> <u>B4B-PA-K-S</u> <u>B4B-PA-K-S</u> <u>B4B-PA-K-S</u> <u>B4B-PA-K-S</u> <u>B4B-PA-K-S</u> <u>B4B-PA-K-S</u> <u>B4B-PA-K-S</u> <u>B4B-PA-K-S</u> <u>B4B-PA-K-S</u> <u>B4B-PA-K-S</u> <u>B4B-PA-K-S</u> <u>B4B-PA-K-S</u> <u>B4B-PA-K-S</u> <u>B4B-PA-K-S</u> <u>B4B-PA-K-S</u> <u>B4B-PA-K-S</u> <u>B4B-PA-K-S</u> <u>B4B-PA-K-S</u> <u>B4B-PA-K-S</u> <u>B4B-PA-K-S</u> <u>B4B-PA-K-S</u> <u>B4B-PA-K-S</u> <u>B4B-PA-K-S</u> <u>B4B-PA-K-S</u> <u>B4B-PA-K-S</u> <u>B4B-PA-K-S</u> <u>B4B-PA-K-S</u> <u>B4B-PA-K-S</u> <u>B4B-PA-K-S</u> <u>B4B-PA-K-S</u> <u>B4B-PA-K-S</u> <u>B4B-PA-K-S</u> <u>B4B-PA-K-S</u> <u>B4B-PA-K-S</u> <u>B4B-PA-K-S</u> <u>B4B-PA-K-S</u> <u>B4B-PA-K-S</u> <u>B4B-PA-K-S</u> <u>B4B-PA-K-S</u> <u>B4B-PA-K-S</u> <u>B4B-PA-K-S</u> <u>B4B-PA-K-S</u> <u>B4B-PA-K-S</u> <u>B4B-PA-K-S</u> <u>B4B-PA-K-S</u> <u>B4B-PA-K-S</u> <u>B4B-PA-K-S</u> <u>B4B-PA-K-S</u> <u>B4B-PA-K-S</u> <u>B4B-PA-K-S</u> <u>B4B-PA-K-S</u> <u>B4B-PA-K-S</u> <u>B4B-PA-K-S</u> <u>B4B-PA-K-S</u> <u>B4B-PA-K-S</u> <u>B4B-PA-K-S</u> <u>B4B-PA-K-S</u> <u>B4B-PA-K-S</u> <u>B4A-PA-N TYPE</u> <u>B0ARD-N TYPE <u>B0ARD-N TYPE</u> <u>B0ARD-N TYPE</u> <u>B0ARD</u></u>			
VA001 VA001 VA001 OCCII SYMBOL OSC1 CON1 CNS1 CNS2 CNS3 CNS5 CN	41698-120 41698-120 A T OR MODEL TYPE EFOMC1005 EFOMC1005 EFOMC1005 IEC T OR MODEL TYPE B2B-PH-K-S CT-6P-V B11B-PH-K-S B4B-HK-S B4B-HK-S			
VA001 VA001 VA001 OCCII SYMBOL OSC1 CON1 CNS1 CNS2 CNS3 CNS5 CN	416NR-12D ATOR MODEL TYPE EFONC1005 JECTOR MODEL TYPE B2B-PH-K-S CT-8P-V CT-5P-V B1B-PH-K-S B4B-PH-K-S			
	416NR-12D ATOR MODEL TYPE EFONC1005 JECTOR MODEL TYPE B2B-PH-K-S CT-8P-V CT-5P-V B1B-PH-K-S B4B-PH-K-S		FACE	
VA001 VA001 VA001 OCCII SYMBOL 05C1 CONI CNS CNS CNS CNS CNS CNS CNS CNS	416NR-12D A T O R MODEL TYPE EFONC1005 FFONC1005 JECTOR MODEL TYPE B2D-PH-K-S CT-6P-V B3D-PH-K-S B4D-PH-K-S B4D-PH-K-S B4D-PH-K-S B4D-PH-K-S B4D-PH-K-S B4D-PH-K-S B4D-PH-K-S B4D-PH-K-S B4D-PH-K-S B5D-PA-K-S B0ARD-N TYPE B0ARD-N TYPE B0ARD			
VA001 VA001 VA001 OCCII SYMBOL 0851 CONI SYMBOL 0851 CONI SYMBOL CN3 CN3 CN3 CN4 CN3 CN4 CN5 CN5 CN5 CN5 CN5 CN5 CN5 CN5	416NR-12D ATOR MODEL TYPE EFONC1005 FFONC1005 JECTOR MODEL TYPE B2B-PH-K-S CT-6P-V B1B-PH-K-S B0ARD-N TYPE B0ARD-N TYPE			
	41698-120 A TOR MODEL TYPE EFONC1005 FFONC1005 JECTOR MODEL TYPE B28-PH-K-S CT-SP-V B18-PH-K-S B48-PH-K-S B48-PH-K-S B48-PH-K-S B48-PH-K-S B48-PH-K-S B58-PA-K-S B0ARO-N TYPE B0ARO-N TYPE B0ARO-N TYPE B0ARO-N TYPE B0ARO-N TYPE B0ARO-N TYPE B0ARO-N TYPE B0ARO-N TYPE B0ARO-N TYPE			
	41698-120 41698-120 A T OR MODEL TYPE EFOMC1005 EFOMC1005 EFOMC1005 NODEL TYPE B28-PH-K-S CT-6P-V B118-PH-K-S B49-PH-K-S B40-H			
	41699-120 A T OR MODEL TYPE EFONC1005 FFONC1005 JECTOR MODEL TYPE B29-PH-K-S CT-6P-V B19-PH-K-S B0-ARO-N TYPE B0-ARO-N TYPE B0			

BZ1	PKM13EPY	Ŧ	4	
LED				
		100	mir.	-
SYMBOL	I MODEL TYPE		<u> </u>	D THAN
		TYPE	FALL	1000
LD721	selz713k - Yellow	н		
LD723	isel.6914a - Orange	н		
LD725	Sel6414e - Green	н		
		H		
LD221	EIS19-OPOA7 VOLET	H		
	E1S19-OP0A7 VIOLET	Ĥ		
			_	




- 39 -

PRINTED WIRING BOARD LOCATION DIAGRAM


MODEL RAS-70YH7

MAIN P.W.B.

Marking on P.W.B




COMPONENT SIDE




SOLDERING SIDE

RECEIVING P.W.B.


Marking on P.W.B




P.W.B. MAIN




P.W.B. IPM-BOARD




P.W.B. NF-BOARD





- 44 -


BASIC MODE



Auto	
rature and outdoor temperature.	
or temperature. ad by this judgment, the judgment b	y room temperature in the next paragraph
Restricted to cooling	
Restricted to heating	
(initial judgment) he followings) after 1 hour has elapsed since the after the previous manual mode op	
vitched to auto while operating at m	
R°C · Coolina	oom emperature Cooling
lue from the remote controller.	23 °C Heating
peration (Continuous judgment)	9°C 30°C Outdoor
ollowings) erval time.	temperature
ain before 1 hour has elapsed since	the operation was stopped.
	re which is the sum of the basic preset temperature nperature correction value, powerful shift value, etc.).
eset temperature –3°C Change to h set temperature –3°C Continue coo	
eset temperature +2°C Change to c set temperature +2°C Continue hea	
°C	Cooling
1	
final preset tempera	ture +2°C
ration mode.	

Table 1 Mode data file

	RAS-70YH7	
LABEL NAME	VALUE	
WMAX	5700 min ⁻¹	
WMAX2	5700 min ⁻¹	
WSTD	5400 min ⁻¹	
WBEMAX	4000 min ⁻¹	
СМАХ	5200 min ⁻¹	
CSTD	4900 min ⁻¹	
СКҮМАХ	4000 min ⁻¹	
СЈКМАХ	4000 min ⁻¹	
CBEMAX	2300 min ⁻¹	
WMIN	1200 min ⁻¹	
CMIN	1200 min ⁻¹	
STARTMC	60 Seconds	
DWNRATEW	100%	
DWNRATEC	100%	
SHIFTW	0.00°C	
SHIFTC	1.00°C	
CLMXTP	30.00°C	
YNEOF	25.00°C	
TEION	2.00°C	
TEIOF	9.00°C	
SFTDSW	0.66°C	
DFTIM_OTP0	50 Minutes	
DFTIM_OTP10	50 Minutes	
DFTIM_OTP5	60 Minutes	
STARCPL	1600 min ⁻¹	




Notes:


- (1) Condition for entering into Cool Dashed mode. When fan set to "Hi" or "Auto mode" and temperature difference between indoor temperature and set temperature has a corresponding compressor rpm (calculated value in Table 2) larger than CMAX.
- (2) Cool Dashed will release when i) a maximum 25 minutes is lapsed and ii) room temperature is lower than set temperature –3°C (thermo off) and iii) when room temperature has achieved setting temperature –1°C then maximum Cool Dashed time will be revised to 20 minutes. And iv) indoor fan is set to Lo and Med fan mode and v) change operation mode.
- (3) During Cool Dashed operation, thermo off temperature is set temperature (with shift value) -3°C. After thermo off, operation continue in Fuzzy control mode.
- (4) Compressor minimum "ON" time and "OFF" time is 3 minutes.
- (5) During normal cooling mode, compressor maximum rpm CMAX will maintain for 60 minutes if indoor temperature is lower than CLMXTP. No time constrain if indoor temperature is higher than CLMXTP.
- (6) When fan is set to "Hi", compressor rpm will be limited to CKYMAX.
- (7) When fan is set to "Med", compressor rpm will be limited to CJKMAX.
- (8) When fan is set to "Lo", compressor rpm will be limited to CBEMAX.
- (9) During Cool Dashed, when room temperature reaches set temperature -1°C compressor rpm is actual rpm x DWNRATEC.


Table 2 $\Delta TCMAX$


Tamana	Coloulated
Temperature difference	Calculated
	compressor rpm
1.66	2265 min ⁻¹
2	2435 min ⁻¹
2.33	2600 min ⁻¹
2.66	2765 min ⁻¹
3	2935 min ⁻¹
3.33	3100 min ⁻¹
3.66	3265 min ⁻¹
4	3435 min ⁻¹
4.33	3600 min ⁻¹
4.66	3765 min ⁻¹
5	3935 min ⁻¹
5.33	4100 min ⁻¹
5.66	4265 min ⁻¹
6	4435 min ⁻¹
6.33	4600 min ⁻¹
6.66	4765 min ⁻¹
7	4935 min ⁻¹
7.33	5100 min ⁻¹
7.66	5265 min ⁻¹
8	5435 min ⁻¹
8.33	5600 min ⁻¹
8.66	5765 min ⁻¹
9	5935 min ⁻¹
9.33	6100 min ⁻¹
9.66	6265 min ⁻¹
10	6435 min⁻¹
10.33	6600 min ⁻¹
10.66	6765 min ⁻¹
11	6935 min ⁻¹



- (1) The sleep operation starts when the sleep key is pressed.
- (2) When the sleep key is set, the maximum compressor speed is limited, and the indoor fan is set to "sleep Lo".
- (3) 30 minutes after the sleep key is set, the sleep shift of temperature starts, and upper shift is made at least 6 times.
- If 25°C is not reached after 6 shifts, shifts repeat unit 25°C is reached.
- (4) The sleep shift upper value of set temperature is 28°C.
- (5) After 6 hours, a shift down to the initial set temperature is made at a rate of 0.33°C/5 min.
- (6) If the operation mode is changed during sleep operation, the set temperature is cleared, and shift starts from the point when switching is made.
- (7) The indoor fan speed does not change even when the fan speed mode is changed.
- (8) When operation is stopped during sleep operation, the set temperature when stopped, as well as the time, continue to be counted.
- (9) If the set time is changed during sleep operation, all data including set temperature, time, etc. is cleared and restarted.
- (10) If sleep operation is canceled by the cancel key or sleep key, all data is cleared.







Notes:


- Condition for entering into Hot Dashed mode. When fan set to "Hi" or "Auto mode" and i) Indoor temperature is lower than 18°C, and ii) outdoor temperature is lower than 10°C, and iii) Temperature difference between indoor temperature and set temperature has a corresponding compressor rpm (calculated value in Table 3) larger than WMAX.
- (2) Hot Dashed will release when i) Room temperature has achieved the set temperature + SFTDSW. ii) Thermo off.
- (3) During Hot Dashed operation, thermo off temperature is set temperature (with shift value) +3°C. After thermo off, operation continue in Fuzzy control mode.
- (4) Compressor minimum "ON" time and "OFF" time is 3 minutes.
- (5) During normal heating mode, compressor maximum rpm WMAX will maintain for 120 minutes if indoor temperature is higher than 18°C. No time limit constrain if indoor temperature is lower than 18°C and outdoor temperature is lower than 2°C.
- (6) During Hotkeep or Defrost mode, indoor operation lamp will blink at interval of 3 seconds "ON" and 0.5 second "OFF".
- (7) When heating mode starts, it will enter into Hotkeep mode if indoor heat exchanger temperature is lower than YNEOF + 0.33°C.
- (8) When fan is set to "Med" or "Lo", compressor rpm will be limited to WBEMAX.
- (9) In "Ultra-Lo" fan mode, if indoor temperature is lower than 18°C, indoor fan will stop. If indoor temperature is higher than 18°C + 0.33°C, fan will continue in "Ultra-Lo" mode. During Hotkeep or Defrost mode, fan will continue in "Ultra-Lo" mode.
- (10) During Hot Dashed or outdoor temperature is lower than -5°C, compressor rpm is WMAX2.
- (11) During Hot Dashed, when room temperature reaches set temperature + SFTDSW compressor rpm is actual rpm x DWNRATEW.

Table 3 $\Delta TWMAX$

Temperature	Calculated
difference	compressor rpm
1.66	1965 min ⁻¹
2	2135 min ⁻¹
2.33	2300 min ⁻¹
2.66	2465 min ⁻¹
3	2635 min ⁻¹
3.33	2800 min ⁻¹
3.66	2965 min ⁻¹
4	3135 min ⁻¹
4.33	3300 min ⁻¹
4.66	3465 min ⁻¹
5	3635 min ⁻¹
5.33	3800 min ⁻¹
5.66	3965 min ⁻¹
6	4135 min ⁻¹
6.33	4300 min ⁻¹
6.66	4465 min ⁻¹
7	4635 min ⁻¹
7.33	4800 min ⁻¹
7.66	4965 min ⁻¹
8	5135 min ⁻¹
8.33	5300 min ⁻¹
8.66	5465 min ⁻¹
9	5635 min ⁻¹
9.33	5800 min ⁻¹
9.66	5965 min ⁻¹
10	6135 min ⁻¹
10.33	6300 min ⁻¹
10.66	6465 min ⁻¹
11	6635 min ⁻¹


Notes:

1. See the data in Table 1 on page 47 for each constant in capital letters in the diagrams.




Notes:

- (1) The defrosting inhibit period is set as shown in the diagram below. When defrosting has finished once, the inhibit period is newly set, based on the outdoor temperature when the compressor was started. During this period, the defrost signal is not accepted.
- (2) If the difference between the room and outdoor temperatures is large when defrosting is finished, the maximum compressor speed (WMAX) or (WMAX2) can be continued for 120 minutes maximum.
- The defrosting period is 20 minutes maximum. (3)
- When operation is stopped during defrosting, it is switched to auto refresh defrosting. (4)
- Auto refresh defrosting cannot be engaged within 15 minutes after operation is started or (5) defrosting is finished.



Reverse cycle operation time < [DEFCOL] : The time corresponding to outdoor temperature is set.



Notes:

- The sleep operation starts when the sleep key is p (1) (2) When the sleep key is set, the maximum compress
- is set to "Sleep Silent" (FWSOY). (3) If the operation mode is changed during sleep oper
- control starts.
- (4) The indoor fan speed does not change even when When defrosting is to be set during sleep operation, (5) after defrosting.
- (6) When operation is stopped during sleep operation, th continue to be counted.
- (7) If the set time is changed during sleep operation, al and restarted.
- (8) If sleep operation is cancelled by the cancel key or
- There is no preset temperature shift due to time el (9)


NOTE

1. Refer to the Table 1 Mode data file on page 47 for the constants expressed by capital alphabet letters in the drawing.

6.5hr ►
Lo
eed = WBEMAX
pressed. sor speed is limited to WBEMAX, and the indoor fan
ration, the changed operation mode is set and sleep
the fan speed mode is changed. (Lo) defrosting is engaged and sleep operation is restored
ne set temperature when stopped, as well as the time,
I data including set temperature, time, etc. is cleared
r sleep key all data is cleared. lapse.

REFRIGERATING CYCLE DIAGRAM

MODEL RAS-70YH7/RAC-70YH7




		PRESENT CONDITION	NOL		
INPUT SIGNAL	OPERATION	OPERATION MODE	AIR DEFLECTOR	OPERALING SPECIFICATION	HEFEHENCE
KEY INPUT	STOP	EACH MODE	STOP	ONE SWING (CLOSING AIR DEFLECTOR) ① DOWNWARD ② UPWARD	INITIALIZE AT NEXT OPERATION.
			DURING ONE SWING	STOP AT THE MOMENT.	
		AUTO COOL COOL FAN AUTO DRY	STOP	START SWINGING ① DOWNWARD ② UPWARD ③ DOWNWARD	
	DURING		DURING SWINGING	STOP AT THE MOMENT.	
	OPERATION	AUTO HEAT HEAT CIRCULATOR	STOP	START SWINGING ① DOWNWARD ② UPWARD ③ DOWNWARD	
			DURING SWINGING	STOP AT THE MOMENT.	
THERMO. ON (INTERNAL FAN ON)		AUTO DRY DRY	TEMPORARY STOP	START SWING AGAIN.	
THERMO. ON (INTERNAL FAN OFF)	OPERATION	AUTO HAET HEAT CIRCULATOR	DURING SWINGING	STOP SWINGING TEMPORARILY. (SWING MODE IS CLEARED IF SWING COMMAND IS TRANSMITTED DURING TEMPORARY STOP.)	
MAIN SWITCH	STOP	COOL FAN DRY	STOP DURING ONE SWING	INITIALIZE ① DOWNWARD ② UPWARD	
5		HEAT CIRCULATOR	STOP DURING ONE SWING	INITIALIZE ① DOWNWARD	
MAIN SWITCH OFF	DURING OPERATION	EACH MODE	STOP DURING SWINGING DURING	ONE SWING (CLOSING AIR DEFLECTOR) ① DOWNWARD ② UPWARD	INITIALIZE AT NEXT OPERATION.
			STOP	INITIALIZING CONDITION OF EACH MODE.	
CHANGE OF OPERATION	DURING OPERATION	EACH MODE	DURING SWINGING	STOP SWINGING AND MODE BECOMES INITIALIZING CONDITION.	

DESCRIPTION OF MAIN CIRCUIT OPERATION


RAS-70YH7

1. Reset Circuit



- The reset circuit is used to reset the program to its initial settings when the power is turned on or when the power is recovered after a power failure.
- The micro computer is reset when the reset input is "Hi", and operation is possible when the reset input is "Lo".
- The waveforms at each point when the power is turned on and off are shown in the diagrams.
- When the power is turned on, the voltages of the DC 12V line and DC 5V lines are increased. When the voltage of DC 12V lines reaches about 7V, ZD202 is turned ON, the potential of Q201's base rises and Q202 is turned ON. Since Q202's collector is set to "LO" at this time, Q202 is turned OFF and the reset input of the micro computer is set to "Lo". The DC 5V line voltage has already become 5V at this time and the micro computer starts operation.
- When the power is turned OFF, the voltage of the DC 12V line decreases. When it becomes about 7V, ZD202 is turned OFF, then Q201 is turned OFF, Q202 is turned ON the reset input of the micro computer is set to "Hi' and the micro computer is set to the reset mode.


2. Buzzer Circuit




When the buzzer is to be activated, buzzer output pin (30) of the micro computer alternates between ON and OFF repeatedly at 4kHz and Q301 is turned ON/OFF accordingly. A 4kHz voltage/frequency is applied to the buzzer and the diaphragm of the buzzer vibrates to output 4kHz sound.

3. Initial setting (IC401)

The pre-heating operation start value, ratings of the compressor, maximum rotation speed, etc. are preset in the micro computer.



4. Receive circuit



Infrared signals from the wireless remote controller are received by the light receiving unit and output after being amplified and shaped.

5. Auto Sweep Motor Circuit




Fig. 5-1 Auto Sweep Motor Circuit (Horizontal air deflectors only)

• Fig. 5-1 shows the Auto sweep motor drive circuit; the signals shown in Fig. 5-2 are output from pins (15-(18) of the micro computer.

Micro computer pins			Step	width			Horizor	
Horizontal air deflectors	1	2	3	4	5	6	7	8
(10)				<u> </u>	 	 		
(11)			 	 	 	 		
(12)		 	 	 		 	 	
(13)		1 		1 1 1 1	 		 	

Fig. 5-2 Micro computer Output Signals


• As the micro computer's outputs change as shown in Fig. 5-2, the core of the auto sweep motor is excited to turn the rotor. Table 5-1 shows the rotation angle of horizontal air deflectors.

Table 5-1	Auto	sweep	Motor	Rotation
-----------	------	-------	-------	----------


	Rotation angle per step (°)	Time per step (ms)
Horizontal air deflectors	0.0879	10

6. Room Temperature Thermistor Circuit

- Fig. 6-1 shows the room temperature thermistor circuit.
- The voltage at (A) depends on the room temperature as shown in Fig. 6-2.




7. Heat exchanger temperature thermistor circuit






- The circuit detects the indoor heat exchanger temperature and controls the following.
 - (1) Low-temperature defrosting during cooling and dehumidifying operation.

The voltage at A depends on the heat exchanger temperature as shown in Fig. 7-2.







8. Temporary Switch



- The temporary switch is used to operate the air conditioner temporarily when the wireless remote control • is lost or faulty.
- The air conditioner operates in the previous mode at the previously set temperature. However, when the . power switch is set to OFF, it starts automatic operation.



<Exp. of circuit wave>



- Fan motor will receive signal thru Joint Connector with VDC (Motor Drive Voltage), VCC (Motor Controller Power Supply), VSC (RPM Instruction) motor WCC return the FG sinal under frequency RPM.
 - The circuit produces fan motor drive from 340V DC supplied from the indoor unit and controls the fan • motor speed.

A CAUTION 1


Indoor fan motor circuit will be connected with primary power source line and please take care of the electrical shock.

A CAUTION 2

Please do not disconnect the fan motor connector during running due to the high voltage supply, it will cause the damage at fan motor and PWB.

RAC-70YH7

1. Power Circuit





% This circuit full-wave rectifies 220-240VAC applied between terminals L and N and boosts it to a required voltage with the IPM to create a DC voltage.

The voltage become 320-360V when the compressor is operated.

※ Importance component

- (1) Intelligence Power Module (IPM)A module that constitute by an inverter part.
- (2) Diode Stack (DB1, DB601, DB602)These rectify the 220-240VAC from terminal L and N to a DC power supply.

<Reference>


In case of Intelligence Power Module malfunction or connection failure immediately after compressor starts, its may stop due to error of [abnormal low speed], [switching failure],[Ip stop] and others.

<Reference>

If diode stack (DB601,DB602) are faulty, DC voltage may not be generated and the compressor may not operate at all. Also be aware that the 3.15A fuse might have blown.

(3) Smoothing capacitors (CO21 ~ CO24, 400 μ F, 450V)

This smoothes (averages) the voltage rectified by the diode stack.




(4) IGBT to improve efficiency (Q601,Q602)

It will improve the efficiency during compressor load become heavy when current flow thru the chopper period of Q601, Q602.

(5) C001 ~ C007, C015, C016, C026, C027, L004, L005

These absorb electrical noise generated during operation of compressor and also absorb external noise entering from power line to protect electronic parts.

(6) Surge Absorber, Varistor1, 2, 3These absorbs external power surge.



*Be careful to avoid an electric shock as a high voltage is generated. Also take care not to cause a short-circuit through incorrect connection of test equipment terminals. The circuit board can be damage.


2. PWB for power circuit

Voltage specification of power circuit as shown in below table. <Checking point>

Output	Spec	Main load	Measuring point	Example of possible failure mode.
5V 0/P	5 ±0. 4V	Micon, Thermistor	Tester⊕ : L105(5V) Tester⊖ : J25(0V)	Outdoor not operate, no blinking indication
12V 0/P	$12^{\pm 1}V$	Micon, IC2,3,4 Relay circuit	Tester⊕ : L104(12V) Tester⊖ : J25(0V)	Outdoor not operate, no blinking indication
16V 0/P	15. 5±1.5V	IPM for Comp IPM for DC fan	Tester⊕ : J58(16V) Tester⊖ : J25(0V)	Stop : LD301 3,4 or 12 times blinking
PAM-15V 0/P	15 ±1.55 ∨	ACT circuit	Tester⊕ : J23(PAM-15V) Tester⊝ : J25(OV)	Stop : LD301 14 times blinking

*Power circuit for pwb can consider normal if the result is satisfied with above specification.

3. Reversing valve control circuit



 Reversing valve control circuit can switch reversing valve ON/OFF according to instruction from indoor microcomputer depending on the operation condition shows in Table 3-1.
 Voltage at each point in each operation condition is approximately as shown below when measured by tester. (When collector voltage of Q401 is measured)

Op	peration condition	Collector voltage of Q401
Cooling	General operation of Cooling	About 0.8V
	In normal heating operation	About 35V
Heating	MAX. rotation speed instructed by indoor microcomputer after defrost is completed	About 35V
	Defrosting	About 0.8V
Dehumidifying	Sensor dry	About 0.8V

Table 3-1	
-----------	--

4. Temperature Detection Circuit




Fig. 4-1

- * OH thermistor circuit detect the temperature at the surface of compressor head, DEF thermistor circuit detect the defrosting operation temperature.
- * A thermistor is a negative resistor element which has characteristics that the higher(lower) the temperature, the lower(higher) the resistance.
- * When the compressor is heated, the resistance of the OH thermistor becomes low and \oplus 5V is divided by OH thermistor and R301 and the voltage at pin 66 of microcomputer.
- * Compare the voltage at microcomputer pin 66 and setting value stored inside. If the value exceed the set value, microcomputer will judge that the compressor is overheated and stop the operation.
- * When frost is formed on the outdoor heat exchanger, the temperature at the exchanger drops abruptly. Therefore the resistance of the DEF thermistor becomes high and the voltage at pin 65 of micro computer drops. If this voltage becomes lower than the set value stored inside, microcomputer will enter the defrost control.
- * During defrost operation, the microcomputer will transfer the defrosting condition command to indoor unit via SDO pin of interface of IF transmission output.
- * The microcomputer read the outdoor temperature by Outside Air thermistor and transfer it to the indoor unit, thus controlling the compressor rotation speed according to the set value in the EEPROM of indoor unit and switching the operation mode (outdoor fan on/off etc.) to DRY mode.

Below table show the typical values of outdoor temperature in relation to the voltage.


lable 4-1						
Outside Air Temperature (°C)	-10	0	10	20	30	40
Voltage at both side of R3O3 (V)	1.19	1.69	2. 23	2.75	3. 22	3.62

<Reference>


When the thermistor is open open condition or disconnect, microcomputer pin $65 \sim 67$ are approx.OV; When thermistor is shorted, they are approx.5V and LD301 will blink 7 times.

However, an error is detected when only the OH thermistor is shorted and will enter blinking mode after 12 minutes start the compressor operation.

5. Electric expansion valve circuit



- * The electric expansion value is driven by DC12V. Power is supplied to 1 or 2 phases of 4-phase winding to switch magnetic pole of winding in order to control the opening degree.
- Relationship between power switching direction of phase and open/close direction is shown below.
 When power is supplied, voltages at pins 4 to 1 of CN15 are about 0.9V and 12V when no power is supplied.
 When power is reset, initial operation is performed for 10 or 20 seconds. During initial operation, measure all voltages at pin 4 to 1 of CN15 by using a multimeter. If there is any pin with voltage that has not changed from 0.9V or 12V, expansion valve or micro computer is broken.



* Fig. 5-1 shows logic waveform when expansion valve is operating.

With expansion valve control, opening degree is adjusted to stabilize target temperature by detecting compressor head temperature. The period of control is about once per 20 seconds and output a few pulse.

6. Outdoor DC fan motor control circuit

* This model is built with DC fan motor control circuit inside outdoor electrical unit.




Fig	6—	1
-----	----	---

This DC fan motor is control by outdoor micro computer that follow the operating instruction received from indoor micro computer. The DC current that flow from R741 will presume actual operation speed and control the rotation to follow the operating instruction. Based on this DC current it will detect a over current and other fan motor failure.

(1) Fan motor speed controller during starting

Due to the interference of strong wind etc., operation movement is changed based on fan direction and rotation speed as shown below during starting of operation. In addition, the fair wind is define as wind that blow to outside direction using Mouth Ring part. At strong and contrary wind ... The rotational speed is not controlled as to protect the equipment

and fan will rotate reversely depend on the wind. Automatically


	start when wind condition become weak.
At contrary wind	The rotational speed is controlled in fair wind direction after it
	slowly reduce the speed and finally stop.
At fair wind	The rotational speed is controlled as it is.
At strong fair wind	The rotational speed is not controlled as to protect the equipment
	and fan will rotate reversely depend on the wind. Automatically
	start when wind condition become weak.

(2) Fan motor speed controller during unit operating

There is a case where fan rpm is reducing during rotating caused by interference of strong wind If this condition continue in long period, fan will stop rotating. (LD301 : 11 times blinking) The unit will restart according to control as per during start (1).

- (3) Method of confirming self diagnosis LD301 lamp : 12 times blinking If the unit stop and LD301 on the pwb blinking 12 times [fan lock stop is detected], follow below steps to confirm it.
 - Fan lock stop is detected when something has disturb the fan rotation by inserting material into propeller fan or ice has growing inside outdoor unit caused by snow. Remove it if found something is bloking the fan.
 - 2. Confirmed that CN24 connector is securely inserted. Fan lock stop is detected also when connector is not properly inserted. Please securely insert if found any disconnection.
 - 3. Fan lock stop also can be detected where strong wind blown surrounding the unit. Please confirm after restart the unit. (It may take few minutes to operate the compressor) It is not a malfunction of electrical unit or fan motor if the unit run continuesly after restart the unit.
 - 4. Check fan motor condition as below procedure.

[Checking Fan Motor] procedure



5. Reconnect again fan motor connector (CN24).

*Please confirm above checking procedure if found F4(3.15A fuse) blown.

If fan motor is broken, replace both electrical unit and fan motor. Reference

**No power is supllied to the outdoor unit if F4(3.15A Fuse) is blown.


Both DC fan motor and switching power supply is using same fuse.

Caution


*Beware of electric shock due to high voltage when conducting an operation check. Power supply for DC fan motor and compressor is common (DC260~360V).

SERVICE CALL Q & A


COOLING MODE




AUTO FRESH DEFROSTING




AT STARTING OPERATION







TROUBLE SHOOTING

PRECAUTIONS FOR CHECKING





DISCHARGE PROCEDURE AND METHOD TO STOP ENERGIZE THE POWER CIRCUIT




[Other cautions]


(1) Disconnection of tab terminal receptacle

All receptacle used to connect with tab terminal are built with lock mechanism. Please take note that by using a force to pull out the receptacle without releasing the lock, can cause a damage. Furthermore, during connecting the receptacle back make sure to securely insert until end.


* Receptacle type and procedure to releasing the lock



Vertical type (with plastic casing) Pull out by holding the plastic casing.



Vertical type (without casing) Pull out while pushing the release button.



Horizontal type (with insulation sleeve)


Pull out from top of insulation sleeve while pushing the release button.

(2) Disconnecting on board connector

On board connector with lock machanism are widely used. Please take note that by using a force to pull out with out releasing the lock mechanism, can cause a damage.

Furthermore, during inserting back the connector make sure it surely done.

Release lock with finger before disconnecting.




(3) Connector disconnection during discharge is prohibited


Disconnecting connector during discharge is extremely prohibited.Component on board and fan motor will damage. Proceed trouble shooting process after confirming smoothing capacitor of indoor & outdoor pwb has been discharge.

CHECKING THE INDOOR TIMER LAMP IF BLINKING 1 TIME

<Caution> Please turn OFF power supply before proceed with below checking flow.



CHECKING THE INDOOR/OUTDOOR UNIT ELECTRICAL PARTS AND REFRIGERATING CYCLE



Perform troubleshooting according to the number of times the indoor timer lamp and outdoor LD301 blink.

SELF-DIAGNOSIS LIGHTING MODE

No.	Blinking of Timer lamp	Reason for indication	Possible cause
1	5560. — — — — — — 1 time	Reversing valve defective When the indoor heat exchanger temperature is too low in the heating mode or it is too high in the cooling mode.	 Reversing valve defective Heat exchanger thermistor disconnected (only in the heating mode) (Note) The malfunction mode is entered the 3rd time this abnormal indication appears (read every 3 minutes).
2	586C 2 times	Outdoor unit forced operation When the outdoor unit is in forced operation or balancing operation after forced operation	Electrical parts in the outdoor unit
3	588C. 3 times	Indoor/outdoor interface defective When the interface signal from the outdoor unit is interrupted.	 Indoor interface circuit Outdoor interface circuit
4	5 5 560. — — 4 times	Outdoor electrical assembly defective.	Please check at the outdoor electrical led lamp blinking (LD301) and refer to self diagnosis lighting mode for outdoor unit.
5	5 580 – − 9 times	Room thermistor or heat exchanger thermistor is faulty When room thermistor or heat exchanger thermistor is opened circuit or short circuit.	(1) Room thermistor(2) Heat exchanger thermistor
6	5 5∞. 10 times	Over-current detection at the DC fan motor when over-current is detected at the DC fan motor of the indoor unit.	 Indoor fan locked Indoor fan motor Indoor control P.W.B.
7	5‱ − − 13 times	IC401 or IC402 data reading error When data read from IC401 or IC402 is incorrect.	IC401 or IC402 abnormal


<Cautions>

※1


- (1) If the interface circuit is faulty when power is supplied, the self-diagnosis display will not be displayed.
- (2) If the indoor unit does not operate at all, check to see if the F-cable is connected or disconnected.
- (3) To check operation again when the timer lamp is blinking, you can use the remote control for operation (except for mode mark %1).

CHECKING INDOOR UNIT ELECTRICAL PARTS


1. Power does not come on (no operation)




2. Outdoor unit does not operate (but receives remote infrared signal)




3. Only indoor fan does not operate (other is normal)




4. Air deflector does not move (others are normal)




5. All systems stop from several seconds to several minutes after operation is started (all indicators are also off)





6. Check the main P.W.B (power circuit)




CHECKING THE OUTDOOR UNIT ELECTRICAL PART









SELF CHECK

When self-diagnosis lamp blinks 2,3,4 and 5 times happen, to determine whether compressor faulty or electrical unit faulty, please conduct a SELF CHECK as below.

- 1. Switch OFF main power supply.
- 2. Short circuit between JW001 and JW002.
- 3. Switch ON main power supply LD302 will blink 1 time.
- 4. (Within 3 minutes) Press Test/Service Switch for 1 second or more.
- 5. Self-diagnosis result will be shown LD303 will ON (LIT) and LD301 will be blinking. Then refer to diagnosis table 2.
- 6. Switch OFF main power supply. Then release back JW001 and JW002 to original condition (no short circuit condition).
- * If step No. 6 is not carried out, the system will not operate properly until 3 minutes has lapsed after restore the power supply.

* SELF CHECK diagnosis result

SELF-DIAGNOSIS LIGHTING MODE 🛛 LIT 🛛 BLINKING 🗆 OFF					
L L L D D D 3 3 3 0 0 0 1 2 3 RED RED RED	SELF-DIAGNOSIS RESULT	REPAIR METHOD			
	ELECTRICAL OK	① CHANGE COMPRESSOR			
2 TIMES	PEAK CURRENT CUT OFF	© CHANGE P.W.B.s			
7 TIMES	COMPRESSOR CURRENT ABNORMAL	 ◎ IF COMPRESSOR CONNECTOR LOOSE OR NG - CHECK CONNECTOR CONDITION ◎ IF COMPRESSOR CONNECTOR OK, - CHECK COMPRESSOR, CHANGE P.W.B.S 			
Ø □ ■ 10 TIMES	DC VOLTAGE ABNORMAL	 IF AC VOLTAGE INPUT ABNORMAL (OVER STANDARD VOLTAGE ±10%), FOLLOW STANDARD AC VOLTAGE INPUT IF AC VOLTAGE INPUT IS NORMAL (WITHIN ±10%), CHANGE P.W.B.S 			
□ □ ■ EEPROM READING ERROR		© Change P.W.B. Main			

In case abnormalities found in measurement result, change the defect part.

In case electrical is normal and before it can be use, modify back

JW001 and JW002 as normal condition (before conduct a self check).

In case of service person forgot to release JW001 and JW002 to original condition;

Case 1:

If main power supply continuously ON, outdoor microcomputer will keep showing diagnosis result (LD303 will ON and LD301 will blinks).

<u>Case 2:</u>

If main power supply OFF at once, then switch ON again:

a) Outdoor microcomputer will wait the self check command (by pressing test/service switch) within 3 minutes (LD302 blinks 1 time).

If test/service signal input is not received, unit will return to normal operation mode after this 3 minutes has lapsed. (LD302 OFF and LD301 blinks 1 time).


<u>Case 3:</u>

If main power supply OFF at once, then switch ON again and on indoor unit by remote control;

- a) Indoor unit will receive remote control signal and send signal to outdoor unit. For the first 3 minutes, outdoor micro-computer will ignore this indoor signal (LD302 blinks 1 time).
- b) After 3 minutes has lapsed (LD302 OFF and LD301 blinks 1 time), unit will return to normal operation mode.

HOW TO OPERATE USING OUTDOOR UNIT TEST SWITCH

- 1. Pull out power cord plug and wait for 1 minute before plug in again.
- 2. Remove outdoor electrical cover and confirm that LD301 will blink 1 time.
- 3. Force cooling operation is start when TEST SWITCH is pressed for 1 second or more.
 - ※ (There is a case where operation will only start after 1 minute after pressing the TEST SWITCH due to initilizing of the expansion valve)
- 5. Press again the TEST SWITCH for about 1 minute or more to stop the force cooling operation.




※ Caution

- 1. Turn OFF the breaker first before can start servicing.
- 2. Never operate the unit in this condition for more than 5 minutes.
- If the checking is done with the compressor connector disconnected, the unit will continue normal operation when electrical part are normal, or it will repeat operating for approximate 1 minute and stop due to overload power limit cut
- 4 If interface signal (DC35V) terminal C and D are not connected when the outdoor unit TEST SWITCH is used for checking,LD301 will blink 9 times after operation to indicate a communication error.
- 5. To proceed with TEST SWITCH operation again, breaker must be turn OFF and ON it again. (TEST SWITCH will operate 1 time only once power is supplied)
- 6 When service operation is completed, restore the connection as original condition.

LIGHTING MODE OF SELF-DIAGNOSIS LAMP


POSITION OF SELF-DIAGNOSIS LAMP

1




LIGHTING MODE SELF-DIAGNOSIS LAMP

2 LIGHTING MODE SELF-DIAGNOSIS LAMP




CHECKING THE REMOTE CONTROLLER



CHECKING THE REFRIGERATING CYCLE


(JUDGING BETWEEN GAS LEAKAGE AND COMPRESSOR DEFECTIVE)

1. Troubleshooting procedure (No operation, No heating, No cooling)



PARTS LIST AND DIAGRAM

INDOOR UNIT MODEL : RAS-70YH7




MODEL RAS-70YH7

NO.	PART NO.	Q'TY / UNIT	PARTS NAME
1	PMRAS-30CHP6 00	2 1	CABINET ASSY
2	PMRAS-72CHA3 01	3 1	MOUNTING PLATE
3	PMRAS-80YHA R0	1 1	FAN MOTOR
4	PMRAS-80YHA R0	4 1	TANGENTIAL FAN
5	PMRAS-72CHA3 01	7 1	P-BEARING ASSY
6	PMRAS-72CHA3 00	7 1	FAN MOTOR SUPPORT
7	PMRAS-70YH7 R0	3 1	CYCLE ASSY
8	PMRAS-72CHA3 00	5 1	BEARING COVER
9	PMRAS-24CE9G 00	4 1	PIPE SUPPORT (U-COVER)
10	PMRAS-80YHA R0	5 1	DRAIN PAN ASSY
11	PMRAS-72CHA3 R0	1 4	AUTO SWEEP MOTOR
12	PMRAS-70YH7 R0	4 1	P.W.B (LED)
13	PMRAS-80YH5 00	3 1	FRONT COVER ASSY
14	PMRAS-80YH5 00	2 1	FRONT PANEL
15	PMRAS-10C7M 00	3 3	САР
16	PMRAS-72CHA3 00	9 1	FILTER (R)
17	PMRAS-70YH7 R0	2 1	REMOTE CONTROL ASSY
18	PMRAS-10C3M 00	3 1	REMOTE CONTROL SUPPORT
19	PMRAS-72CHA3 00	3 1	FILTER (L)
20	PMRAS-72CHA3 R2	2 1	THERMISTOR
21	PMRAS-70YHA1 00	6 1	S-COVER R
22	PMRAS-70YH7 R0	1 1	P.W.B (MAIN)
23	SVP-2WDS62329A	1	SE-COVER
24	PMRAS-72CHA3 01	5 1	P.W.B (RECEIVER)
25	PMRAS-72CHA3 02	4 1	FAN COVER
26	PMRAS-72CHA3 01	3 1	PIPE SUPPORT

PARTS LIST AND DIAGRAM

OUTDOOR UNIT MODEL : RAC-70YH7




MODEL RAC-70YH7

NO.	PART NO.		Q'TY / UNIT	PARTS NAME
1	PMRAC-60YH7	S01	1	COMPRESSOR
2	KPNT1	001	6	PUSH NUT
3	RAC-2226HV	805	3	COMPRESSOR RUBBER
4	PMRAC-70YHA	S03	1	CONDENSER
5	PMRAC-70YHA1	999	1	REVERSING VALVE
6	PMRAC-25NH4	S03	1	ELECTRICAL EXPANSION COIL
7	PMRAC-80YHA	905	1	VALVE (5S)
8	PMRAC-50NH4	S03	1	VALVE (2S)
9	PMRAM-72Q8	S03	1	THERMISTOR (OH)
10	PMRAC-25NH4	S09	1	OVERHEAT THERMISTOR SUPPORT
11	PMRAC-X13CX	906	1	OVERLOAD RELAY COVER
12	PMRAC-50YHA2	S07	1	THERMISTOR (DEFROST)
13	PMRAC-50YHA2	S09	1	COIL (REVERSING VALVE)
14	PMRAC-50YHA2	S04	1	REACTOR
15	PMRAC-70YHA2	S01	1	P.W.B (MAIN)
16	PMRAC-70YHA2	S02	1	P.W.B (IPM)
17	PMRAS-25NH4	S13	1	TERMINAL BOARD (4P)
18	PMRAM-72Q8	S03	1	THERMISTOR (OUTSIDE TEMPERATURE)
19	PMRAC-70YHA	907	1	PROPELLER FAN
20	PMRAC-70YHA	S12	1	SUPPORT (FAN MOTOR)
21	PMRAC-70YHA2	S05	1	FAN MOTOR
22	PMRAC-70YHA	S01	1	CABINET
23	PMRAC-70YHA	S06	1	NET
24	PMRAC-24CP5	905	1	TOP COVER
25	PMRAC-70YHA	S09	1	SIDE PLATE-R
26	PMRAC-70YHA2	S04	1	STRAINER (COND)
27	PMRAC-70YHA	910	1	STRAINER (PIPE)
28	PMRAC-70YHA	908	1	SIDE PLATE-L
29	PMRAC-70YHA	S05	1	GRILL
30	PMRAC-80YHA	906	1	EXPANSION VALVE
31	PMRAC-70YHA	915	1	SV-COVER
32	PMRAC-70YHA	916	1	NET COVER
33	PMRAC-63CA1	S02	1	TERMINAL BOARD (2P)
34	PMRAC-70YHA2	S03	1	P.W.B (NF-BOARD)

HITACHI

RAS-70YH7 / RAC-70YH7



Printed in Malaysia