
Service Manual

(Mono bloc) Air-to-Water Heatpump System



Mono bloc Unit WH-MXC09D3E5 WH-MXC12D6E5 (WH-MXC09D3E5-1) (WH-MXC12D6E5-1)

WARNING

This service information is designed for experienced repair technicians only and is not designed for use by the general public. It does not contain warnings or cautions to advise non-technical individuals of potential dangers in attempting to service a product. Products powered by electricity should be serviced or repaired only by experienced professional technicians. Any attempt to service or repair the product or products dealt with in this service information by anyone else could result in serious injury or death.

PRECAUTION OF LOW TEMPERATURE

In order to avoid frostbite, be assured of no refrigerant leakage during the installation or repairing of refrigeration circuit.

Panasonic[®]

© Panasonic Appliances Air-Conditioning (M) Sdn. Bhd. 2012. Unauthorized copying and distribution is a violation of law.

TABLE OF CONTENTS

		FAGE			AGE
1.	Saf	ety Precautions3	13. Pr	otection Control	69
2.	Spe	ecifications5	13.1	Protection Control For All Operations	69
	-	WH-MXC09D3E5 (WH-MXC09D3E5-1)5	13.2	Protection Control For Heating Operation	71
		WH-MXC12D6E5 (WH-MXC12D6E5-1)7		Protection Control For Cooling Operation	
3.	Fea	tures9	14. Se	rvicing Mode	73
4.	Loc	eation of Controls and Components10		Test Run	
		Mono Bloc Unit10		Proper Pump Down Procedure	
				How To Adjust Water Flow Rate Expansion Vessel Pre Pressure	/ 3
5.	Din	nensions18	17.7	Checking	73
	5.1	Mono Bloc Unit18	15. Ma	nintenance Guide	
6.	Ref	rigeration and Water Cycle Diagram19	16. Tro	oubleshooting Guide	76
7.	Blo	ck Diagram21		Refrigeration Cycle System	
	7.1	WH-MXC09D3E5 (WH-MXC09D3E5-1)21		Relationship Between The Condition Of	, 0
		WH-MXC12D6E5 (WH-MXC12D6E5-1)22		The Mono Bloc Unit And Pressure And	
		, , , , , , , , , , , , , , , , , , ,		Electric Current	77
8.	Wir	ing Connection Diagram23	16.3	Breakdown Self Diagnosis Function	
	8.1	WH-MXC09D3E5 (WH-MXC09D3E5-1)23		Error Codes Table	
		WH-MXC12D6E5 (WH-MXC12D6E5-1)25	16.5	Self-diagnosis Method	81
9.	Ele	ctronic Circuit Diagram27	17. Dis	sassembly and Assembly Instructions	114
	9.1	WH-MXC09D3E5 (WH-MXC09D3E5-1)27	17.1	To Remove The Cabinet Front Plate	114
		WH-MXC12D6E5 (WH-MXC12D6E5-1)29	17.2	To Remove The Cabinet Top Plate	114
		· · · · · · · · · · · · · · · · · · ·	17.3	To Remove The Cabinet Rear Plate	115
10). Prii	nted Circuit Board31		To Remove Pressure Gauge	
	10.1	Water System31		To Remove RCCB	115
		Refrigerant System33	17.6	To Remove Transformer and Electronic	
11	Inc	tallation Instruction		Controller Board	116
• •		no Bloc Unit35	17.7	To Remove Pressure Relief Valve and	440
			17.0	Air Purge Valve To Remove Flow Switch	
		Select The Best Location37		To Remove Water Pump	
		Mono Bloc Unit Installation		0To Remove Bottle Complete	
		Piping Installation38		•	
	11.4	Connect The Cord And Cable To Mono Bloc Unit39	18. Te	chnical Data	118
			18.1	Operation Characteristics	118
12	. Op	eration and Control44	18.2	Heating Capacity Table	122
	12.1	Basic Function44		Cooling Capacity Table	
	12.2	Water Pump58	18.4	Hydraulic Pump Performance	123
	12.3	Pump Down Operation58	19 Fx	ploded View and Replacement Parts	
	12.4	Flow Switch59		st	124
		Force Heater Mode Operation59			
		Mono Bloc Unit Safety59		(Refrigerant System)	
		Auto Restart Control59	19.2	(Water System)	129
		Indication Panel60			
		Back-Up Heater Control60			
		Tank Booster Heater Control60			
		Base Pan Heater Control (Optional)61			
		Three Way Valve Control			
		Sterilization Mode			
	12.14	Quiet Operation			
		Anti Freeze Control			
		Solar Operation (Optional)63 External Room Thermostat Control			
	14.17	(Optional)67			
	12 19	Two ways valve control68			
	12.10	1 1 10 11 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1			

1. Safety Precautions

- Read the following "SAFETY PRECAUTIONS" carefully before perform any servicing.
- Electrical work and water installation work must be installed or serviced by a licensed electrician and licensed water system installer respectively. Be sure to use the correct rating and main circuit for the model installed.
- The caution items stated here must be followed because these important contents are related to safety. The meaning of each indication used is as below. Incorrect installation or servicing due to ignoring of the instruction will cause harm or damage, and the seriousness is classified by the following indications.

\triangle	WARNING	This indication shows the possibility of causing death or serious injury.
\triangle	CAUTION	This indication shows the possibility of causing injury or damage to properties.

• The items to be followed are classified by the symbols:

\bigcirc	This symbol denotes item that is PROHIBITED from doing.

 Carry out test run to confirm that no abnormality occurs after the servicing. Then, explain to user the operation, care and maintenance as stated in instructions. Please remind the customer to keep the operating instructions for future reference.

	(!) WARNING	
1.	Do not modify the machine, part or material during repairing service.	\Diamond
2.	If wiring unit is supplied as repairing part, do not repair or connect the wire even partial wire break. Exchange the whole wiring unit.	\Diamond
3.	Do not wrench the fasten terminal. Pull it out or insert it straightly.	\Diamond
4.	Do not install Mono bloc unit near handrail of veranda. When installing Mono bloc unit at veranda of high rise building, child may climb up to Mono bloc unit and cross over the handrail and causing accident.	\Diamond
5.	Do not use unspecified cord, modified cord, join cord or extension cord for power supply cord. Do not share the single outlet with other electrical appliances. Poor contact, poor insulation or over current will cause electrical shock or fire.	\Diamond
6.	Do not tie up the power supply cord into a bundle by band. Abnormal temperature rise on power supply cord may happen.	\Diamond
7.	Do not insert your fingers or other objects into the unit, high speed rotating fan may cause injury.	0
8.	Do not sit or step on the unit, you may fall down accidentally.	\Diamond
9.	Keep plastic bag (packaging material) away from small children, it may cling to nose and mouth thus causing suffocation.	0
10	. Do not use pipe wrench to install refrigerant pipe. Using pipe wrench may deform the pipes and cause unit malfunction.	\Diamond
11	. Do not purchase unauthorized electrical parts for installation, service, maintenance and etc They might cause electrical shock or fire.	\Diamond
12	. Do not modify the wiring of Mono bloc unit for installation of other components (i.e. heater, etc). Overloaded wiring or wire connection points may cause electrical shock or fire.	0
13	. For electrical work, follow local wiring standard, regulation and this installation instruction. An independent circuit and single outlet must used. If electrical circuit capacity is not enough or defect found in electrical work, it will cause electrical shock or fire.	be
14	. For water circuit installation work, follow to relevant European and national regulations (including EN61770) and local plumbing and buil regulation codes.	lding
15	. Must engage an authorized dealer or specialist for installation. If installation is defective, it will cause water leakage, electrical shock or f	fire.
16	. Install according to this installation instructions strictly. If installation is defective, it will cause water leakage, electrical shock or fire.	
17	. Only use the supplied or specified installation parts. Else, it may causes Mono bloc unit vibrate, fall, water leakage, electrical shock or fi	re.
18	. Install at a flat, strong and firm location which is able to withstand the Mono bloc unit's weight. If the location is slanting, or strength is no enough the set will fall and cause injury.	ot

- 19. This equipment is strongly recommended to be installed with Residual Current Device (RCD) on-site according to the respective national wiring rules or country-specific safety measures in terms of residual current.
- 20. The unit is only for use in a closed water system. Utilization in an open water system may lead to excessive corrosion of the water piping and risk of incubating bacteria colonies, particularly Legionella, in water.
- 21. If there is any doubt about the installation procedure or operation, always contact the authorized dealer for advice and information.
- 22. Select a location where in case of water leakage, the leakage will not cause damage to other properties.
- 23. When installing electrical equipment at wooden building of metal lath or wire lath, in accordance with electrical facility standard, no electrical contact between equipment and building is allowed. Insulator must be installed in between.
- 24. This installation may be subjected to building regulation approval applicable to respective country that may require to notify the local authority before installation.
- 25. Any work carried out on the Mono bloc unit after removing the front panel which is secured by screws, must be carried out under the supervision of authorized dealer and licensed installation contractor.
- 26. This unit must be properly earthed, the electrical earth must not be connected to a gas pipe, water pipe, the earth of a lightening rod or a telephone. Otherwise there is a danger of electrical shock in the event of an insulation breakdown or electrical earth fault in the Mono bloc unit.
- 27. When replace refrigeration circuit components, confirm on usage of specified refrigerant type. Using of refrigerant other than the specified type may cause product damage, burst and injury etc.
- 28. Do not add or replace refrigerant other than the specified type. Equipment may damage or deteriorate in safety due to usage of other refrigerant.

CAUTION

- Do not install the Mono bloc unit in areas where there is a risk of flammable gas leakage. There is a risk of fire if flammable gas accumulates near or around the Mono bloc unit.
- Do not release refrigerant during piping work for installation, re-installation and during repairing a refrigeration parts. Take care of the liquid refrigerant, it may cause frostbite.
- Make sure the power supply cord does not contact with hot part (i.e. water piping). High temperature may cause insulator of power supply cord damage hence electrical shock or fire

Do not touch the sharp aluminum fins or edges of metal parts. If you are required to handle sharp parts during installation or servicing, please wear hand glove. Sharp parts may cause injury.

- Do not apply excessive force to water pipes that may damage the pipes. If water leakage occurs, it will cause flooding and damage to other properties.
- Carry out drainage piping as mentioned in installation instructions. If drainage is not perfect, water leakage may happen and may cause damage to properties of the user.
- The piping installation work must be flushed before the Mono bloc unit is connected to remove contaminants. Contaminants may damage the Mono bloc unit components.
- Select an installation location where it is accessible for maintenance.
- Power supply connection to Mono bloc unit.
 - Power supply point should be in easily accessible place for power disconnection in case of emergency.
 - Must follow local national wiring standard, regulation and this installation instruction.
 - Strongly recommended to make permanent connection to a circuit breaker. It must be a double pole switch with a minimum 3.0 mm gap. For 9kW models:
 - Use approved 30A circuit breaker for power supply 1
 - For electrical heater connection to main for power supply 2 (either @ or ©)
 - (Backup Heater only)
 - (b) Use approved 30A circuit breaker (Backup Heater + Booster Heater)

For 12kW/14kW/16kW models:

- Use approved 30A circuit breaker for power supply 1
- Use approved 30A circuit breaker for power supply 2
- Use approved 15A/16A circuit breaker for power supply 3
- 10. Ensure the correct polarity is maintained throughout all wiring. Otherwise, it will cause electrical shock or fire.
- 11. After installation, the installer is obliged to verify correct operation of the Mono bloc unit. Check the connection point for water leakage during test run. If leakage occurs, it will cause damage to other properties.
- 12. Installation work.
 - Four or more people are required to carry out the installation work. The weight of Mono bloc unit might cause injury if carried by less than four people.

2. Specifications

2.1 WH-MXC09D3E5 (WH-MXC09D3E5-1)

	Item	Unit	Refrigerant System	
Performance Test Cor	ndition		EN 1	4511
Cooling Condition (Am	nbient/Water)		A35W7	-
Cooling Capacity		kW	7.00	-
		BTU/h	23900	-
		kcal/h	6020	-
EER		W/W	3.11	-
		kcal/hW	2.68	-
Heating Condition (An	nbient/Water)		A7W35	A2W35
Heating Capacity		kW	9.00	9.00
		BTU/h	30700	30700
		kcal/h	7740	7740
COP		W/W	4.74	3.53
		kcal/hW	4.07	3.04
Air Flow		m³/min (ft³/min)	Cooling: 89.5 (3160) Heating: 76.8 (2710)	
Refrigeration Control I	Device		Expansion Valve	
Refrigeration Oil		cm ³	FV50S (1200)	
Refrigerant (R410A)		kg (oz)	2.30 (81.2)	
Pipe Diameter	Liquid	mm (inch)	9.52 (3/8)	
	Gas	mm (inch)	15.88	3 (5/8)
Compressor	Туре		Hermetic M	otor (Rotary)
	Motor Type		Brushless (4-poles)	
	Rated Output	kW	3.	00
Fan	Туре		Propel	ler Fan
	Material		P	P
	Motor Type		Induction	(8-poles)
	Input Power	W	-	_
	Output Power	W	6	60
	Fan Speed	rpm		an) 580 (Bottom Fan) an) 530 (Bottom Fan)
Heat Exchanger	Fin material		Aluminium	(Pre Coat)
	Fin Type		Corrug	ated Fin
	Row × Stage × FPI		2 × 5	1 × 18
	Size (W × H × L)	mm	881.5 × 1	295.4 × 44

Item		Unit	Mono Bloc Unit	
Dimension	Height	mm (inch)	1410 (55.5)	
	Width	mm (inch)	1283	(50.5)
	Depth	mm (inch)	320 (12.6)
Net Weight	<u>.</u>	kg (lbs)	155 (342)	
Noise Level		dB-A	Cooling: 49 Heating: 49	Cooling: - Heating: -
			Cooling: 67 Heating: 66	Cooling: - Heating: -
Power Source (Pha	ase, Voltage, Cycle)	Ø	Single	
		V	230	
		Hz	50	
Input Power		kW	Cooling: 2.25 Heating: 1.90	Cooling: - Heating: 2.55
Maximum Input Power For Mono bloc Unit		kW	5.41	
Power Supply 1: Phase (ø) / Max. Current (A) / Max. Input Power (W)			Single / 25.0 / 5.41k	

	Item	Unit	Mono Bloc Unit		
Power Supply 2: Phas	se (ø) / Max. Current (A) / Max. In	put Power (W)	Single / 26.0 / 6.00k		
Power Supply 3: Phas	se (ø) / Max. Current (A) / Max. In	-1-	- / -		
Starting Current		Α	10	1.4	
Running Current		Α	Cooling: 10.4 Heating: 8.8	Cooling: - Heating: 11.8	
Maximum Current For	Mono bloc Unit	Α	25.0		
Power Factor		%	Cooling: 94 Heating: 94	Cooling: - Heating: 94	
Power factor means to	otal figure of compressor and outo	door fan motor.			
Power Cord	Number of core				
Length		m (ft)	-		
Thermostat	•		Electroni	c Control	
Protection Device			Electroni	c Control	

Item			Unit	Water System
Performance Test Conditio	n			EN 14511
Operation Range Outdoor A		mbient	°C	Cooling: 16 ~ 43 Heating: -20 ~ 35
	Water Outlet		°C	Cooling: 5 ~ 20 Heating: 25 ~ 55
Internal Pressure Differenti	al		kPa	Cooling: 10.0 Heating: 15.0
Refrigerant Pipe Diameter	Liquid		mm (inch)	9.52 (3/8)
	Gas		mm (inch)	15.88 (5/8)
Water Pipe Diameter	Inlet		mm (inch)	30 (1-3/16)
	Outlet		mm (inch)	30 (1-3/16)
Water Drain Hose Inner Dia	ameter		mm (inch)	15.00 (19/32)
Pump	Motor Type			Capacitor Run Induction Motor (5 μF)
	No. of Speed			3
	Input Power		W	180
Hot Water Coil	Туре			Brazed Plate
	No. of Plat	es		60
	Size (W x	H x L)	mm	93 x 100 x 325
	Water Flow	v Rate	l/min (m³/h)	Cooling: 20.1 (1.2) Heating: 25.8 (1.6)
Pressure Relief Valve Water	er Circuit		kPa	Open: 300, Close: 265 and below
Flow Switch				Magnetic Lead Switch
Protection Device		A	Residual Current Circuit Breaker (40)	
Expansion Vessel		Volume	I	10
	•	MWP	bar	3
Capacity of Integrated Elec	tric Heater		kW	3.00

Note:

- Cooling capacities are based on outdoor air temperature of 35°C Dry Bulb with controlled water inlet temperature
 of 12°C and water outlet temperature of 7°C.
- Heating capacities are based on outdoor air temperature of 7°C Dry Bulb (44.6°F Dry Bulb), 6°C Wet Bulb (42.8°F Wet Bulb) with controlled water inlet temperature of 30°C and water outlet temperature of 35°C.
- Specification are subjected to change without prior notice for further improvement.

2.2 WH-MXC12D6E5 (WH-MXC12D6E5-1)

	Item	Unit	Refrigerant System	
Performance Test Con	dition		EN 14511	
Cooling Condition (Am	bient/Water)		A35W7	-
Cooling Capacity		kW	10.00	-
		BTU/h	34100	-
		kcal/h	8600	-
EER		W/W	2.78	-
		kcal/hW	2.39	-
Heating Condition (Am	bient/Water)		A7W35	A2W35
Heating Capacity		kW	12.00	12.00
		BTU/h	41000	41000
		kcal/h	10320	10320
COP		W/W	4.67	3.40
		kcal/hW	4.02	2.92
Air Flow		m³/min (ft³/min)	Cooling: 93.3 (3290) Heating: 80.0 (2830)	
Refrigeration Control Device			Expansion Valve	
Refrigeration Oil		cm ³	FV50S (1200)	
Refrigerant (R410A)		kg (oz)	2.30 (81.2)	
Pipe Diameter	Liquid	mm (inch)	9.52 (3/8)	
	Gas	mm (inch)	15.88	(5/8)
Compressor	Туре		Hermetic Mo	otor (Rotary)
	Motor Type		Brushless	(4-poles)
	Rated Output	kW	3.	00
Fan	Туре		Propel	ler Fan
	Material		Р	Р
	Motor Type		Induction	(8-poles)
	Input Power	W	_	_
	Output Power	W	6	0
	Fan Speed	rpm	Cooling: 600 (Top Fa Heating: 510 (Top Fa	an) 640 (Bottom Fan) an) 550 (Bottom Fan)
Heat Exchanger	Fin material		Aluminium	(Pre Coat)
	Fin Type		Corruga	ated Fin
	Row × Stage × FPI		2 × 5	1 × 18
	Size (W × H × L)	mm	881.5 × 12	295.4 × 44

	Item		Mono Bloc Unit	
Dimension	Height	mm (inch)	1410 (55.5)	
	Width	mm (inch)	1283	(50.5)
	Depth	mm (inch)	320 (12.6)
Net Weight		kg (lbs)	155 ((342)
Noise Level		dB-A	Cooling: 50 Heating: 50	Cooling: - Heating: -
			Cooling: 68 Heating: 67	Cooling: - Heating: -
Power Source (Pha	se, Voltage, Cycle)	Ø	Single	
		V	230	
		Hz	50	
Input Power		kW	Cooling: 3.60 Heating: 2.57	Cooling: - Heating: 3.53
Maximum Input Pov	ver For Mono bloc Unit	kW	6.27	
Power Supply 1: Ph	nase (ø) / Max. Current (A) / Max	k. Input Power (W)	Single / 29.0 / 6.27k	
Power Supply 2: Ph	nase (ø) / Max. Current (A) / Max	k. Input Power (W)	Single / 26.0 / 6.00k	

	Item	Unit	Mono Bloc Unit	
Power Supply 3: Pha	se (ø) / Max. Current (A) / Max. In	put Power (W)	Single / 13	3.0 / 3.00k
Starting Current		Α	16	5.7
Running Current		А	Cooling: 16.7 Heating: 11.9	Cooling: - Heating: 16.3
Maximum Current Fo	r Mono bloc Unit	Α	29.0	
Power Factor		%	Cooling: 94 Cooling: - Heating: 94 Heating: 94	
Power factor means t	total figure of compressor and out	door fan motor.		-
Power Cord	Number of core			
Length		m (ft)	-	
Thermostat	<u> </u>		Electronic Control	
Protection Device			Electroni	c Control

Item			Unit	Water System
Performance Test Condition	n			EN 14511
Operation Range	Outdoor Ambient		°C	Cooling: 16 ~ 43 Heating: -20 ~ 35
	Water Out	let	°C	Cooling: 5 ~ 20 Heating: 25 ~ 55
Internal Pressure Differentia	al		kPa	Cooling: 21.0 Heating: 27.5
Refrigerant Pipe Diameter	Liquid		mm (inch)	9.52 (3/8)
	Gas		mm (inch)	15.88 (5/8)
Water Pipe Diameter	Inlet		mm (inch)	30 (1-3/16)
	Outlet		mm (inch)	30 (1-3/16)
Water Drain Hose Inner Dia	ameter		mm (inch)	15.00 (19/32)
Pump	Motor Type			Capacitor Run Induction Motor (5 μF)
	No. of Speed			3
	Input Pow		W	180
Hot Water Coil	Type No. of Plates			Brazed Plate
				60
	Size (W x	H x L)	mm	93 x 100 x 325
	Water Flow	v Rate	l/min (m³/h)	Cooling: 28.7 (1.7) Heating: 34.4 (2.1)
Pressure Relief Valve Water	er Circuit		kPa	Open: 300, Close: 265 and below
Flow Switch				Magnetic Lead Switch
Protection Device		A	Residual Current Circuit Breaker (40)	
Expansion Vessel		Volume	I	10
		MWP	bar	3
Capacity of Integrated Electric Heater			kW	6.00

Note:

- Cooling capacities are based on outdoor air temperature of 35°C Dry Bulb with controlled water inlet temperature of 12°C and water outlet temperature of 7°C.
- Heating capacities are based on outdoor air temperature of 7°C Dry Bulb (44.6°F Dry Bulb), 6°C Wet Bulb (42.8°F Wet Bulb) with controlled water inlet temperature of 30°C and water outlet temperature of 35°C.
- Specification are subjected to change without prior notice for further improvement.

3. Features

- Inverter Technology
 - Energy saving
- High Efficiency
- Compact Design
- Environment Protection
 - Non-ozone depletion substances refrigerant (R410A)
- Easy to use remote control
- · Weekly Timer setting
- Quality Improvement
 - Random auto restart after power failure for safety restart operation
 - Gas leakage protection
 - Prevent compressor reverse cycle
 - Inner protector to protect compressor

Serviceability Improvement

- Breakdown Self Diagnosis function
- System Status Check Buttons for servicing purpose
- System Service Mode Button for servicing purpose
- Front maintenance design for Mono bloc unit


• Operation Condition

		Water outlet temperature (°C)	Ambient temperature (°C)
COOLING	Maximum	20	43
COOLING	Minimum	5	16
HEATING	Maximum	55	35
TILATING	Minimum	25	-20


NOTICE: When the outdoor temperature is out of the above temperature range, the heating capacity will drop significantly and Mono bloc unit might stop for protection control.


4. Location of Controls and Components

4.1 Mono Bloc Unit



4.1.1 Main Components





Water pump : The pump circulates the water in the water circuit.

Pressure gauge : The manometer allows read out of the water pressure in the water circuit.

Flow switch : The flow switch checks the flow in the water circuit and protects the heat exchanger against

high pressure built-up and the pump against damage.

Pressure relief valve : The pressure relief valve prevents excessive water pressure in the water circuit (> 300kPa).

Electric Heater : Additional heating capacity to the system when water and ambient temp is low.

Expansion Vessel : Storage for excessive water.

4.1.2 Location of Control

4.1.2.1 Remote Control


- Some functions described in this manual may not be applicable to your unit.
- Consult your nearest authorized dealer for further information.
- For normal operation, the For normal operation, the Tornormal operation operation.
 - 1 OFF/ON Button
 This button starts or stops the mode operation function of the unit.
 - Operation LED

This LED indicates the unit is in operation.

3 Operation Mode Button

This button is to set operation mode.

The mode does the following transition by button operation.



4 Quiet Operation Button

This button is to enjoy quiet environment by reduces mono bloc unit noise.

5 Backup Heater Enabling Button

This button is to select backup heater mode operation.

6 System Setting Mode Buttons

These setting button can change the temperature range of setup setting mode selection.

Perform the steps below to set preferred temperature range.

STEP 1: Press SET button for 5 seconds to enter setting mode.

STEP 2: Press upward or downward button to choose the 8 of the parameter as below for change the temperature range.

- 1) Low outdoor ambient set temperature (Selection range: -15°C ~ 15°C).
- 2) High outdoor ambient set temperature (Selection range: -15°C ~ 15°C).
- 3) Water outlet set temperature at low outdoor ambient temperature (Selection range: 25°C ~ 55°C).
- 4) Water outlet set temperature at high outdoor ambient temperature (Selection range: 25°C ~ 55°C).
- 5) Set temperature for turning OFF heating operation (Selection range: 5°C ~ 35°C).
- 6) Outdoor ambient set temperature for turning ON heater operation (Selection range: -15°C ~ 20°C).
- 7) Water set temperature during cool mode (5°C ~ 20°C)
- 8) Sanitary tank set temperature (Selection range: 40°C ~ 75°C).

STEP 3:Press SELECT button to enter selected parameter.

STEP 4:Press upward or downward button to set desired temperature.

STEP 5:Press SET button again to confirm the setting.

Note: Repeat steps 2 to 5 to set other parameters.

STEP 6:Press CANCEL button or wait 30 seconds to exit setting mode.

Water Temperature Thermo Shift Setting

Perform the steps below to set the desired shift temperature.


STEP 1:Press SET button within 5 seconds.

STEP 2:Press SELECT button to enter the setting temperature.

STEP 3:Press upward or downward button to set desired temperature (Selection range: -5°C ~ 5°C).

STEP 4:Press SET button again to confirm the setting.

STEP 5:Press CANCEL button or wait 30 seconds to exit setting.



7 Timer Setting Group Buttons

This button is to set weekly timer and clock-time combine with setting button.

Perform the steps below to setting the current day and time.

STEP 1: Press CLOCK button.

STEP 2: Press SETTING Upward or Downward buttons to set current day.

STEP 3: Press SET button to confirm.

STEP 4: Repeat STEP 2 and 3 to set the current time.

Note: The current time that has been set will be the standard time for all the Timer Operations.

8 Force Heater Mode Button

This button is to select force heater mode operation.

Press OFF/ON button to stop the force heater mode operation.

- 9 System Service Mode Button
- (10) System Status Check Button

This button is to check the various mode status.

Perform the steps below to check the selection status.

STEP 1: Press CHECK button for 5 seconds to enter status mode.

STEP 2: Press SEARCH Upward or Downward buttons for checking below value.

1.Compressor running frequency

2.Error history

3. Water inlet tempetarure

4. Tank Temperature

STEP 3: Press CANCEL button at setting mode or wait 30 seconds to exit status check.

(11) Error Reset Button

This button is to reset the remote control and system error code.

12 Heat Mode OFF/ON Indicator

This icon indicates heating mode OFF/ON operation.

13 Tank Mode Indicator

This icon indicates tank mode operation.

(14) Quiet Mode Indicator

This icon indicates quiet mode operation.

15 Backup Heater Enabled/Disabled Indicator

This icon indicates backup heater enabled/disabled mode operation.

16 Force Heater Request OFF/ON Indicator

This icon indicates force heater request OFF/ON mode operation.

17 Backup Heater Actual (OFF/ON) Indicator

This icon indicates backup heater actual operation.

18 Booster Heater Actual (OFF/ON) Indicator

This icon indicates booster heater actual operation.

19 System Defrost Operation OFF/ON Indicator

This icon indicates the system defrost operation request OFF/ON display.

20 System Setting Mode OFF/ON Indicator

This icon indicates the system setting mode request OFF/ON display.

21 System Status Check Mode OFF/ON Indicator

This icon indicates the status check mode request OFF/ON display.

22 System Service Mode OFF/ON Indicator

This icon indicates the system service mode request OFF/ON display.

23 Timer/Clock Setting Display

This LCD show the weekly schedule timer setting and clock display.

24 External Thermo Controller Connected Display

This LCD show the external thermo controller connected display.

25 Outdoor Ambient Temperature Display

This LCD show the outdoor ambient temperature.

26 Water Outlet Temperature Display

This LCD show the water outlet temperature.

27 Solar Display

This LCD show the solar display.

28 Caution (Tank Temperature above 60°C) Indicator

This LCD show the Caution display.

(29) Cool Mode OFF/ON Indicator

This icon indicates cooling mode OFF/ON operation.

4.1.3 Setting Up The Special Functions

- After initial installation, you can manually adjust the settings. The initial setting remains active until the user changes it.
- The remote control can be used for multiple installations. Some functions may not be applicable to your unit.
- Ensure the operation LED is in OFF condition before setting.

	SELECT CANCEL	TUS .	1. Press and simultaneously for 5 seconds to enter special setting mode. "SETTING" and "STATUS" indicator is ON. 2. Press or to browse functions. 3. Press or to enter function. 4. Press or to enable YES or disable NO function, or set other options. 5. Press to confirm.		
1	ره ون	COU	External Thermo Controller (YES / NO) To set external thermo controller connection.		
2	HEATER	(AP	Backup Heater Capacity Selection (3kW / 6kW / 9kW) To reduce the heater power whenever unnecessary. Options vary depending on model.		
3	Rn Ł ,	FrE	Water System Freeze Prevention Function (YES / NO) To activate or deactivate water system freeze prevention function when unit is OFF.		
4	TANK	con	Tank Connection (YES / NO) To set tank connection. Note: If select "Tank connection" is "NO", Set 5 ~ 14 are skipped.		
5	SOLAR	Pry	Solar Priority (YES / NO) To choose the solar use for water tank heat up.		
6	COOL	Pry	Cooling Priority (YES / NO) To choose the room cooling as priority during COOL + TANK mode. If select "Cooling priority" is "YES", Set 8 ~ 9 are irrelevant to COOL + TANK mode.		
7	HEAT	Pry	Heating Priority (YES / NO) To choose the room heating as priority during HEAT + TANK mode. Note: If select "Heating priority" is "YES", Set 8 ~ 9 are irrelevant to HEAT + TANK mode.		
8	COOL/HEAT	inE	Cooling/Heating operation Interval Set To set timer for Cool mode or Heat mode during COOL + TANK mode or HEAT + TANK mode (0.5hour ~ 10 hours). If both "Heating priority" and "Cooling priority" are "YES", Set 8 ~9 are skipped.		
9	TANK	inE	Tank Heat-up Interval Set To set timer for Tank during COOL + TANK mode or HEAT + TANK mode (5minutes ~ 1hour 35minutes).		
10	BOOSTER	հեշ	Booster Heater Function (YES / NO) To activate or deactivate tank booster heater function Note: If select "Booster heater function" is "NO", Set 11 is skipped.		
11	BOOSTER	<i>8</i> LY	Booster Heater Delay Timer Set To set delay timer for booster heater to ON if water tank temperature is not reached (20minutes ~ 1hour 35minutes).		
• TI	Do not use the system during sterilization to prevent scalding or overheat during shower. The sterilization function field settings must be configured by the authorized dealer according to local laws and regulation. The sterilization set temperature may not achieve if tank booster heater function is deactivated.				
12	St rl	Fun	Sterilization (YES / NO) To set sterilization, if required. Note: If select "Sterilization" is "NO", set 13 ~ 15 are skipped.		
13	Str		Sterilization Day & Time Set To set timer for sterilization (only once a week, will operate even in standby condition).		
14	St rl	Ьοι	Sterilization Temperature Set To set temperature for sterilization function (40°C ~ 75°C).		
15	Str	oPr	Sterilization Continue Time To set timer to maintain heating temperature in order to complete the sterilization function (5minutes ~ 1hour).		

4.1.4 Basic Operation



TO TURN ON OR OFF THE UNIT

 When unit is ON, operation LED is lit and the actual temperature for water outlet and outdoor ambient are shown on the remote control display.

MODE

TO SELECT OPERATION MODE



- HEAT MODE
 - To turn ON or OFF the panel/floor heating operation.
 - In this mode, the mono bloc unit will provide heating capacity to the system.
- HEAT + TANK MODE
 - In this mode, the mono bloc unit will provide heating capacity to the sanitary tank and the system.
 - This operation is not used when the sanitary water tank is not installed.
- TANK MODE
 - To turn ON or OFF the sanitary tank operation.
 - In this mode, the mono bloc unit will provide heating capacity to the sanitary tank.
- COOL MODE
 - To turn ON or OFF the panel operation.
 - In this mode, the mono bloc unit will provide cooling capacity to the system.
- COOL + TANK MODE
 - In this mode, the mono bloc unit will provide cooling capacity to the system.
 - Mono bloc unit will control booster heater in sanitary tank.

QUIET

TO ENJOY QUIET ENVIRONMENT

• This operation reduces mono bloc unit noise. In this condition, it may cause decrease in heating/cooling capacity.

HEATER

TO ENABLE THE BACKUP HEATER

 The backup heater provides extra heating capacity during cold outdoor temperature and only can operated at heat mode operation when he was enabled by pushing this button.

- The backup heater will automatically turn ON when the setting conditions is fulfilled.
- To disabled the Heater operation manually, press the respective button again.

STATUS CHECK SEARCH


SYSTEM STATUS CHECK MODE

- 1.Press for 5 seconds to enter STATUS mode.
- 2.Press or to check the Water Inlet Temperature, Tank Temperature, Compressor Running Frequency or Error History.
 - Press to exit STATUS mode.
 - Once STATUS mode is entered, "STATUS" indicator is ON.
 - STATUS mode cannot be activated when the "SETTING" indicator is ON.

4.1.5 Advance Operation

- It is strongly recommended to contact the nearest authorized dealer to change the water temperature range.
- · Using the remote control could set the temperature range for water outlet temperature and outdoor ambient temperature.

SYSTEM SETTING MODE



- 1. Press $\stackrel{\text{SET}}{\bigcirc}$ for 5 seconds to enter "SETTING" mode. "SETTING" indicator is ON.
- 2. Press or to choose a parameter.
- 3. After selecting the desired parameter, press to enter the parameter.
- 4. Press or to set the desired temperature.
- 5. Press again to confirm the setting.
- Repeat steps 2 to 5 to set other parameters.

Operation Mode	Parameter * Description		
HEAT	outLo	Low outdoor ambient set temperature (-15°C ~ 15°C). Water Temperature ↑	
HEAT	ه ۱۲ کان ه	High outdoor ambient set temperature (-15°C ~ 15°C).	
HEAT	H 50 Fo	Water outlet set temperature at low outdoor ambient temperature (25°C ~ 55°C).	
HEAT	H 50 H ¹	Water outlet set temperature at high outdoor ambient temperature (25°C ~ 55°C).	
HEAT	OFF	Set temperature for turning OFF heating operation (5°C ~ 35°C).	
HEATER	o nf ox	Outdoor ambient set temperature for turning ON heater operation (-15°C ~ 20°C).	
COOL	SEŁ	Water set temperature during cool mode (5°C~20°C)	
TANK	SEŁ	Sanitary tank set temperature (40°C ~ 75°C).	


WATER TEMPERATURE THERMO SHIFT SETTING

- 1. Press within 5 seconds.
- Repeat steps 3 to 5 to set the desired shift temperature (-5°C ~ 5°C).

Notes:

- Press or wait 30 seconds to exit "SETTING" mode.
- The setting temperature will be stored in the system once confirm.
- "SETTING" mode cannot be activated when the "SERVICE" and "STATUS" indicator is ON.

Weekly Timer Setting 4.1.6




Function	Step
Enter timer mode	Press .
Set day & time	1. Press 💩 or 👿 to select your desired day.
	2. Press to confirm.
	3. "1" will be blinking, press to set program 1.
	4. Press to select ON or OFF timer.
	5. Press 💩 or 👿 to select your desired time.
	You can set , , , and desired shift temperature with timer.
	 Press to confirm program 1. The selected day will be highlighted with ▼.
	 After 2 seconds, the display will move to the next program.
	 7. Repeat steps 4 to 7 to set programs 2 to 6. During timer setup, if no button is pressed within 30 seconds, or if the button is pressed the
	setting at that moment is confirmed and timer setup is ended.
Add/Modify timer	Repeat the steps above.
Disable timer	Press , then press .
Enable timer	Press , then press .
Check timer	1. Press .
	2. Press 💩 or 🕏 until your desired day is shown, press 🌑 to confirm your selection.
	3. Press 🙆 or 🍑 to check the set programs.
Cancel timer	1. Press .
	2. Press o or until your desired day is shown, press to confirm your selection.
	3. Press to enter program setting.
	4. Press or wuntil your desired program is shown.
	5. Press to cancel the program.
Notes:	

- You can set the Timer for each day of the week (Monday to Sunday) with 6 programs per day.
 When the unit is switched on by the ON TIMER, it will use the previously set temperature to control the water outlet temperature.
 Same timer program cannot be set in the same day.


- You may also select collective days with same timer setting.
 Promotes energy saving by allowing you to set up to 6 programs in any given day.


5. Dimensions

5.1 Mono Bloc Unit




6. Refrigeration and Water Cycle Diagram






7. Block Diagram

7.1 WH-MXC09D3E5 (WH-MXC09D3E5-1)





7.2 WH-MXC12D6E5 (WH-MXC12D6E5-1)




8. Wiring Connection Diagram


8.1 WH-MXC09D3E5 (WH-MXC09D3E5-1)






8.2 WH-MXC12D6E5 (WH-MXC12D6E5-1)







9. Electronic Circuit Diagram


9.1 WH-MXC09D3E5 (WH-MXC09D3E5-1)





9.2 WH-MXC12D6E5 (WH-MXC12D6E5-1)







10. Printed Circuit Board

10.1 Water System

10.1.1 Main Printed Circuit Board




10.1.2 Solar Printed Circuit Board (Optional)




10.2 Refrigerant System


10.2.1 Main Printed Circuit Board



10.2.1.1 Capacitor Printed Circuit Board




10.2.1.2 Noise Filter Printed Circuit Board




11. Installation Instruction Mono Bloc Unit

Dimension Diagram



Main Components



Component name

- 1 PCB
- 2 Pressure relief valve
- 3 Flow switch
- 4 Pressure gauge
- ⑤ Water pump
- 6 RCCB
- Bushing
- 8 Cabinet front plate
- 9 Cabinet top plate
- 10 Overload protector
- 11 Heater assembly
- 12 Expansion vessel
- 13 Cover
- 4 Air purge valve

Connector name

- a Water inlet
- **b** Water outlet

It is advisable to avoid more than 2 blockage directions. For better ventilation & multiple-outdoor installation, please consult authorized dealer/specialist.

11.1 Select The Best Location

- Install the Mono bloc unit in outdoor locations only.
- Avoid installations in areas where the ambient temperature may drop below -20°C.
- The Mono bloc unit must be installed on a flat, solid surface.
- A place removed from any heat source or steam which may effect the operation of the Mono bloc unit.
- A place where air circulation is good.
- A place where drainage can be easily done.
- A place where Mono bloc unit's operation noise will not cause discomfort to the user.
- A place which is accessible for maintenance.
- Ensure to keep minimum distance of spaces as illustrated below from wall, ceiling, or other obstacles.
- A place where flammable gas leaking might not occur.
- A place where the Mono bloc unit's piping and wiring lengths come within reasonable ranges.
- If an awning is built over the unit to prevent direct sunlight or rain, be careful that heat radiation from the condenser is not obstructed.
- Do not place any obstacles which may cause a short circuit of the discharged air.
- Avoid installing the Mono bloc unit at a location where suction side may be exposed directly to wind.
- If Mono bloc unit installed near sea, region with high content of sulphur or oily location (e.g. machinery oil, etc.), it lifespan maybe shorten.
- When installing the product in a place where it will be affected by typhoon or strong wind such as wind blowing between buildings, including the rooftop of a building and a place where there is no building in surroundings, fix the product with an overturn prevention wire, etc. (Overturn prevention fitting model number: K-KYZP15C)



 When connecting solar pump station cable between Mono bloc unit and solar pump station, the distance between both apparatuses shall be 2 ~ 8 meters and the length of the said cable must be shorter than 10 meter.
 Failure to do so may lead to abnormal operation to the system.

11.2 Mono Bloc Unit Installation

Mono bloc unit will become heavy when filled with water. Please install the unit on a strong concrete floor and consider the weight of the unit and water.

- Fix Mono bloc unit on the concrete floor with M12 anchor bolt at 4 locations.
- Pull-out strength of these anchor bolts must be above 15000N.




Illustration of grip type and embedded type anchor bolt

11.3 Piping Installation

⚠ WARNING

This section is for authorized and licensed electrician / water system installer only. Work behind the front plate secured by screws must only be carried out under supervision of qualified contractor, installation engineer or service person.

Please engage a licensed water circuit installer to install this water circuit.

- The minimum requirement of water in the system is 50 litres. If this value could not be achieved, please install additional buffer tank (field supply).
- This water circuit must comply with relevant European and national regulations (including EN61770), and local building regulation codes.
- Ensure the components installed in the water circuit could withstand water pressure during operation.
- Do not apply excessive force to piping that may damage the pipes.
- Use Rp 1 ½" nut for both water inlet and water outlet connection and clean all piping with tap water before connecting to the Mono bloc unit.
- Cover the pipe end to prevent dirt and dust when inserting it through a wall. If an existing tank is to be connected to this Mono bloc unit, ensure the pipes are clean before water pipe installation is carried out.
- An external filter (30 mesh or more field supplied) must be installed before the water inlet of the Mono bloc unit.
- Refer to Diagram 3.1 for pipe connection of Radiator, Floor Heater, Tank Unit, Solar Pump Station, 3-way Valve Kit and etc. Fail to connect the pipes appropriately might cause the unit malfunction.





Diagram 3.1: Typical Water Piping Installation


- Choose proper sealer which can withstand the pressures and temperatures of the system.
- Make sure to use two spanners to tighten the connection. Tighten the nuts with torque wrench: 117.6 N•m.
- If non-brass metallic piping is used for installation, make sure to insulate the piping to prevent galvanic corrosion.
- Do not use pipes that are crushed or deformed. If these inferior pipes are used, it may cause unit malfunction.
- Make sure to insulate the water circuit piping (insulator thickness: 20mm or more) to prevent condensation
 during cooling operation (cooling model only) and reduction of heating capacity, as well as avoid freezing of the
 outdoor water circuit piping during winter season.
- After installation, check the water leakage condition in connection area during test run.
- In case of a power supply failure or pump operating failure, drain the system (as suggested in the figure below).



When water is idle inside the system, freezing up is very likely to happen which could damage the system.

Drainage piping installation


- Use a drain hose with inner diameter of 15 mm.
- The hose must be installed in a continuously downward direction and left open to the frost-free atmosphere.
- If drain hose is long, use a metal support fixture along the way to eliminate the wayy pattern of drain tube.
- Water will drip from this hose, therefore the outlet of this hose must be installed in an area where the outlet cannot become blocked.
- Do not insert this hose into sewage or drain pipe that may generate ammonia gas, sulfuric gas, etc.
- If necessary, use a hose clamp to tighten the hose at drain hose connector to prevent it from leaking.




11.4 Connect The Cord And Cable To Mono Bloc Unit

(REFER TO WIRING DIAGRAM AT UNIT FOR DETAIL)

- 1 An isolating device must be connected to the power supply cable.
 - o Isolating device (Disconnecting means) should have minimum 3.0 mm contact gap.
 - o Connect the approved polychloroprene sheathed power supply 1 cord (3 x 4.0 or 6.0 mm²) and power supply 2 cord (3 x 4.0 mm²) and power supply 3 cord (3 x 1.5 mm²), type designation 60245 IEC 57 or heavier cord to the RCCB, and to the other end of the cord to isolating device (Disconnecting means).
- 2 To avoid the cable and cord being damaged by sharp edges, the cable and cord must be passed through a bushing (located at the right hand side of the mono bloc unit) before being connected to the terminal block. The bushing must be used and must not be removed.
- 3 Secure the cable onto the control board with the holder (clamper).




*REMARK: Cooling model refer to WH-M*C*** models.




Connecting with external device (optional)

- 1 All connections shall follow to the local national wiring standard.
- 2 It is strongly recommended to use manufacturer-recommended parts and accessories for installation.
- 3 Maximum output power of booster heater shall be \leq 3 kW. Booster Heater cord must be (3 x min 1.5 mm²), of type designation 60245 IEC 57 or heavier.
- 4 Two-way Valve shall be spring and electronic type, refer to "Field Supply Accessories" table for details. Valve cable shall be (3 x min 0.5 mm²), of type designation 60245 IEC 57 or heavier, or similarly double insulation sheathed cable.
 - * note: Shall be CE marking compliance component.
 - Maximum load for the valve is 9.8VA.
 - *Cooling model only
- Three-way Valve shall be spring and electronic type, refer to "Field Supply Accessories" table for details. Valve cable shall be (3 x min 0.5 mm²), of type designation 60245 IEC 57 or heavier, or similarly double insulation sheathed cable.
 - * note: Shall be CE marking compliance component.
 - It shall be directed to heating mode when it is OFF.
 - Maximum load for the valve is 9.8VA.
- 6 Room Thermostat cable must be (4 or 3 x min 0.5 mm²), double insulation layer of PVC-sheathed or polychloroprene sheathed cable.
- 7 Tank OLP cable must be (2 x min 0.5 mm²), double insulation layer of PVC-sheathed or polychloroprene sheathed cable.
 - * note: if such connection deemed NO necessary for tank OLP, please connect jumper between terminal no. 13 and 14.
- Tank Sensor shall be resistance type, please refer to Graph 4.1 for the characteristic and details of sensor. Its cable shall be (2 x min 0.3 mm²), double insulation layer (with insulation strength of min 30V) of PVC-sheathed or polychloroprene sheathed cable.
- 9 External Controller shall be connected to 1-pole switch with min 3.0mm contact gap. (connection refer to Diagram 4.2). Its cable must be (2 x min 0.5 mm²), double insulation layer of PVC-sheathed or polychloroprene sheathed cable.
 - * note: When making such connection, kindly remove the jumper between terminal no. 17 and 18.
 - Switch used shall be CE compliance component.
 - Maximum operating current shall be less than 3A_{rms}.
- 10 Must install Solar Connection PCB (optional) to Mono bloc unit when Solar Pump Station is utilized. Refer Solar Connection PCB's installation instruction for detail of installation.
- 11 Solar Three-way Valve cable shall be (3 x min 0.5 mm²), double insulation layer PVC-sheathed or polychloroprene sheathed cable.
- 12 Solar Pump Station cable shall be (2 x min 0.5 mm²), of double insulation PVC-sheathed or polychloroprene sheathed cable. Strongly recommended install with maximum length of 10 meter only.



Terminal screw	Tightening torque N•cm {kgf•cm}		
M4	157~196 {16~20}		
M5	196~245 {20~25}		

11.4.1 Wire Stripping And Connecting Requirement



11.4.2 Connecting Requirement

- The equipment's power supply 1 complies with IEC/EN 61000-3-12 provided that the short-circuit power S_{sc} is greater than or equal to (Refer below table) at the interface point between the user's supply and the public system. It is the responsibility of the installer or user of the equipment to ensure, by consultation with the distribution network operator if necessary, that the equipment is connected only to a supply with a short-circuit power S_{sc} greater than or equal to (Refer below table)
- The equipment's power supply 1 shall be connected to a suitable supply network, having service current capacity ≥100A per phase. Please liaise with supply authority to ensure that the service current capacity at the interface point is sufficient for the installation of the equipment.
- The equipment's power supply 2 complies with IEC/EN 61000-3-12.
- The equipment's power supply 2 shall be connected to a suitable supply network, with the following maximum permissible system impedance $Z_{max} = 0.236\Omega$ at the interface.
- Please liaise with supply authority to ensure that the power supply 2 is connected only to a supply of that impedance or less.

For power supply 3: (Only applicable for model 12kW,14kW and 16kW)

- The equipment's power supply 3 complies with IEC/EN 61000-3-12.
- The equipment's power supply 3 shall be connected to a suitable supply network, with the following maximum permissible system impedance $Z_{max} = 0.464\Omega$ at the interface.
- Please liaise with supply authority to ensure that the power supply 3 is connected only to a supply of that impedance or less.

type	series	A
1	WH-MD*E5*	858kW
2	WH-MX*E5*	817.85kW

11.4.3 Wired Remote Controller Instalation


	⚠ WARNING				
\bigcirc	Do not modify the length of the remote control cable. Otherwise, it will cause fire or electrical shock.				
0	Be sure to turn off the main power before installing and connecting the remote control. Otherwise, it will cause the electrical shock.				
0	Use the attached accessories parts and specified parts for installation. Otherwise, it will cause the set to fall, fire or electrical shock.				
0	Wire routing must be properly arranged so that control board cover is fixed properly. If control board cover is not fixed properly, it will cause fire or electrical shock.				
0	If passing the remote control cable through a wall, be sure to install a water trap above the cable. Otherwise, it will cause the electrical shock.				
	⚠ CAUTION				
0	Install in a flat surface to avoid warping of remote control, else damage to the LCD case or operation problems may result.				
0	Avoid installing the remote control cable near refrigerant pipes or water pipes, else will cause electrical shock or fire.				
0	Install the remote control cable at least 5cm away from electric wires of other appliances to avoid miss operation (electromagnetic noise).				
•	Be sure to use only the accessory screws to avoid damage of remote control PCB.				

Attached Accessories

No.	Name	Qty.	Diagram	Remark	
(1)	Remote control	1			
(2)	Remote control cable	1		Length (15 m)	
(3)	Screw (M4 machine pitched - 30mm)	3		Installing the remote control to an outlet box (embedded cable)	
(4)	Screw (M4 self tapping - 14mm)	3	W(X)	Installing the remote control to the wall (exposed cable)	

11.4.3.1 Selecting The Installation Location

- Allow sufficient space around the remote control (1) as shown in the illustration above.
- Install in a place which is away from direct sunlight and high humidity.
- Install in a flat surface to avoid warping of the remote control. If installed to a wall with an uneven surface, damage to the LCD case or operation problems may result.
- Install in a place where the LCD can be easily seen for operation. (Standard height from the floor is 1.2 to 1.5 meters.)
- Avoid installing the remote control cable near refrigerant pipes or drain pipes, else it will cause electrical shock or fire.




11.4.3.2 Installing The Remote Control Unit To The Wall


- 1 Remove the remote control (1) lower case. (Insert a flat-tipped screw driver or similar tool 2 to 3 mm into one of the gaps at the bottom of the case, and twist to open. Refer to the illustration at right.)
 - Be careful not to damage the lower case.
- 2 Do not remove the protective tape which is affixed to the upper case circuit board when removing the remote control lower case.
- 3 Secure the lower case to an outlet box or wall. Refer to (A) or (B) instructions below depending on your choice of cable installation.
- 4 Be sure to use only the screws provided.
- Do not over tighten the screws, as it may result in damage to the lower case.

A. If Remote Control Cable Is Embedded

- 1 Embed an outlet box (JIS C 8336) into the wall. Outlet box may be purchased separately. Medium-sized square outlet box (obtain locally) Part No. DS3744 (Panasonic Co., Ltd.) or equivalent.
- 2 Secure the remote control lower case to the outlet box with the two accessory screws (3). Make sure that the lower case is flat against the wall at this time, with no bending.
- 3 Pass the remote control cable (2) into the box.
- 4 Route the remote control cable (2) inside the lower case through rear feeding-out direction.
- 5 Insert firmly the connector of remote control cable (2) to connector (CON1) in the upper case circuit board. [Refer to the illustration at below.]




6 Secure the remote control upper case to the lower case with the tabs provided.




⚠ CAUTION

When the wall is hollow, please be sure to use the sleeve for remote control cable to prevent dangers caused by mice biting the cable.




B. If Remote Control Cable Is Exposed

- 1 Install the remote control lower case to the wall with the two accessory screws (4).
- 2 Fasten the screws properly until screw head is lower than the rib and reach the base of remote control lower case to ensure they do not damage the PCB inside the remote control (1).



3 The feeding-out direction for the remote control cable can be either via top, left or right side.

- 4 Use nipper to cut a notch at the upper case. (Select the intended feeding-out position)
- 5 Route the remote control cable (2) inside the lower case in accordance with the intended feeding-out direction. (Refer to the illustration at below)
- 6 Insert firmly the connector of remote control cable (2) to connector (CON1) in the upper case circuit board. (Refer to the illustration at below)
- 7 Secure the remote control upper case to the lower case with the tabs provided.





11.4.3.3 Connecting The Remote Control Cable To Mono Bloc Unit

⚠ WARNING

Be sure to turn off the main power before installing and connecting the remote control. Otherwise, it will cause the electrical shock.


- 1 Remove the cabinet front plate.
- 2 Connect the remote control cable with the provided connector as shown in below illustration. (Refer wiring diagram for detail.)
- 3 Guide the remote control cable through the clamper and Bushing ①. (Refer illustration "How to connect Remote Control to Provided Connector" for detail.)
- 4 Reinstall the cabinet front plate after connection complete.





11.4.3.4 Disposal of Mono Bloc Unit Drain Water

- When a Drain elbow is used, please ensure to follow below:
 - 1 The unit should be placed on a stand which is taller than 50mm.
 - 2 Cover the 8 holes (ø20mm) with Rubber cap (refer to illustration below)
 - 3 Use a tray (field supply) when necessary to dispose the Mono bloc unit drain water.



• If the unit is used in an area where temperature falls below 0°C for 2 or 3 consecutive days, it is recommended not to use the Drain elbow 🗈 and Rubber cap 🗈, for the drain water freezes and the fan will not rotate.

12. Operation and Control

12.1 Basic Function

Inverter control, which equipped with a microcomputer in determining the most suitable operating mode as time passes, automatically adjusts output power for maximum comfort always. In order to achieve the suitable operating mode, the microcomputer maintains the set temperature by measuring the temperature of the environment and performing temperature shifting. The compressor at Mono bloc unit is operating following the frequency instructed by the microcomputer at Mono bloc unit that judging the condition according to internal water setting temperature and water outlet temperature.

12.1.1 Heating Operation

12.1.1.1 Thermostat control

- Compressor is OFF when Water Outlet Temperature Internal Water Setting Temperature > 2°C for continuously 3 minutes.
- Compressor is ON after waiting for 3 minutes, if the Water Outlet Temperature Water Inlet Temperature (temperature at thermostat OFF is triggered) < -3°C.


12.1.2 Cooling Operation

12.1.2.1 Thermostat control


- Compressor is OFF when Water Outlet Temperature Internal Water Setting Temperature < -1.5°C for continuously 3 minutes.
- Compressor is ON after waiting for 3 minutes, if the Water Outlet Temperature Water Inlet Temperature (temperature at thermostat OFF is triggered) > 3°C.

12.1.3 Cool Mode Operation

- 1 3 ways valve control:
 - 3 ways valve switch and fix to room side.
- 2 Heat pump operate follow normal cooling operation.
- 3 Backup heater DOES NOT operate during cool mode.
- 4 Solar 3 way valve operates follow solar operation specification.
- 5 2 ways valve control:
 - 2 ways valve is closed.



12.1.4 Cool + Tank Mode Operation



12.1.5 Tank Mode Operation

Control contents:

- 3 ways valve direction
 - 3 ways valve switch and fix to tank side.
- Heat pump Thermostat characteristic
 - Water set temperature = Tank set temperature or [50°C] whichever lower.
 - Heat pump Water Outlet set temperature is set to Maximum (53°C) at tank mode.

i. Case 1


- THERMO OFF TEMP:
 - 1 THERMO OFF TEMP = Water set temperature + [1°C].
 - 2 Tank temperature > THERMO OFF TEMP for continuous 10 seconds after heat pump OFF, water pump OFF.
- THERMO ON TEMP:
 - 1 THERMO ON TEMP = Water set temperature + [-1°C].
 When detect tank temperature < THERMO ON TEMP, water pump ON for 3 minutes then heat pump ON.


ii. Case 2


- Heat pump THERMO OFF TEMP:
- 1 Heat pump THERMO OFF TEMP = 53°C + [+4°C].
- 2 Water outlet temperature > Heat pump THERMO OFF TEMP for continuous 3 minutes, heat pump OFF.
- Heat pump THERMO ON TEMP:
 - 1 Heat pump THERMO ON TEMP = Water inlet during thermo off time + [-3°C].
 - 2 Heat pump ON back when water outlet temperature < Heat pump THERMO ON TEMP.

iii. Case 3

- Heat pump THERMO OFF TEMP:
 - 1 Water inlet temperature > 55°C for continuous 60 secs, heat pump OFF.
- Heat pump THERMO ON TEMP:
 - 1 Heat pump THERMO ON TEMP = Water inlet temperature < 55°C.
- Booster heater control
 - Booster heater turn On and Off follow normal operation.
 - Booster heater turn ON condition:
 - 1 During startup time (initialization), Booster heater turn ON after DELAY TIMER.
 - 2 When tank temperature lower than HEATER ON TEMP.
 - 3 20 minutes from previous heater off.
 - Booster heater turn OFF condition:
 - 1 When tank temperature higher than tank set temperature for continuous 15 secs.
- Solar 3 way valve
 - Solar pump operates follow solar operation specification.
- 2 way valve closes
- Others
 - Indoor backup heater cannot be ON during tank mode only.







12.1.6 Heat + Tank Mode Operation

Setting 1: When Heating priority is set by remote control:

- 1 3 ways valve control:
 - 3 ways valve switch to room side during External Room Thermo ON OR Solar 3 ways valve ON OR
 Tank Thermo OFF time, and switch to tank side at External Room Thermo OFF AND Solar 3 ways valve OFF
- 2 Heat pump operation control:-
 - During External Room Thermo ON time: (When room thermo ON, heat pump must operate to room side)
 - · Heat pump operate follow normal operation at room side
 - During External Room Thermo OFF time:
 - Switch 3 ways valve to tank side, IF Under Solar Priority Set condition:
 - Tank temperature < Tank THERMO ON TEMP AND Solar Valve OFF Under Solar Priority Not Set condition:
 - o Tank temperature < Tank THERMO ON TEMP

- Switch back 3 ways valve to room side, Heat pump and water pump turn OFF, IF
 - o External Room Thermo ON back **OR**

Under Solar Priority Set condition:

 Tank temperature > Tank THERMO OFF TEMP. for continuous 3 minutes OR Solar Valve ON

Under Solar Priority Not Set condition:

- Tank temperature > Tank THERMO OFF TEMP for continuous 3 minutes
- * THERMO ON and THERMO OFF point refer to case below.

Operation condition when 3 ways valve switch to tank side:

- Tank water set temperature = tank set temperature or [50°C] whichever lower
- Heat Pump Water Outlet set temperature is set to [53°C] during tank interval
- Initial Tank THERMO ON TEMP = heat pump tank target temperature + [-1°C]

Case 1:

- THERMO OFF TEMP:
 - 1. THERMO OFF TEMP = Tank water set temperature + [1°C].
 - 2. Tank temperature > THERMO OFF TEMP for continuous 10 seconds after compressor off, switch 3 ways valve to room side.
- o Next THERMO ON TEMP:
 - 1. THERMO ON TEMP = Heat pump tank target temperature + [-1°C] or
 - 2. If tank temperature < THERMO ON TEMP AND External Room Thermo OFF, switch to tank side.

Case 2:

- o Heat pump THERMO OFF TEMP:
 - 1. Heat pump THERMO OFF TEMP = 53°C + [+4°C].
 - 2. Water outlet temperature > Heat pump THERMO OFF TEMP for continuous 3 minutes, heat pump OFF.
- Next THERMO ON TEMP:
 - 1. THERMO ON TEMP = Water inlet when heat pump THERMO OFF + [-3°C].
 - 2. If water outlet temperature < THERMO ON TEMP AND External Room Thermo OFF, heat pump ON.

<u> Case 3:</u>

- o Heat pump THERMO OFF TEMP:
 - 1. Water inlet temperature > 55°C for continuous 60 secs, heat pump OFF.
- o Next THERMO ON TEMP:
 - 1. THERMO ON TEMP = Water inlet temperature < 55°C.
 - 2. If water inlet temperature < THERMO ON TEMP AND External Room Thermo OFF, heat pump ON.


Case 4: (Only during solar priority is set condition)


- When solar request ON, solar valve will ON and switch 3 ways valve to room side
- THERMO ON TEMP:
 - 1. THERMO ON TEMP = Heat pump tank target temperature + [-1°C].
 - 2. If tank temperature < THERMO ON TEMP AND External Room Thermo OFF AND Solar 3WV OFF, switch to tank side.</p>
- 3 Backup Heater control:-
 - During External Room Thermo ON time, follow normal backup heater control operation
 - During External Room Thermo OFF time, Backup heater OFF
- 4 Booster heater control:
 - Booster heater On/Off follow normal operation.
 - * Under solar priority is set condition, when solar 3 way valve is ON, booster heater turn OFF.

5 Solar 3 way valve:

- Solar 3 way valve operates follow solar operation specification.
 - * Under solar priority is set condition, when solar 3WV turn ON, booster heater will turn OFF and 3 ways valve switch to room side.
 - * Under solar priority is not set condition, solar 3WV will OFF when heat pump operate to tank side.

o 2 way valve opens.





Setting 2: When heating priority is not set by remote control:

- When Solar Priority is set / not set by remote control:
 - 1 3 ways valve control:
 - 3 ways valve switch to room side during heating heat-up interval, and switch to tank side during tank heat-up interval. Both mode will switch alternatively. Tank mode is the Initial running mode of this heat + tank mode (heating no priority).
 - 2 Heat pump operation control:
 - During heating heat-up interval
 - Follow normal heating operation.

Under solar priority set condition:

- Switch to tank heat-up interval and start counting tank heat-up timer when External Room Thermo
 OFF AND solar 3WV OFF AND Tank temperature < THERMO ON TEMP (End Room Interval
 Early) OR
- Switch to tank heat-up interval and start counting tank heat-up timer when tank temperature < THERMO ON TEMP **AND** solar 3WV OFF

Under solar priority not set condition:

- Switch to tank heat-up interval and start counting tank heat-up timer when External Room Thermo OFF **AND** Tank temperature < THERMO ON TEMP (End Room Interval Early) **OR**
- Switch to tank heat-up interval and start counting tank heat-up timer when tank temperature < THERMO ON TEMP
- * THERMO ON TEMP is defined form following Case1 to Case4.
- During tank heat-up interval
 - Heat pump tank target temperature = Tank set temperature or [50°C] whichever lower
 - Heat pump Water Outlet set temperature is set to Maximum [55°C] during tank interval
 - Initial Tank THERMO ON TEMP = heat pump tank target temperature + [-1°C]

Case 1:

- THERMO OFF TEMP:
 - 1. THERMO OFF TEMP = Heat pump tank target temperature + [+1°C].
 - 2. Tank temperature > THERMO OFF TEMP for continuous 10 seconds after heat pump off due to water thermo, switch 3 ways valve to room side. End Tank heat-up interval and start count heating heat-up interval.
- THERMO ON TEMP:
 - 1. THERMO ON TEMP = Heat pump tank target temperature + [-1°C].
 - 2. After Heating heat-up interval, always detect tank temperature. Switch to next tank heat-up interval when tank temperature < THERMO ON TEMP

Case 2:

- Heat pump THERMO OFF TEMP:
 - 1. Heat pump THERMO OFF TEMP = 53°C + [+4°C].
 - 2. Water outlet temperature > Heat pump THERMO OFF TEMP for continuous 3 minutes, heat pump OFF.
- THERMO ON TEMP:
 - THERMO ON TEMP = Water inlet temperature, when heat pump thermo off + [-3°C].

Case 3:

- Heat pump THERMO OFF TEMP:
 - 1. Water inlet temperature > 55°C for continuous 60 secs, heat pump OFF.
- THERMO ON TEMP:
 - 1. THERMO ON TEMP = Water inlet temperature < 55°C.

Case 4 (Only during solar priority is set condition):

- When solar pump ON, tank heat-up interval end early and 3 ways valve switch to room side.
- THERMO ON TEMP:
 - 1. THERMO ON TEMP = Heat pump tank target temperature + [-1°C].
 - 2. After Heating heat-up interval, always detect tank temperature. Switch to next tank heat-up interval when tank temperature < THERMO ON TEMP and solar 3 way valve OFF.

- Tank interval will end and start heating interval timer, IF
 - * When this condition happen at tank side before case 1 thermo-off. 3WV switch to room side compulsory and continue until complete room interval.
 - 1. Tank interval timer finish AND External Room Thermo ON OR
 - 2. Fulfill above Case 1 of thermo off condition.

3 Backup heater control:

- During heating heat up interval.
 - Follow normal backup heater control operation.
- During tank heat-up interval.
 - Backup heater OFF during this interval.


4 Booster heater control:


- o During heating heat-up interval.
 - Booster heater ON/OFF according to booster heater operation control.
- During tank heat-up interval.
 - Once switch from heating heat-up interval to tank heat-up interval, turn off the booster heater and start counting the BOOSTER HEATER DELAY TIMER.
 - Booster heater turn ON after BOOSTER HEATER DELAY TIMER fulfill and tank temperature lower than tank set temperature.
 - BOOSTER HEATER DELAY TIMER is clear when switch to heating heat-up interval.

5 Solar 3 way valve:


- o Solar 3WV operates follow solar operation specification.
- * Under solar priority is set condition, when solar 3WV is ON, booster heater turn OFF
- * Under solar priority is not set condition, solar 3WV only can ON during heating heat-up interval.

6 2 way valve opens.






Under Solar Priority Not Set Condition:



12.1.7 Setting Water Outlet Temperature for Heat Mode


The set temperature define the parameters for the outdoor ambient temperature dependent operation of the unit.
 Where by the internal water setting temperature is determined automatically depending on the outdoor temperature. The colder outdoor temperatures will result in warmer water and vice versa. The user has the possibility to shift up or down the target water temperature by remote control setting.



• Change in setting water outlet temperature is updated every 30 minutes.

12.1.7.1 Heating Mode Operation Time Chart


Exp:



- 3 ways valve control:
 - 3 ways valve switch and fix to room side.
- 2 Heat pump operate follow normal heating operation.
- 3 Backup heater operate follow normal operation.
- 4 Solar 3 way valve operates follow solar operation specification
- 5 2 ways valve control:
 - o 2 ways valve opens.


12.1.8 Water Temperature Thermo Shift Setting

- Switchs are ignored during "PUMPDW" = ON.
- Switchs are ignored during "STATUS" = ON.
- "▲", "▼", "SELECT" switch are ignored if "SETTING" = OFF.
- "CANCEL" switch is ignored if "SETTING" = OFF & "STATUS" = OFF.
- If "SET" Switch pressed for less than 5secs, immediately enter water temperature shift setting mode.
- Once enter this setting mode, "SETTING" display is ON.
 This setting mode is used to easily shift the target water outlet temperature.



12.1.9 Fan Motor Operation


Fan motor is adjusted according to operation condition. It starts when compressor starts operation and it stops 30 seconds after compressor stops operation.



12.2 Water Pump

12.2.1 Water Pump Control

- Once the indoor unit is ON, the water pump will be ON immediately and no error judgement for 9 minutes.
 However, during this 9 minutes operation, if there is any abnormality cause at outdoor or malfunction, the compressor should be OFF immediately and restart delay after 3 minutes.
- The system will start checking on the water flow level after operation start for 9 minutes. If water flow level is
 detected low continuously for 10 secs, the water pump and compressor will be OFF permanently and OFF/ON
 remote control LED will blink (H62 error occurs).
- When error happen, the power has to be reset to clear the error.
- If there is no error indication, the water pump shall be continuously running.
- The water pump will remain ON when compressor OFF due to thermostat OFF setting is reached.



12.2.2 Water Pump Only Operation

- Water pump only circulation can be set from the control panel SERVICE S/W when the operation is in Standby Mode.
- Press the SERVICE S/W for continuous 5sec to enter Service Mode.
- In Service Mode, select Sr:02 and press SET S/W to start water pump only operation.
- Water pump will stop operation when H62 is triggered.
- Press the OFF/ON button to stop the water pump only operation.

12.3 Pump Down Operation

Purpose

Ensure the pump down operation when relocating or disposing of the unit. The pump down operation will extract all refrigerant from the piping into the mono bloc unit.

- Pump down operation control:
 - 1 Press the SERVICE S/W for continuous 5 secs to enter Service mode.
 - 2 In service mode, select Sr:01 and press SET S/W to start Pump Down operation.
 - 3 There will be no Low Pressure error & Freeze prevention judgement during pumpdown operation.
 - 4 3 ways valve will shift to room side.
 - 5 Press the ON/OFF button to stop the unit.

12.4 Flow Switch

12.4.1 Flow Switch Control

- 1 The water flow switch serve as an overload protector that shuts down the unit when the water level is detected to be low.
- 2 Detection is Lo (0V) when there is no water flow, and detection is Hi (5V) when there is water flow.

12.5 Force Heater Mode Operation


The backup heater also serves as backup in case of malfunctioning of the Mono bloc unit.

- 1 Make sure the OFF/ON remote control LED is OFF (no operation).
- 2 Press the Force button to start the force heater mode operation.
- 3 During force heater mode, all other operations are not allowed.
- 4 Press OFF/ON button to stop the force heater mode operation.

12.6 Mono Bloc Unit Safety

12.6.1 Mono Bloc Unit Safety Control

- 1 When water pump is ON, the system will start checking flow switch status (ON/OFF).
- If the flow switch ON for 10 seconds, the system will check on the water inlet temperature for 10 seconds. If the water inlet temperature not exceeds 80°C, the water pump shall be continuously running with normal mode.
 - If the water inlet temperature exceeds 80°C for continuously 10 seconds, the water pump will be OFF immediately.
- 3 After water pump OFF for more than 10 minutes, it will be ON back and the Mono bloc unit safety control checking is restarted.



12.7 Auto Restart Control

When the power supply is cut off during the operation of Mono bloc unit, the compressor will re-operate after power supply resumes.

12.8 Indication Panel

LED	Operation	
Color	Green	
Light ON	Operation ON	
Light OFF	Operation OFF	

Note:

If Operation LED is blinking, there is an abnormality operation occurs.

12.9 Back-Up Heater Control

12.9.1 Electric Heater control

- Normal Heating Mode
 - o Heater On condition:
 - a. Heater switch is ON
 - b. After Heatpump thermo ON for [30] mins
 - c. After water pump operate [9] mins
 - d. Outdoor air temperature < Outdoor set temperature for heater
 - e. When water outlet temperature < Water set temperature + [-8°C]
 - f. [20] minutes since previous Backup heater Off
 - When heatpump cannot operate due to error happens during normal operation, heater will go into force mode automatic
 - * Heater need to operate during deice operation
 - Heater Stop Condition:
 - a. When outdoor set temperature > outdoor set temperature + [+2°C] for continuous 15 secs OR
 - b. When water out temp > water set temperature + [-2°C] for continuous 15 secs OR
 - c. Heater switch is Off OR
 - d. Heat pump thermo-off or OFF condition


2 Force Heater Mode

- o Heater On Condition:
 - a. After water pump operate [9] mins
 - b. When water outlet temperature < water set temperature + [-8°C]
 - c. [20] minutes since previous Backup heater Off
- Heater Stop condition
 - a. Force mode off OR
 - b. When water outlet temperature > water set temperature + [-2°C] for continuous 15 secs
- * Do not operate heater at the following situation
- 1 Water outlet temperature sensor, and water inlet sensor abnormal
- 2 Flow switch abnormal
- 3 Circulation pump stop condition
- 4 During Heat pump switch to tank side

12.10 Tank Booster Heater Control

12.10.1 Tank booster heater control


Heating operation condition:




- 1 Booster heater Turn On condition:
 - After BOOSTER HEATER DELAY TIMER fulfill during heat pump startup time in tank mode, or during switching from heating heat-up interval to tank heat-up interval in heat + tank mode (heating priority not set).
 - Tank temperature < tank set temperature + [-5°C],
 - o 20 minutes since previous heater off.
 - * BOOSTER HEATER DELAY TIMER is clear when tank heat-up interval end.
- 2 Booster heater Turn Off condition:
 - Tank temperature > tank set temperature + [+2°C] for continuous 15 sec.
 - When BOOSTER HEATER DELAY TIMER start count after switch from heating heat-up interval to tank heat-up interval.
 - * DELAY TIMER can be set by remote control.

12.11 Base Pan Heater Control (Optional)

• To enable the base pan heater function, pin 3 of SW2 of water system PCB has to be switched from OFF to ON position.



- Base pan heater ON condition:
 - o When outdoor ambient temperature ≤ 3°C AND
 - Deice operation ON
 Base pan heater will continue ON for 10 minutes after deice operation ends.
- Base pan heater OFF condition:
 - When outdoor ambient temperature > 3°C OR
 - When operation is not heating OR
 - o Base pan heater ON timer count completed



12.12 Three Way Valve Control

- Purpose:
 - 3 ways valve is used to change flow direction of hot water from heat pump between heating side and tank side
- Control contents:
 - 1 3 ways valve switch Off:
 - o During 3 ways valve switch Off time, the hot water will provide heat capacity to heating side.
 - 2 3 ways valve switch On:
 - During 3 ways valve switch On time, the hot water will provide heat capacity to tank side.
 - 3 Stop condition:
 - o During stop mode, 3 ways valve will be in switch off position.

12.13 Sterilization Mode

- Purpose:
 - o Boil tank temperature to customer set boiling temperature to operate sterilization.
- Control start condition:
 - Tank connection set to YES by remote controller.
 - Sterilization function selection is YES.
 - o Sterilization signal received from remote controller by timer.
- Control stop condition:
 - After boiling timer completed. Boiling timer start counting once tank achieve boiling set temperature OR
 - After 4 hours of operation since sterilization function start OR
- Control content:
 - o Once the sterilization function enable, set the target tank temperature to Boiling Set Temperature.
 - Booster heater will allow to ON during solar priority SET condition.
 - Booster heater OFF Temp. = Boiling Set Temperature 0°C
 - Booster heater ON Temp. = Boiling Set Temperature 7°C
 - The sterilization set temperature may not achieve if tank booster heater function is deactivated.
 - o Boiling timer which set by remote controller will start count after tank achieve boiling set temperature.
 - Sterilization operation will end after complete boiling timer or Max 4 hrs from function start.
 - o Target tank temperature will set back to normal tank set temperature.
 - * Tank heater control is not affected by solar pump when solar priority set.

12.14 Quiet Operation

- Purpose:
 - To provide quiet operation compare to normal operation by reduces Mono bloc unit noise.
- Starting condition:
 - 1 When quiet button is presses.
 - When quiet request ON time by weekly timer (Refer to remote control.)
- When any of above mentioned condition is achieved, this control is activated.

New target FM speed = Present target FM speed - 80 rpm

Minimum target FM speed = 200 rpm

- Cancellation condition:
 - 1 Cancel by press quiet button
 - 2 Stop by OFF/ON button
 - 3 When quiet request OFF time by weekly timer

When any of above mentioned condition is achieved, this control is cancelled.

12.15 Anti Freeze Control

- Anti freeze protection control can be select YES or NO from control panel. Default setting is YES.
- In heatpump system, there are 2 types of anti freeze control:
 - 1. Water pump circulation anti frost control
 - Water pump turns ON when **ALL** the below conditions are fulfilled:
 - Heatpump OFF (standby) OR water pump stop (Tank Mode) OR error occurs
 - Water flow switch is not abnormal
 - Outdoor ambient temp. < 3°C
 - Water inlet/outlet temp. < 6°C
 - o After 5 minutes from previous water pump OFF
 - Water pump turns OFF when ANY of the below conditions is fulfilled:
 - Outdoor ambient temp. ≥ 4°C
 - During -5°C < outdoor ambient temp. < 4°C
 - After water pump ON for 4 minutes, and water inlet/outlet temp. ≥ 8°C
 - Else, shift to backup heater anti freeze control
 - During outdoor ambient temp. < -5°C
 - After water pump ON for 4 minutes, and water inlet/outlet temp. ≥ 20°C
 - Else, shift to backup heater anti freeze control
 - However, if flow switch is abnormal (H62), then water pump circulation anti freeze control will not activate.
 - Backup heater anti freeze control:
 - Backup heater turns ON when **ALL** the below conditions are fulfilled:
 - o Water inlet/outlet temp. < 6°C
 - Water pump circulation anti freeze control activated, and water pump ON for 4 minutes
 - Backup heater turns OFF when ANY of the below conditions is fulfilled:
 - Water inlet/outlet temp. > 28°C
 - Water pump circulation anti freeze control deactivated/water pump OFF


However, if backup heater is abnormal (H70), then backup heater anti freeze control will not activate.

12.16 Solar Operation (Optional)

12.16.1 Solar Operation

- 1 Control according to preset whether Solar Priority is set or not.
- 2 When tank connection is NOT set at SETTING mode, Solar operation is disabled.
- When Pump A (from Solar pump station) is detected On through connection Y3 and Y4, then the Solar pump 3 Way Valve is requested ON (Refer to figure below).

Connecting diagram with the Solar Pump Station



12.16.2 Solar Operation Control

When solar priority is SET

- 1 Operation condition:
 - Solar pump operates if all of the following conditions are fulfilled:-
 - Power On. (regardless operation ON or OFF)
 - There is operation request from solar pump station.
 - Tank hot water temp is below solar on upper limit temp [EEPROM 1 : 70]°C.

2 Stop condition:

- Solar pump stops operating when:-
 - No power supply to unit OR
 - There is NO operation request from Solar pump station OR
 - Tank hot water temp is above solar off upper limit temp [EEPROM 2 : 77]°C.
 - * heat pump OFF OR operate to room side when solar pump operate during solar priority set.
 - * booster heater OFF when solar pump operate during solar priority set.


When solar priority is NOT SET

- 1 Operation condition:
 - a Solar pump operates if all of the following conditions are fulfilled:-
 - · Power On. (regardless operation ON or OFF).
 - There is operation request from Solar pump station.
 - Tank hot water temp is below solar on upper limit temp [EEPROM 1 : 70]°C.
 - Heat pump thermo OFF in tank mode OR Heat pump operate to room side (During Operation ON and tank mode selected).


2 Stop condition:

- a Solar pump stops operating when:
 - No power supply to unit OR
 - There is NO operation request from Solar pump station OR
 - Tank hot water temp is above solar off upper limit temp [EEPROM 2 : 77]°C.
 - Heat pump thermo ON and operate to tank side. (During Operation ON and tank mode selected).


<u>Heat + Tank Mode (Heating Priority Not Set)</u> (Solar Priority Set)




(Solar Priority Not Set)




Heat + Tank Mode (Heating Priority Set)



<u>Tank Mode</u> (Solar Priority Set)



(Solar Priority Not Set)



12.17 External Room Thermostat Control (Optional)

Purpose:


1 Better room temperature control to fulfill different temperature request by external room thermostat. Recommended external room thermostat:

Maker	Characteristic
Siemen (REV200)	Touch panel
Siemen (RAA20)	Analog

Connection external room thermostat:


Wire Connection and thermo characteristic of Siemen REV200:

Setting	L/L1 (H)	Heat Thermo	L/L2 (C)	Cool Thermo
Set Temp < Actual Temp	Open Circuit	OFF	Short Circuit	ON
Set Temp > Actual Temp	Short Circuit	ON	Open Circuit	OFF



Wire Connection and thermo characteristic of Siemen RAA20:

Setting	L/Y1 (H)	Heat Thermo	L/Y2 (C)	Cool Thermo
Set Temp < Actual Temp	Open Circuit	OFF	Short Circuit	ON
Set Temp > Actual Temp	Short Circuit	ON	Open Circuit	OFF




Control Content:

- External room thermostat control activate only when remote thermostat connection select YES by Indoor remote control.
- When indoor running heat mode, refer thermo On/Off from heating line feedback. And when indoor running cool mode, refer thermo On/Off from cooling line feedback.
- Heat pump Off immediately when receive thermo off feedback.

12.18 Two ways valve control

Functionality of 2 ways valve:

- Use to allow hot water to floor heating panel or block cold water to floor heating panel.
- Control contents:
 - 1 When indoor running in heat mode, OPEN the 2 ways valve.
 - 2 When indoor running in cool mode, CLOSE the 2 ways valve.
 - 3 Stop condition:
 - a. During stop mode, fix 2 ways valve in close condition.



- * During pump down mode, fix 2 ways valve in close condition.
- * During force mode, open 2 ways valve.
- * Recommended Parts : SFA 21/18 (Siemens)

13. Protection Control

13.1 Protection Control For All Operations

13.1.1 Time Delay Safety Control

1 The compressor will not start for three minutes after stop of operation.

13.1.2 30 Seconds Forced Operation

- 1 Once the compressor starts operation, it will not stop its operation for 30 seconds.
- 2 However, it can be stopped using remote control.

13.1.3 Total Running Current Control

- 1 When the Mono bloc unit running current exceeds X value, the compressor frequency will decrease.
- 2 If the Mono bloc unit running current does not exceed X value, the compressor frequency will return to normal operating frequency.
- 3 If the Mono bloc unit running current continue to increase till exceed Y value, compressor will stop, and if this occurs 3 times within 20 minutes, system will stop operation and OFF/ON remote control LED will blink (F16 error occurs).


	MXC0	9D3E5	MXC12D6E5	
Operation Mode	Х	Y	Х	Y
Heating	24.0	29.8	28.0	29.8
Cooling	16.0	29.8	16.7	29.8

13.1.4 IPM (Power transistor) Prevention Control

- A. Overheating Prevention Control
- 1 When the IPM temperature rises to 95°C, compressor will stop immediately.
- 2 Compressor will restart delay 3 minutes when the IPM temperature decreases to 90°C. If this condition repeats continuously 3 times within 30 minutes, system will stop operation and OFF/ON remote control LED will blink (F22 error occurs).
- B. DC Peak Current Control
- 1 When the current to IPM exceeds set value of 49A +/- 5A for MXC09D & MXC12D, compressor will stop. Compressor will restart after three minutes.
- 2 If the set value exceeds again for more than 30 seconds after the compressor restarts, operation will restart after two minutes.
- 3 If the set value exceeds again for within 30 seconds after the compressor restarts, operation will restart after one minute. If this condition repeats continuously for seven times, system will stop operation and OFF/ON remote control LED will blink (F23 error occurs).

13.1.5 Compressor Overheating Prevention Control

 The compressor operating frequency is regulated in accordance to compressor tank temperature as shown in below figures. When the compressor tank temperature exceeds 112°C, compressor will stop, and if this occurs 4 times within 30 minutes, system will stop operation and OFF/ON remote control LED will blink (F20 error occurs).




13.1.6 Low Pressure Protection Control

- Purpose:
 - To protect the system operation.
- Detection period:
 - After compressor on for 5 minutes.
- Detection conditions:
 - When detection of Tem above 30°C.
 - Calculation of average evaporation temperature (Tem).
 - Use outdoor low pressure sensor.
 - Tem use the value calculated for discharge temperature setting value.
- After detection:
 - Compressor stops restart again after 3 mins.
 - o When abnormalities continuously generated 60 times within 480 minutes.
 - o Protection is prohibited.
 - o Error H42 will be displayed.

13.1.7 High Pressure Sensor Control

- Purpose:
 - o To protect the system operation.
- Detection period:
 - o After compressor on for 1 minute.
- Detection conditions:
 - When abnormal high voltage detection, 5V or when open circuit detection 0V for 5 seconds continuously.
- After detection:
 - o When abnormality is detected continue 5 seconds, unit stop operation.
 - o OFF/ON remote control LED will blink (H64 error occurs).

13.1.8 Outside Temperature Current Control



13.1.9 Extreme Low Temperature Control

- Purpose:
 - To improve the compressor reliability during cold start and after deice when running in extreme low outdoor temperature -20°C.
- Starting condition:
 - Heating operation
 - Outdoor air temperature < -10°C
 - o Actual frequency ≥ 50Hz
 - Compressor discharge temperature < 20°C

When the above condition is fulfilled, this control is activated.

5Hz up every 30 sec. until it reaches the target frequency.

- Cancellation condition:
 - o starting condition not fulfill.
 - o Cancel the extreme low temperature control when compressor discharge sensor ≥ 60°C

13.1.10 Crank Case Heater Control

- Purpose:
 - For compressor protection during low outdoor ambient operation (during heating low temperature operation).
- Control content:
 - a. Trigger heater START condition
 - When the outdoor air temperature is 4°C or below, and discharge temperature is 12°C or below.
 - b. Resetting heater STOP condition
 - 1. when the outdoor air temperature 6°C.
 - 2. when the discharge temperature 19°C.


13.2 Protection Control For Heating Operation

13.2.1 Outdoor Air Temperature Control

The maximum current value is regulated when the outdoor air temperature rises above 14°C in order to avoid compressor overloading.

13.2.2 Deice Operation

When outdoor pipe temperature and outdoor air temperature is low, deice operation start where outdoor fan motor stop.



13.2.3 Heat-exchanger (hot water coil) protection control


- Backup heater ON condition:-
 - water inlet temperature < 18°C AND
 - outdoor ambient temperature < 10°C
- Backup heater OFF condition:
 - o water inlet temperature > 20°C OR
 - o outdoor ambient temperature > 13°C

However this control will take place 29 minutes after compressor restart.

13.3 Protection Control For Cooling Operation

13.3.1 Outdoor Air Temperature Control

- The Compressor operating frequency is regulated in accordance to the outdoor air temperature as shown in the diagram below.
- This control will begin 1 minute after the compressor starts.
- Compressor frequency will adjust base on outdoor air Temperature.



13.3.2 Freeze Prevention Control 1

- 1 When Mono bloc unit (Water System) heat exchanger temperature is lower than 0°C continuously for 10 seconds, compressor will stop operating.
- 2 Compressor will resume its operation three minutes after the Mono bloc unit (Water System) heat exchanger is higher than 1°C.
- 3 Mono bloc unit heat exchanger freeze prevention (H99) will memory in error history.

14. Servicing Mode

14.1 Test Run


- 1 Fill up the Tank Unit with water. For details refer to Tank Unit installation instruction and operation instruction.
- 2 Antifreeze agent must be added into water circuit to prevent freezing of water when outdoor ambient temperatures is low. Recommended antifreeze: Propylene glycol: 40% (equivalent to -20°C)
- 3 Set ON to the Mono bloc unit and RCCB. Then, for remote control operation please refers to (Mono bloc) Air-to-Water Heatpump's operation instruction.
- For normal operation, pressure gauge reading should be in between 0.05 MPa and 0.3 MPa. If necessary, adjust the water pump speed accordingly to obtain normal water pressure operating range. If adjust water pump speed cannot solve the problem, contact your local authorized dealer.
- 5 After test run, please clean the external filter. Reinstall it after finish cleaning.

14.2 Proper Pump Down Procedure

- Strictly follow the steps below for proper pump down procedure. Explosion may occur if the steps are not followed as per sequence.
 - 1 Press the "SERVICE" switch on remote control to enter SERVICE mode. Operate the system in Sr : 01 mode for pump down operation.
 - 2 After 10~15 minutes, (after 1 or 2 minutes in case very low ambient temperatures (< 10°C)), fully close 2 way valve.
 - 3 After 3 minutes, fully close 3 way valve.
 - 4 Press the "OFF/ON" switch on remote control to stop pump down operation.
 - 5 Remove the refrigerant piping.

14.3 How To Adjust Water Flow Rate

- Before adjust the water flow rate, make sure that the total water volume in the installation is 50 litres minimum.
- The water flow rate can be adjusted with select the water pump speed on the water pump. The default setting is medium speed (II). However, please ensure the minimum flow rate cannot be less than 18L/min.
 Adjust it to high speed (III) or slow speed (I) if necessary (e.g. reduce the noise of running water).
 Graph 5.1 shown the external static pressure (kPa) versus water flow rate (L/min).



• Flow rate characteristic of indoor unit is as per above mentioned.

14.4 Expansion Vessel Pre Pressure Checking

- Expansion Vessel with 10 L air capacity and initial pressure of 1 bar is installed in this Mono bloc unit.
- Total amount of water in system should be below 200 L. (Note: This amount of water is not include the tank unit volume)
- If total amount of water is more than 200L, please install additional expansion vessel (field supply).
- Please keep the installation height difference of system water circuit within 10 m.
 (Inner volume of same Mono bloc unit is about 5 L)

15. Maintenance Guide


In order to ensure optimal performance of the unit, seasonal inspections on the unit, external filter and field wiring have to be carried out at regular intervals. This maintenance should be carried out by authorized dealer.

1 Water pressure

Water pressure should not lower than 0.05 MPa (with inspects the pressure gauge). If necessary add tap water into tank unit. Refer to tank unit installation instruction for details on how to add water.


2 Pressure relief valve

- Take out the cover with remove the mounting screw for access to the pressure relief valve.
- Check for correction operation of pressure relief valve by turn up the lever to become horizontal (Refer to figure of "Pressure relief valve")
- o If you do not hear a clacking sound (due to water drainage), contact your local authorized dealer.
- Turn down the lever after checking finish. In case the water keeps drained out from the unit, switch off the system, and then contact your local authorized dealer.
- Reinstall the cover with tighten the mounting screws properly, if the pressure relief valve is functioning normal.



3 Air purge valve

Air purge valve must be installed at all high points in a closed water circuit system. An automatic air purge valve is provided inside the indoor unit. To automatically purge the air from the system, turn the plug on the air outlet anticlockwise by one complete turn from fully closed position. Excessive air is automatically purged if the plug is kept in this position.




4 RCCB

Ensure the RCCB set to "ON" condition before check RCCB.

Turn on the power supply to the Mono bloc unit.

This testing could only be done when power is supplied to the Mono bloc unit.



Be careful not to touch parts other than RCCB test button when the power is supplied to Mono bloc unit. Else, electrical shock may happen.

- Push the "TEST" button on the RCCB. The lever would turn down and indicate "0", if it functions normal.
- o Contact authorized dealer if the RCCB malfunction.
- o Turn off the power supply to the Mono bloc unit.
- o If RCCB functions normal, set the lever to "ON" again after testing finish.

5 Reset overload protector

Overload Protector serves the safety purpose to prevent the water over heating. When the Overload Protector trip at high water temperature, take below steps to reset it.

- o Take out OLP Cover.
- o Use a test pen to push the centre button gently in order to reset the Overload protector.
- Fix the OLP Cover to the original fixing condition.




How to reset Overload protector

6 External water filter (field supply)

Clean the external water filter in regularly basic.

- External water filter is located inside the tube connector which is before water inlet connector of Mono bloc unit (indicated with "WATER IN"). (Refer to figure below)
- Use spanner to detach the tube connector nut.
- o Take out the filter carefully so that not deforms it shape.
- Use tap water only to wash the residue on the filter. If necessary, gently use soft brush only to clean the hard dirt.
- o After clean, put it back to the original location and tighten the nut connection with torque wrench.



16. Troubleshooting Guide

16.1 Refrigeration Cycle System

In order to diagnose malfunctions, make sure that there are no electrical problems before inspecting the refrigeration cycle.


Such problems include insufficient insulation, problem with the power source, malfunction of a compressor and a fan

The normal pressure of the refrigeration cycle depends on various conditions, the standard values for them are shown in the table on the right.

Normal Pressure (Standard)

	Gas pressure MPa (kg/cm²G)
Heating Mode	2.3 ~ 2.9 (23 ~ 29)
Cooling Mode	0.9 ~ 1.2 (9 ~ 12)

- ★ Condition: Outdoor temperature 7°C at heating mode and 35°C at cooling mode.
 - Compressor operates at rated frequency.



16.2 Relationship Between The Condition Of The Mono Bloc Unit And Pressure And Electric Current

	Heating Mode			Cooling Mode		
Condition of the Mono Bloc Unit	Low Pressure	High Pressure	Electric current during operation	Low Pressure	High Pressure	Electric current during operation
Water leakage or insufficient water flow rate in the system	-	-	-	1	*	*
Excessive amount of refrigerant	*	~	-	*	*	*
Inefficient compression	1	1	*	1	1	1
Insufficient refrigerant (gas leakage)	*	*	*	*	*	*
Mono Bloc unit (Refrigerant System) heat exchange deficiency	*	*	*	-	-	-
Clogged expansion valve or Strainer	*	-	-	-	*	*

Carry out the measurements of pressure, electric current, and temperature fifteen minutes after an operation is started.

16.3 Breakdown Self Diagnosis Function

16.3.1 Self Diagnosis Function (Three Digits Alphanumeric Code)

- When abnormality occur during operation, the system will stop operation, and OFF/ON remote control LED will blink and error code will display on the remote control Timer display LCD.
- Even error code is reset by turning OFF power supply or by pressing ERROR RESET button, if the system abnormality is still un-repaired, system will again stop operation, and OFF/ON remote control LED will again blink.
- The error code will store in IC memory.

To check the error code


- 1 When an abnormality occurs, system will stop operation and OFF/ON remote control LED will blink.
- 2 Error code of the abnormality will display on the remote control Timer display LCD.
- 3 To determine the abnormality description, the Error Code Table needs to be referred.

To display past/last error code

- 1 Turn ON power supply.
- 2 Press and hold the CHECK button for more than 5 seconds to enter status mode.
- 3 Press the SEARCH DOWN/UP button to retrieve past/last error code.
- 4 Press the CANCEL button or wait 30 seconds to exit status mode.

To permanently delete error code from IC memory

- 1 Turn ON power supply.
- 2 Press and hold the ERROR RESET button for more than 8 seconds till a beep sound is heard.



16.4 Error Codes Table

Diagnosis display	Abnormality/Protection control	Abnormality Judgement	Primary location to verify	
H00	No abnormality detected	_	_	
H12	Indoor/Outdoor capacity unmatched	90s after power supply	 Indoor/outdoor connection wire Indoor/outdoor PCB Specification and combination table in catalogue 	
H15	Outdoor compressor temperature sensor abnormality	Continue for 5 sec.	Compressor temperature sensor (defective or disconnected)	
H23	Indoor refrigerant liquid temperature sensor abnormality	Continue for 5 sec.	 Refrigerant liquid temperature sensor (defective or disconnected) 	
H42	Compressor low pressure abnormality	-	 Outdoor pipe temperature sensor Clogged expansion valve or strainer Insufficient refrigerant Outdoor PCB Compressor 	
H62	Water flow switch abnormality	Continue for 1 min.	Water flow switch	
H63	Refrigerant low pressure abnormality	4 times occurrence within 20 minutes	 Outdoor low pressure sensor (defective or disconnected) 	
H64	Refrigerant high pressure abnormality	Continue for 5 sec.	 Outdoor high pressure sensor (defective or disconnected) 	
H70	Back-up heater OLP abnormality	Continue for 60 sec.	 Back-up heater OLP (Disconnection or activated) 	
H72	Tank sensor abnormal	Continue for 5 sec.	Tank sensor	
H76	Indoor - remote control communication abnormality	_	Indoor - control panel (defective or disconnected)	
H90	Indoor/outdoor abnormal communication	> 1 min after starting operation	Internal/external cable connections Indoor/Outdoor PCB	
H91	Tank heater OLP abnormality	Continue for 60 sec.	Tank heater OLP (Disconnection or activated)	
H95	Indoor/Outdoor wrong connection	_	Indoor/Outdoor supply voltage	
H98	Outdoor high pressure overload protection	_	 Outdoor high pressure sensor Water pump or water leakage Clogged expansion valve or strainer Excess refrigerant Outdoor PCB 	
H99	Indoor heat exchanger freeze prevention	_	Indoor heat exchangerRefrigerant shortage	
F12	Pressure switch activate	4 times occurrence within 20 minutes	Pressure switch	
F14	Outdoor compressor abnormal revolution	4 times occurrence within 20 minutes	Outdoor compressor	
F15	Outdoor fan motor lock abnormality	2 times occurrence within 30 minutes	Outdoor PCBOutdoor fan motor	
F16	Total running current protection	3 times occurrence within 20 minutes	Excess refrigerant Outdoor PCB	
F20	Outdoor compressor overheating protection	4 times occurrence within 30 minutes	Compressor tank temperature sensor Clogged expansion valve or strainer Insufficient refrigerant Outdoor PCB Compressor	
F22	IPM (power transistor) overheating protection	3 times occurrence within 30 minutes	Improper heat exchangeIPM (Power transistor)	
F23	Outdoor Direct Current (DC) peak detection	7 times occurrence continuously	Outdoor PCB Compressor	
F24	Refrigeration cycle abnormality	2 times occurrence within 20 minutes	Insufficient refrigerant Outdoor PCB Compressor low compression	
F25	Cooling/Heating cycle changeover abnormality	4 times occurrence within 30 minutes	4-way valve V-coil	
F27	Pressure switch abnormality	Continue for 1 min.	Pressure switch	
F36	Outdoor air temperature sensor abnormality	Continue for 5 sec.	Outdoor air temperature sensor (defective or disconnected)	
F37	Indoor water inlet temperature sensor abnormality	Continue for 5 sec.	Water inlet temperature sensor (defective or disconnected)	
F40	Outdoor discharge pipe temperature sensor abnormality	Continue for 5 sec.	Outdoor discharge pipe temperature sensor (defective or disconnected)	
F41	PFC control	4 times occurrence within 10 minutes	Voltage at PFC	

Diagnosis display	Abnormality/Protection control	Abnormality Judgement	Primary location to verify
F42	Outdoor heat exchanger temperature sensor abnormality	Continue for 5 sec.	Outdoor heat exchanger temperature sensor (defective or disconnected)
F43	Outdoor defrost sensor abnormality	Continue for 5 sec.	Outdoor defrost sensor (defective or disconnected)
F45	Indoor water outlet temperature sensor abnormality	Continue for 5 sec.	Water outlet temperature sensor (defective or disconnected)
F46	Outdoor Current Transformer open circuit	_	Insufficient refrigerant Outdoor PCB Compressor low
F48	Outdoor EVA outlet temperature sensor abnormality	Continue for 5 sec.	Outdoor EVA outlet temperature sensor (defective or disconnected)
F49	Outdoor bypass outlet temperature sensor abnormality	Continue for 5 sec.	Outdoor bypass outlet temperature sensor (defective or disconnected)
F95	Cooling high pressure overload protection	-	Outdoor high pressure sensor Water pump or water leakage Clogged expansion valve or strainer Excess refrigerant Outdoor PCB

16.5 Self-diagnosis Method

16.5.1 Connection Capability Rank Abnormality (H12)

Malfunction Decision Conditions:

During startup operation of cooling and heating, the capability rank of indoor checked by the outdoor is used to determine connection capability rank abnormality.


Malfunction Caused:

- 1 Wrong model interconnected.
- 2 Wrong indoor unit or outdoor unit PCB (main) used.
- 3 Faulty indoor unit or outdoor unit PCB (main).

Abnormality Judgment:

Continue for 90 seconds.

Troubleshooting:



16.5.2 Compressor Tank Temperature Sensor Abnormality (H15)

Malfunction Decision Conditions:

During startup and operation of cooling and heating, the temperatures detected by the compressor tank temperature sensor are used to determine sensor error.


Malfunction Caused:

- 1 Faulty connector connection.
- 2 Faulty sensor.
- 3 Faulty outdoor unit PCB (main).

Abnormality Judgment:

Continue for 5 seconds.

Troubleshooting:



16.5.3 Indoor Refrigerant Liquid Temperature Sensor Abnormality (H23)


Malfunction Decision Conditions:

During startup and operation of cooling and heating, the temperatures detected by the indoor refrigerant liquid temperature sensor are used to determine sensor error.

Malfunction Caused:

- 1 Faulty connector connection.
- 2 Faulty sensor.
- 3 Faulty indoor unit PCB (main).

Abnormality Judgment:




16.5.4 Compressor Low Pressure Protection (H42)

Malfunction Decision Conditions:

During operation of heating and after 5 minutes compressor ON, when outdoor pipe temperature below -29°C or above 26°C is detected by the outdoor pipe temperature sensor.

Malfunction Caused:

- 1 Dust accumulation on the outdoor unit heat exchanger.
- 2 Air short circuit at outdoor unit.
- 3 2 way valve partially closed.
- 4 Faulty outdoor unit fan motor.
- 5 Refrigerant shortage (refrigerant leakage).
- 6 Clogged expansion valve or strainer.
- 7 Faulty outdoor pipe temperature sensor.
- 8 Faulty outdoor unit main PCB (main).



16.5.5 Water Flow Switch Abnormality (H62)

Malfunction Decision Conditions:


During operation of cooling and heating, the water flow detected by the indoor water flow switch is used to determine water flow error.

Malfunction Caused:

- 1 Faulty water pump.
- 2 Water leak in system.
- 3 Faulty connector connection.
- 4 Faulty water flow switch.
- 5 Faulty indoor unit PCB (main).

Abnormality Judgment:

Continue for 10 seconds (but no judgment for 9 minutes after compressor startup/restart).



16.5.6 Outdoor High Pressure Abnormality (H64)

Malfunction Decision Conditions:


During operation of cooling and heating, when the outdoor high pressure sensor output signal is 0Vdc or 5Vdc.

Malfunction Caused:

- 1 Faulty connector connection.
- 2 Faulty sensor.
- 3 Faulty outdoor unit PCB (main).

Abnormality Judgment:

Continue 4 times in 20 minutes.



16.5.7 Indoor Backup Heater OLP Abnormality (H70)


Malfunction Decision Conditions:

During operation of indoor backup heater, when no power supplies to indoor backup heater or OLP open circuit.

Malfunction Caused:

- 1 Faulty power supply connector connection.
- 2 Faulty connector connection.
- 3 Faulty indoor backup heater overload protector (OLP).
- 4 Faulty indoor unit PCB (main).

Abnormality Judgment:



16.5.8 Tank Temperature Sensor Abnormality (H72)


Malfunction Decision Conditions:

When tank connection is set to ON, the temperatures detected by the tank temperature sensor are used to determine sensor error.

Malfunction Caused:

- 1 Faulty connector connection.
- 2 Faulty sensor.
- 3 Faulty indoor unit PCB (main).

Abnormality Judgment:



16.5.9 Indoor-Remote Control Communication Abnormality (H76)

Malfunction Decision Conditions:

During standby and operation of cooling and heating, indoor-remote control error occur.


Malfunction Caused:

- 1 Faulty connector connection.
- 2 Faulty remote control.
- 3 Faulty indoor unit PCB (main).

Troubleshooting:



For safety reason and to prevent component breakdown, always switch off the power before remove and connect the component.



16.5.10 Indoor/Outdoor Abnormal Communication (H90)

Malfunction Decision Conditions:

During operation of cooling and heating, the data received from outdoor unit in indoor unit signal transmission is checked whether it is normal.

Malfunction Caused:

- 1 Faulty outdoor unit PCB (main).
- 2 Faulty indoor unit PCB (main).
- 3 Indoor-outdoor signal transmission error due to wrong wiring.
- 4 Indoor-outdoor signal transmission error due to breaking of wire in the connection wires between the indoor and outdoor units.
- 5 Indoor-outdoor signal transmission error due to disturbed power supply waveform.

Abnormality Judgment:

Continue for 1 minute after operation.

For safety reason and to prevent component breakdown, **Troubleshooting:** always switch off the power before remove and connect the component. Check the indoor-outdoor units connection wires. Yes Correct the indoor-outdoor Is there any wiring error? units connection wires. No Turn OFF the power and disconnect terminal 3 wire. Turn ON the power and measure Vdc between terminal 2 & 3 from the outdoor unit. No Is the Vdc fluctuate Replace the outdoor unit between 45-60Vdc? PCB (main). Yes Turn OFF the power and reconnect terminal 3 wire. Turn ON the power and again measure Vdc between terminal 2 & 3 from the outdoor unit. No Is the Vdc fluctuate Replace the indoor unit between 15-60Vdc? PCB (main).

16.5.11 Tank Booster Heater OLP Abnormality (H91)


Malfunction Decision Conditions:

During operation of tank booster heater, and tank booster heater OLP open circuit.

Malfunction Caused:

- 1 Faulty connector connection.
- 2 Faulty tank booster heater overload protector (OLP).
- 3 Faulty indoor unit PCB (main).

Abnormality Judgment:




16.5.12 Unspecified Voltage between Indoor and Outdoor (H95)

Malfunction Decision Conditions:

The supply power is detected for its requirement by the indoor/outdoor transmission.

Malfunction Caused:

- 1 Insufficient power supply.
- 2 Faulty outdoor unit PCB (noise filter/main).




16.5.13 Outdoor High Pressure Protection (H98)

Malfunction Decision Conditions:

During operation of heating, when pressure 4.0 MPa and above is detected by outdoor high pressure sensor.

Malfunction Caused:

- 1 Faulty water pump.
- 2 Insufficient water flow rate in system.
- 3 Water leak in system.
- 4 2/3 way closed.
- 5 Clogged expansion valve or strainer.
- 6 Excessive refrigerant.
- 7 Faulty outdoor high pressure sensor.
- 8 Faulty outdoor unit PCB (main).



16.5.14 Indoor Freeze-up Protection (H99)

Malfunction Decision Conditions:

During anti-freezing control in cooling operation, when the indoor refrigerant liquid temperature < 0°C.

Malfunction Caused:

- 1 Faulty water pump.
- 2 Insufficient water flow rate in system.
- 3 Water leak in system.
- 4 2 way valve partially closed.
- 5 Clogged expansion valve or strainer.
- 6 Refrigerant shortage (refrigerant leakage).
- 7 Faulty indoor refrigerant liquid temperature sensor.
- 8 Faulty indoor unit PCB (main).

For safety reason and to prevent component breakdown, **Troubleshooting:** always switch off the power before remove and connect the component. Check the system water pump Check for clogged expansion valve or strainer. Replace the faulty water Is the water pump working? - Replace the expansion pump. Yes Is the expansion valve or valve and/or strainer ▼ Yes strainer clogged (ice formed)? - Reclaim and recharge Check the system water refrigerant **↓** No flow rate. Check refrigerant amount. Is the water pump speed Nο Readjust the water pump adjusted according to system speed. hydraulic external static pressure? Is the additional refrigerant Reclaim and recharge with amount filled correctly? correct amount of refrigerant. Yes **♦** Yes Check the system water passage. Check the indoor refrigerant liquid temperature sensor Fix the system water Is there any water leakage? leakage. Does it conform to the **♦** No sensor characteristic chart? Yes Replace the indoor unit PCB Check the 2 way valve. (main). No Yes Is the 2 way valve partially Replace the indoor refrigerant Open the 2 way valve. closed? liquid temperature sensor. No

16.5.15 Outdoor High Pressure Switch Activate (F12)

Malfunction Decision Conditions:

During operation of cooling and heating, when pressure 4.5MPa and above is detected by outdoor high pressure switch.

Malfunction Caused:

- 1 Dust accumulation on the outdoor unit heat exchanger.
- 2 Air short circuit at outdoor unit.
- 3 Faulty water pump.
- 4 Insufficient water flow rate in system.
- 5 Water leak in system.
- 6 2/3 way valve closed.
- 7 Clogged expansion valve or strainer.
- 8 Excessive refrigerant.
- 9 Faulty outdoor high pressure sensor and switch.
- 10 Faulty outdoor unit PCB.


Abnormality Judgment:

Continue 4 times in 20 minutes.

Troubleshooting:



For safety reason and to prevent component breakdown, always switch off the power before remove and connect the component.



16.5.16 Compressor Rotation Failure (F14)

Malfunction Decision Conditions:


A compressor rotation failure is detected by checking the compressor running condition through the position detection circuit.

Malfunction Caused:

- 1 Compressor terminal disconnect.
- 2 Faulty outdoor unit PCB (main).
- 3 Faulty compressor.

Abnormality Judgment:

Continue 4 times in 20 minutes.



16.5.17 Outdoor Fan Motor (DC Motor) Mechanism Locked (F15)

Malfunction Decision Conditions:


The rotation speed detected by the Hall IC of the fan motor during fan motor operation is used to determine abnormal fan motor (feedback of rotation > 2550rpm or < 50rpm).

Malfunction Caused:

- 1 Operation stop due to short circuit inside the fan motor winding.
- 2 Operation stop due to breaking of wire inside the fan motor.
- 3 Operation stop due to breaking of fan motor lead wires.
- 4 Operation stop due to fan motor Hall IC malfunction.
- 5 Operation error due to faulty outdoor unit PCB.

Abnormality Judgment:

Continue 2 times in 30 minutes.



16.5.18 Input Over Current Detection (F16)

Malfunction Decision Conditions:


During operation of cooling and heating, when outdoor current above 27.9A is detected by the current transformer (CT) in the outdoor unit PCB.

Malfunction Caused:

- 1 Excessive refrigerant.
- 2 Faulty outdoor unit PCB (main).

Abnormality Judgment:

Continue 3 times in 20 minutes.



16.5.19 Compressor Overheating (F20)

Malfunction Decision Conditions:

During operation of cooling and heating, when temperature above 112°C is detected by the compressor tank temperature sensor.

Malfunction Caused:

- 1 Faulty compressor tank temperature sensor.
- 2 2/3 way valve closed.
- 3 Refrigerant shortage (refrigerant leakage).
- 4 Clogged expansion valve or strainer.
- 5 Faulty outdoor unit PCB (main).
- 6 Faulty compressor.


Abnormality Judgment:

Continue 4 times in 30 minutes.

Troubleshooting:



For safety reason and to prevent component breakdown, always switch off the power before remove and connect the component.



16.5.20 IPM Overheating (F22)

Malfunction Decision Conditions:

During operation of cooling and heating, when temperature 95°C is detected by the outdoor IPM temperature sensor.

Malfunction Caused:

- 1 Faulty outdoor unit fan motor.
- 2 Faulty outdoor unit PCB (main).


Abnormality Judgment:

Continue 3 times in 30 minutes.

Troubleshooting:



For safety reason and to prevent component breakdown, always switch off the power before remove and connect the component.



16.5.21 Output Over Current Detection (F23)

Malfunction Decision Conditions:


During operation of cooling and heating, when outdoor DC current is above $40.1 \pm 5.0 \text{A}$ (for: UD07~09CE) OR $44.7 \pm 5.0 \text{A}$ (for: UD12~16CE) is detected by the IPM DC Peak sensing circuitry in the outdoor unit PCB (main).

Malfunction Caused:

- 1 Faulty outdoor unit PCB (main).
- 2 Faulty compressor.

Abnormality Judgment:

Continue for 7 times.



16.5.22 Refrigeration Cycle Abnormality (F24)

Malfunction Decision Conditions:

- 1 During operation of cooling and heating, compressor frequency > Frated.
- 2 During operation of cooling and heating, running current: 0.65A < I < 1.65A.
- 3 During operation of cooling, water inlet temperature indoor refrigerant liquid temperature < 5°C.
- 4 During operation of heating, indoor refrigerant liquid temperature water inlet temperature < 5°C.

Malfunction Caused:

- 1 Faulty water inlet or indoor refrigerant liquid temperature sensors.
- 2 2/3 way valve closed.
- 3 Refrigerant shortage (refrigerant leakage).
- 4 Clogged expansion valve or strainer.
- 5 Faulty outdoor unit PCB (main).
- 6 Poor compression of compressor.

Abnormality Judgment:

Continue 2 times in 20 minutes.

For safety reason and to prevent component breakdown, **Troubleshooting:** always switch off the power before remove and connect the component. Check the water inlet and indoor ref. liquid temperature sensors. Check for clogged Does it conform to the Replace the water inlet or indoor expansion valve or strainer. sensor characteristic chart? ref. liquid temperature sensor. Yes - Replace expansion valve Yes Is the expansion valve or and/or strainer Check the 2/3 way valve. strainer clogged (ice formed)? - Reclaim and recharge refrigerant Yes Reclaim and recharge for a Is the 2/3 way valve closed? Open the 2/3 way valve. specified amount of fresh refrigerant. - Replace the outdoor unit Is abnormality happened PCB (main) Check for gas leakage. again? - Replace the compressor No - Repair the pipe flare or Yes Procedure complete Is the oil oozing out from union nuts the 2/3 way valve? - Reclaim and recharge refrigerant No

16.5.23 Four Way Valve Abnormality (F25)

Malfunction Decision Conditions:


- 1 During heating operation, when the indoor pipe temperature of thermostat ON indoor unit < 0°C.
- 2 During cooling operation, when the indoor pipe temperature of thermostat ON indoor unit > 45°C.

Malfunction Caused:

- 1 Faulty sensor.
- 2 Faulty connector connection.
- 3 Faulty outdoor unit PCB (noise filter/main).
- 4 Faulty four way valve.

Abnormality Judgment:

Continue 4 times in 30 minutes.



16.5.24 Outdoor High Pressure Switch Abnormal (F27)

Malfunction Decision Conditions:


During compressor stop, and outdoor high pressure switch is remain opened.

Malfunction Caused:

- 1 Faulty connector connection.
- 2 Faulty switch.
- 3 Faulty outdoor unit PCB (main).

Abnormality Judgment:

Continue for 1 minute.



16.5.25 Outdoor Air Temperature Sensor Abnormality (F36)


Malfunction Decision Conditions:

During startup and operation of cooling and heating, the temperatures detected by the outdoor air temperature sensor are used to determine sensor error.

Malfunction Caused:

- 1 Faulty connector connection.
- 2 Faulty sensor.
- 3 Faulty outdoor unit PCB (main).

Abnormality Judgment:



16.5.26 Indoor Water Inlet Temperature Sensor Abnormality (F37)


Malfunction Decision Conditions:

During startup and operation of cooling and heating, the temperatures detected by the indoor water inlet temperature sensor are used to determine sensor error.

Malfunction Caused:

- 1 Faulty connector connection.
- 2 Faulty sensor.
- 3 Faulty indoor unit PCB (main).

Abnormality Judgment:



16.5.27 Outdoor Discharge Pipe Temperature Sensor Abnormality (F40)


Malfunction Decision Conditions:

During startup and operation of cooling and heating, the temperatures detected by the outdoor discharge pipe temperature sensor are used to determine sensor error.

Malfunction Caused:

- 1 Faulty connector connection.
- 2 Faulty sensor.
- 3 Faulty outdoor unit PCB (main).

Abnormality Judgment:



16.5.28 Power Factor Correction (PFC) Abnormality (F41)

Malfunction Decision Conditions:


During operation of cooling and heating, when the PFC protection circuitry in the outdoor unit PCB (main) senses abnormal high DC voltage level.

Malfunction Caused:

- 1 Power supply surge.
- 2 Compressor windings not uniform.
- 3 Faulty outdoor unit PCB (main).

Abnormality Judgment:

Continue 4 times in 10 minutes.



16.5.29 Outdoor Pipe Temperature Sensor Abnormality (F42)

Malfunction Decision Conditions:


During startup and operation of cooling and heating, the temperatures detected by the outdoor pipe temperature sensor are used to determine sensor error.

Malfunction Caused:

- 1 Faulty connector connection.
- 2 Faulty sensor.
- 3 Faulty outdoor unit PCB (main).

Abnormality Judgment:

Continue for 5 seconds.



16.5.30 Outdoor Defrost Temperature Sensor Abnormality (F43)

Malfunction Decision Conditions:


During startup and operation of cooling and heating, the temperatures detected by the outdoor defrost temperature sensor are used to determine sensor error.

Malfunction Caused:

- 1 Faulty connector connection.
- 2 Faulty sensor.
- 3 Faulty outdoor unit PCB (main).

Abnormality Judgment:

Continue for 5 seconds.



16.5.31 Indoor Water Outlet Temperature Sensor Abnormality (F45)

Malfunction Decision Conditions:


During startup and operation of cooling and heating, the temperatures detected by the indoor water outlet temperature sensor are used to determine sensor errors.

Malfunction Caused:

- 1 Faulty connector connection.
- 2 Faulty sensor.
- 3 Faulty indoor unit PCB (main).

Abnormality Judgment:

Continue for 5 seconds.



16.5.32 Outdoor Current Transformer Open Circuit (F46)

Malfunction Decision Conditions:


A current transformer (CT) open circuit is detected by checking the compressor running frequency (≥ rated frequency) and CT detected input current (< 0.65A) for continuously 20 seconds.

Malfunction Caused:

- 1 CT defective.
- 2 Faulty outdoor unit PCB.
- 3 Compressor defective (low compression).

Abnormality Judgment:

Continue 3 times in 20 seconds.



16.5.33 Cooling High Pressure Overload Protection (F95)

Malfunction Decision Conditions:

During operation of cooling, when pressure 4.0MPa and above is detected by outdoor high pressure sensor.


Malfunction Caused:

- 1 Dust accumulation in the outdoor unit heat exchanger.
- 2 Air short circuit at outdoor unit.
- 3 2 way valve closed.
- 4 Faulty outdoor unit fan motor.
- 5 Clogged expansion valve or strainer.
- 6 Excessive refrigerant.
- 7 Faulty outdoor high pressure sensor.
- 8 Faulty outdoor unit PCB (main).

Troubleshooting:



For safety reason and to prevent component breakdown, always switch off the power before remove and connect the component.



17. Disassembly and Assembly Instructions

∧ v

WARNING


High Voltage are generated in the electrical parts area by the capacitor. Ensure that the capacitor has discharged sufficiently before proceeding with repair work. Failure to heed this caution may result in electric shocks.




WARNING

Be sure to switch off all the power supply before performing each of the below action.


17.1 To Remove The Cabinet Front Plate



17.2 To Remove The Cabinet Top Plate




17.3 To Remove The Cabinet Rear Plate



17.4 To Remove Pressure Gauge



17.5 To Remove RCCB




17.6 To Remove Transformer and Electronic Controller Board


1) Disconnect the 2 lead wire T1, T2 (Black) and connector CN-T1 (White) from the Electronic Controller Board.

Transformer

2) Remove 4 screws to remove Transformer.




17.7 To Remove Pressure Relief Valve and Air Purge Valve




⚠ When reinstall the water pipe, use grease or water at the joining.

17.8 To Remove Flow Switch




⚠ When reinstall the water pipe, use grease or water at the joining.

17.9 To Remove Water Pump



⚠ When reinstall the water pipe, use grease or water at the joining.

17.10 To Remove Bottle Complete



⚠ When reinstall the water pipe, use grease or water at the joining.

18. Technical Data

18.1 Operation Characteristics


18.1.1 WH-MXC09D3E5 (WH-MXC09D3E5-1)

Heating Characteristics at Different Outdoor Air Temperature

Condition

Outdoor air temperature : 7°C (DBT), 6°C (WBT)

Indoor water inlet temperature : 30°C Indoor water outlet temperature : 35°C




Cooling Characteristics at Different Outdoor Air Temperature

Condition

Outdoor air temperature : 35°C (DBT), -°C (WBT)

Indoor water inlet temperature : 12°C Indoor water outlet temperature : 7°C




18.1.2 WH-MXC12D6E5 (WH-MXC12D6E5-1)

Heating Characteristics at Different Outdoor Air Temperature

Condition

Outdoor air temperature : 7°C (DBT), 6°C (WBT)

Indoor water inlet temperature : 30°C Indoor water outlet temperature : 35°C




Cooling Characteristics at Different Outdoor Air Temperature

Condition

Outdoor air temperature : 35°C (DBT), -°C (WBT)

Indoor water inlet temperature : 12°C Indoor water outlet temperature : 7°C



18.2 Heating Capacity Table

18.2.1 WH-MXC09D3E5 (WH-MXC09D3E5-1)

Water Out	30)	35	;	40)	45	5	50		55	
Outdoor Air	Capacity	Input Power										
-15	9000	3280	9000	3550	9000	3950	9000	4340	9000	4770	9000	5200
-7	9000	2750	9000	3200	9000	3660	9000	4110	9000	4310	9000	4500
2	9000	2400	9000	2550	9000	2820	9000	3090	9000	3600	9000	4110
7	9000	1680	9000	1900	9000	2200	9000	2500	9000	2880	9000	3100
25	13600	1540	13600	1750	13200	1970	12800	2180	12000	2450	11200	2710

18.2.2 WH-MXC12D6E5 (WH-MXC12D6E5-1)

Water Out	30)	35	;	40)	45	5	50		55	
Outdoor Air	Capacity	Input Power										
-15	12000	4790	12000	5000	11500	5210	11000	5420	10700	5860	10500	6300
-7	12000	3890	12000	4450	12000	5020	12000	5580	12000	5940	12000	6300
2	12000	3230	12000	3530	12000	3910	12000	4290	12000	4900	12000	5510
7	12000	2220	12000	2570	12000	3000	12000	3430	12000	3820	12000	4200
25	13600	1590	13600	1800	13400	2140	13200	2470	12600	2700	12000	2930

18.3 Cooling Capacity Table


18.3.1 WH-MXC09D3E5 (WH-MXC09D3E5-1)

W	ater In	1	2	19		2	3
Wa	ater Out 7		14		18		
Ħ	°C	Q	IP	Q	IP	Q	IP
ojer	18	7.00	1.40	7.67	1.24	8.30	1.14
Ambient	25	7.65	1.95	9.95	1.88	10.11	1.88
۵	35	7.00	2.25	8.28	2.29	9.00	2.30
0	43	6.25	2.70	7.67	2.73	8.57	2.78

18.3.2 WH-MXC12D6E5 (WH-MXC12D6E5-1)


Wa	ater In	12		19		23	
Wa	/ater Out 7		14		18		
nt	°C	Q	IP	Q	IP	Q	IP
bier	18	7.50	1.45	12.20	1.92	13.48	1.98
Amł	25	8.90	2.20	15.25	3.07	16.52	3.19
D,	35	10.00	3.60	11.60	3.70	12.50	3.75
0	43	8.00	3.05	9.24	3.33	10.09	3.33


18.4 Hydraulic Pump Performance




19. Exploded View and Replacement Parts List

19.1 (Refrigerant System)







Note:

- The above exploded view is for the purpose of parts disassembly and replacement. The non-numbered parts are not kept as standard service parts.

< Model: Refrigerant System >


REF. NO.	DESCRIPTION & NAME	QTY.	WH-MXC09D3E5 (WH-MXC09D3E5-1)	WH-MXC12D6E5 (WH-MXC12D6E5-1)	REMARKS
1	BASE PAN ASS'Y	1	CWD52K1276	←	
2	COMPRESSOR	1	5JD420XAA22	←	0
3	BUSHING - COMPRESSOR MOUNT	3	CWH50055	←	
4	NUT-COMPRESSOR MOUNT	3	CWH561049	←	
4a	GASKET FOR TERMINAL COVER	3	CWB811017	←	
5	CRANKCASE HEATER	1	CWA341053	←	
6	CONDENSER COMPLETE	1	CWB32C3035	←	
7	HIGH PRESSURE SENSOR	1	CWA50C2570	←	
8	DISCHARGE MUFFLER	1	CWB121014	←	
9	PRESSURE SWITCH	1	CWA101013	←	
10	3-WAYS VALVE (GAS)	1	CWB011700	←	0
11	4-WAYS VALVE	1	CWB001046	←	0
12	3-WAYS VALVE	1	CWB011699	←	
13	STRAINER	4	CWB111032	←	
20	SOUND PROOF MATERIAL	1	CWG302265	←	
21	SOUND PROOF MATERIAL	1	CWG302266	←	
22	SOUND PROOF BOARD	1	CWH15K1019	←	
23	V-COIL COMPLETE – 4-WAYS VALVE	1	CWA43C2169J	←	0
24	V-COIL COMPLETE – EXP. VALVE	1	CWA43C2385	←	0
25	SENSOR-COMP. TEMP/COIL	1	CWA50C2730	←	0
26	SENSOR-COMP.DISCHARGE	1	CWA50C2576	←	0
27	SENSOR-COMPLETE	1	CWA50C2629	←	0
27a	SENSOR-COMP.	1	CWA50C2577	←	0
28	CABINET REAR PLATE-COMPLETE	1	CWE02K1019A	←	
29	CONTROL BOARD CASING	1	CWH10K1049	· ←	
31	TERMINAL BOARD ASS'Y	1	CWA28K1213	· ←	0
36	ELECTRONIC CONTROLLER (CAPACITOR)	1	CWA746082	· ←	0
38	ELECTRONIC CONTROLLER (NOISE FILTER)	1	CWA745446	· ←	0
44	ELECTRONIC CONTROLLER (MAIN)	1	CWA73C5731R	CWA73C5732R	0
46	REACTOR	1	G0C592J00006		0
47	REACTOR	1	G0C592J00007	←	0
48	TERMINAL COVER	1	CWH171039A	← ←	0
49	NUT-TERMINAL COVER	1	CWH7080300J		
50	FAN MOTOR BRACKET	1	CWD54K1024	←	
	SCREW-FAN MOTOR BRACKET			←	
50a		2	CWH551040J	←	0
53	FAN MOTOR	1	EHDS80AAC	←	0
54	FAN MOTOR	1	EHDS80BAC	←	0
54a	SCREW-FAN MOTOR MOUNT	8	CWH551323	←	
55	PROPELLER FAN ASSY	2	CWH00K1006	←	
56	NUT	2	CWH561092	←	
57	CABINET FRONT PLATE	1	CWE061098A	←	
58	DISCHARGE GRILLE	2	CWE201073	←	
59	CABINET SIDE PLATE ASSY	1	CWE04K1023A	←	
60	WIRE NET	1	CWD041103A	←	
61	CABINET TOP PLATE CO.	1	CWE03C1105	←	
62	ACCESSORY - COMPLETE	1	CWH82C1839	←	
66	CABINET FRONT PLATE	1	CWE061274A	←	
67	HANDLE	2	CWE161014	←	
68	TUBE ASSY (CAP. TUBE)	1	CWT07K1541	←	
70	EXPANSION VALVE	1	CWB051028	←	0
71	EXPANSION VALVE	1	CWB051029	←	
72	ELECTRO MAGNETIC SWITCH	1	K6C1AYY00003	←	0
75	ACCESSORY CO. (DRAIN ELBOW)	1	CWG87C2030	←	


REF. NO.	DESCRIPTION & NAME	QTY.	WH-MXC09D3E5 (WH-MXC09D3E5-1)	WH-MXC12D6E5 (WH-MXC12D6E5-1)	REMARKS
76	CRANKCASE HEATER (BASE PAN)	1	CWA341071	←	
77	V-COIL COMPLETE	1	CWA43C2335	←	0
78	SENSOR - COMP.	1	CWA50C2807	←	0
79	TERMINAL BOARD ASS'Y	1	CWA28K1238	←	0
80	SOUND PROOF MATERIAL	1	CWG302598	←	
81	SOUND PROOF MATERIAL	1	CWG302599	←	

Note:

- All parts are supplied from PAPAMY, Malaysia (Vendor Code: 00029488). "O" marked parts are recommended to be kept in stock.

19.2 (Water System)





Note:

- The above exploded view is for the purpose of parts disassembly and replacement. The non-numbered parts are not kept as standard service parts.

< Model: Water System >

REF. NO.	DESCRIPTION & NAME	QTY.	WH-MXC09D3E5 (WH-MXC09D3E5-1)	WH-MXC12D6E5 (WH-MXC12D6E5-1)	REMARK
1	BASE PAN ASS'Y	1	CWD52K1242	←	
2	HOT WATER COIL-COMPLETE	1	CWB90C1046	←	
3	RECEIVER	1	CWB141039	←	
4	FLOAT (FLOW SWITCH)	1	CWB601008	←	
9	PUMP	1	CWB532096	←	0
16	BOTTLE COMP.	1	CWH90C0034	CWH90C0033	
17	HEATER ASS'Y	1	CWA34K1026	CWA34K1025	
18	SOUND PROOF MATERIAL	1	CWG302593	CWG302592	
18a	SOUND PROOF MATERIAL	1	CWG302594	←	
19	THERMOSTAT	2	CWA151065	←	0
20	ELECTRONIC CONTROLLER (MAIN)	1	CWA73C6753R	CWA73C6754R	0
21	TERMINAL BOARD ASS'Y	1	CWA28K1200	←	0
25	TERMINAL BOARD ASS'Y	1	CWA28K1211	←	0
26	TERMINAL BOARD ASS'Y	1	CWA28K1221	←	0
27	MAGNET RELAYS	1	K6C1AYY00004	←	0
28	TERMINAL BOARD ASS'Y	1	CWA28K1222	←	0
29	CIRCUIT BREAKER	2	CWA181005	←	0
30	TRANSFORMER-COMPLETE	1	CWA40C1096	←	0
31	SENSOR-COMPLETE	1	CWA50C2749	←	0
32	REMOTE CONTROL COMPLETE	1	CWA75C4020	←	0
33	PRESSURE GAUGE	1	CWB070001	←	0
34	PRESSURE RELIEF VALVE	1	CWB621092	←	
35	PRESSURE RELIEF VALVE	1	CWB621094	←	
36	TERMINAL BOARD ASS'Y	1	CWA28K1232	←	
39	OPERATING INSTRUCTION	1	CWF568656	←	
40	INSTALLATION INSTRUCTION	1	CWF615444	←	
42	TUBE CONNECTOR-COMPLETE	1	CWT29C1050	←	
43	TUBE CONNECTOR-COMPLETE	1	CWT29C1064	←	
44	CONTROL BOARD COVER	1	CWH131420A	←	
45	HANDLE	2	CWE161014	←	
46	CABINET SIDE PLATE ASS'Y	1	CWE04K1060A	←	
47	CABINET FRONT PLATE	1	CWE061275A	←	
48	HOLDER COUPLING	1	CWH351181A	←	

Note:

- All parts are supplied from PAPAMY, Malaysia (Vendor Code: 00029488).
- "O" marked parts are recommended to be kept in stock.